


Duty Cycle NVNT ac20 5260MHz Ant3




Duty Cycle NVNT ac20 5280MHz Ant1




Duty Cycle NVNT ac20 5280MHz Ant2




Duty Cycle NVNT ac20 5280MHz Ant3




Duty Cycle NVNT ac20 5320MHz Ant1




Duty Cycle NVNT ac20 5320MHz Ant2




Duty Cycle NVNT ac20 5320MHz Ant3




Duty Cycle NVNT ac40 5270MHz Ant1




Duty Cycle NVNT ac40 5270MHz Ant2




Duty Cycle NVNT ac40 5270MHz Ant3




Duty Cycle NVNT ac40 5310MHz Ant1




Duty Cycle NVNT ac40 5310MHz Ant2




Duty Cycle NVNT ac40 5310MHz Ant3




Duty Cycle NVNT ac80 5290MHz Ant1




Duty Cycle NVNT ac80 5290MHz Ant2




Duty Cycle NVNT ac80 5290MHz Ant3




Duty Cycle NVNT ax160 5250MHz Ant1




Duty Cycle NVNT ax160 5250MHz Ant2




Duty Cycle NVNT ax160 5250MHz Ant3




Duty Cycle NVNT ax20 5260MHz Ant1




Duty Cycle NVNT ax20 5260MHz Ant2




Duty Cycle NVNT ax20 5260MHz Ant3




Duty Cycle NVNT ax20 5280MHz Ant1




Duty Cycle NVNT ax20 5280MHz Ant2




Duty Cycle NVNT ax20 5280MHz Ant3




Duty Cycle NVNT ax20 5320MHz Ant1




Duty Cycle NVNT ax20 5320MHz Ant2




Duty Cycle NVNT ax20 5320MHz Ant3




Duty Cycle NVNT ax40 5270MHz Ant1




Duty Cycle NVNT ax40 5270MHz Ant2




Duty Cycle NVNT ax40 5270MHz Ant3




Duty Cycle NVNT ax40 5310MHz Ant1




Duty Cycle NVNT ax40 5310MHz Ant2




Duty Cycle NVNT ax40 5310MHz Ant3




Duty Cycle NVNT ax80 5290MHz Ant1



Duty Cycle NVNT ax80 5290MHz Ant2




Duty Cycle NVNT ax80 5290MHz Ant3




Test Graphs


Duty Cycle NVNT a 5500MHz Ant1




Duty Cycle NVNT a 5500MHz Ant2




Duty Cycle NVNT a 5500MHz Ant3




Duty Cycle NVNT a 5600MHz Ant1




Duty Cycle NVNT a 5600MHz Ant2




Duty Cycle NVNT a 5600MHz Ant3




Duty Cycle NVNT a 5700MHz Ant1




Duty Cycle NVNT a 5700MHz Ant2




Duty Cycle NVNT a 5700MHz Ant3




Duty Cycle NVNT n20 5500MHz Ant1




Duty Cycle NVNT n20 5500MHz Ant2




Duty Cycle NVNT n20 5500MHz Ant3




Duty Cycle NVNT n20 5600MHz Ant1




Duty Cycle NVNT n20 5600MHz Ant2




Duty Cycle NVNT n20 5600MHz Ant3




Duty Cycle NVNT n20 5700MHz Ant1




Duty Cycle NVNT n20 5700MHz Ant2




Duty Cycle NVNT n20 5700MHz Ant3




Duty Cycle NVNT n40 5510MHz Ant1




Duty Cycle NVNT n40 5510MHz Ant2




Duty Cycle NVNT n40 5510MHz Ant3




Duty Cycle NVNT n40 5590MHz Ant1




Duty Cycle NVNT n40 5590MHz Ant2




Duty Cycle NVNT n40 5590MHz Ant3




Duty Cycle NVNT n40 5670MHz Ant1




Duty Cycle NVNT n40 5670MHz Ant2




Duty Cycle NVNT n40 5670MHz Ant3




Duty Cycle NVNT ac20 5500MHz Ant1




Duty Cycle NVNT ac20 5500MHz Ant2




Duty Cycle NVNT ac20 5500MHz Ant3




Duty Cycle NVNT ac20 5600MHz Ant1




Duty Cycle NVNT ac20 5600MHz Ant2




Duty Cycle NVNT ac20 5600MHz Ant3




Duty Cycle NVNT ac20 5700MHz Ant1




Duty Cycle NVNT ac20 5700MHz Ant2




Duty Cycle NVNT ac20 5700MHz Ant3




Duty Cycle NVNT ac40 5510MHz Ant1




Duty Cycle NVNT ac40 5510MHz Ant2




Duty Cycle NVNT ac40 5510MHz Ant3




Duty Cycle NVNT ac40 5590MHz Ant1




Duty Cycle NVNT ac40 5590MHz Ant2




Duty Cycle NVNT ac40 5590MHz Ant3




Duty Cycle NVNT ac40 5670MHz Ant1




Duty Cycle NVNT ac40 5670MHz Ant2




Duty Cycle NVNT ac40 5670MHz Ant3




Duty Cycle NVNT ac80 5530MHz Ant1




Duty Cycle NVNT ac80 5530MHz Ant2




Duty Cycle NVNT ac80 5530MHz Ant3




Duty Cycle NVNT ac80 5610MHz Ant1




Duty Cycle NVNT ac80 5610MHz Ant2




Duty Cycle NVNT ac80 5610MHz Ant3




Duty Cycle NVNT ax160 5570MHz Ant1




Duty Cycle NVNT ax160 5570MHz Ant2




Duty Cycle NVNT ax160 5570MHz Ant3




Duty Cycle NVNT ax20 5500MHz Ant1




Duty Cycle NVNT ax20 5500MHz Ant2




Duty Cycle NVNT ax20 5500MHz Ant3




Duty Cycle NVNT ax20 5600MHz Ant1




Duty Cycle NVNT ax20 5600MHz Ant2




Duty Cycle NVNT ax20 5600MHz Ant3




Duty Cycle NVNT ax20 5700MHz Ant1




Duty Cycle NVNT ax20 5700MHz Ant2




Duty Cycle NVNT ax20 5700MHz Ant3



Duty Cycle NVNT ax40 5510MHz Ant1



Duty Cycle NVNT ax40 5510MHz Ant2



Duty Cycle NVNT ax40 5510MHz Ant3

