Tronsmart

MIRTUNE S100

PORTABLE
OUTDOOR SPEAKER

USER MANUAL

Button Configuration





*Poke for 2s with a needle or card pin to reset.

How to Use



Turn on/Turn off: Press for 2s.

Switch LED Lighting Modes: Press once to switch among lighting modes & light-off mode
*Kindly note that you could double press to turn it off.

Enter SoundPulse EQ Mode: Press once

Exit SoundPulse EQ Mode: Press once

Disconnect from Bluetooth: Press Once

Enter Stereo Pairing Mode: Press for 3s

Exit Stereo Pairing Mode: Press Once

Reset: Press for 8s

Audio Switching between Speaker & Phone Dialing: Press Once

Play/Pause: Press Once

Activate Voice Assistant: Double Press

Answer/End a Call: Press Once

Reject a Call: Press for 2s

Turn down Volume: Press Once

Previous Song: Press for 2s

Turn up Volume: Press Once

Next Song: Press for 2s

Switch Music Playing Modes: Press once to switch among Bluetooth, USB Flash Disk, TF Card & Aux-in Modes.

Bluetooth Connection

Click 'Tronsmart Mirtune S100' to Connect.



Tronsmart

SHENZHEN GEEKBUY E-COMMERCE CO., LTD.
Warehouse 101H, No. 49 South Wuhe Avenue, Wuhe Community,
Bantian Street, Longgang District, Shenzhen
Email: support@tronsmart.com
800-270-1082 (USA & Canada)
+86-755-23603740 (Global)

FCC ID: 2AV3Z-MIRTUNES100

FC CE RoHS NOM NYCE

www.tronsmart.com Made in China

How to Enter/Exit Stereo Pairing

1. Turn on two speakers and make sure they haven't connected with any device.
2. Press 'Bluetooth button' for 3s on either speaker(Host Speaker) to enter stereo pairing mode. The bluetooth indicator of host speaker will flash.
3. If paired successfully, the bluetooth indicator of host speakers will flash while the vice one will stay blue.
4. Search & click 'Tronsmart Mirtune S100' to connect. The bluetooth indicator of host speakers will stay blue while the vice one will off.
5. Press 'Bluetooth button' once on either speaker to exit stereo pairing mode.

Dual Audio Modes

1. Search & click 'Tronsmart Mirtune S100' to connect with device A.
2. Disconnect 'Tronsmart Mirtune S100' from the device A(Note that do not clear the pairing record on the device).
3. Tronsmart Mirtune S100 will re-enter pairing mode.
4. Search & click 'Tronsmart Mirtune S100' to connect with the device B.
5. Click 'Tronsmart Mirtune S100' on device A to connect.



Tronsmart App

Download 'Tronsmart App' via Google Play or App Store.

Available on the App Store | ANDROID APP ON Google play

Apple & the Apple logo are trademarks of Apple Inc.

Google Play & the Google Play logo are trademarks of Google Inc.

How to Connect Tronsmart App?

1. Turn on Bluetooth setting on your device, search & click 'Tronsmart Mirtune S100' to connect.
2. Open 'Tronsmart' App & allow to access Bluetooth on your device.
3. Slide to find out 'Mirtune S100' & click to connect.
4. If connected successfully, you could customize Equalizers, lights, etc.



尺寸：95.46x135mm
128g铜版纸、手风琴样式、总页数24页

产品型号	Mirtune S100	工明	设计师	LFS
尺寸明	参文档标注	正面四色印刷、背面黑白印刷,过哑膜 🟪 潘通色号：Violet C 🟧 潘通色号：165C	审核	YUAN
日期/版次			SCALE	1:1
20240605 V1.0 初稿 20240619 V1.1 二稿 20240708 V1.2 修改参数			Unit	mm
		备注		Tronsmart