


Tronsmart 20250307 - T8 Mini - 说明书 - V1.2



Tronsmart
T8 Mini
Portable Outdoor Speaker

USER MANUAL

English


Thank you for purchasing the Tronsmart T8 Mini Portable Outdoor Speaker. Please read the user manual before use and keep it handy for future reference. If you have any additional questions or comments, please contact us by email at: support@tronsmart.com.

Package Contents

- 1 x T8 Mini Portable Outdoor Speaker
- 1 x Type-C Charging Cable
- 1 x Warranty Card
- 1 x User Manual

Button Configuration

- ① Power On/Power Off: Power Indicator; Charging Indicator
- ② Volume +/Next Track
- ③ Play/Pause
- ④ Volume -/Previous Track
- ⑤ Bluetooth Button/Bluetooth Indicator
- ⑥ Aux-in Port
- ⑦ TF Card Slot
- ⑧ Type-C Charging Port



01


Specifications

Model	D3010
Color	Black/Blue/Gray/Red
Bluetooth Version	5.3
Bluetooth Profile	HSP / HFP / A2DP / AVRCP
Audio Codec	SBC
Bluetooth Range	Over 15m(49ft) (Open Area)
IP Rating	IPX7
Output Power	15W
Input Power	5V/1A, via Type-C port
Frequency Range	20Hz ~ 20KHz
Battery	3.6V/2600mAh
Playtime(Varied by Volume Level & Audio Content)	LED Off: Up to 18 hours(50% Volume)
Charging Time	3 hours
Frequency Band	2400-2480MHz
Maximum Transmission Power	40dBm

02

How to Use

1. Turn On/Off




On: Press for 2s
Off: Press for 2s

Power indicator stays white
Indicator off

2. Connection


Search & click "Tronsmart T8 Mini" to connect.



Pairing: Bluetooth indicator flashes blue
Connected: Bluetooth indicator stays blue

3. Disconnect from device

Quickly connect to another device, you could press the "Bluetooth" button once to disconnect from device.




× 1

03


4. True Wireless Stereo Mode

Connect 2 Tronsmart T8 Mini speakers to enjoy powerful stereo sound.

1) Turn on both speakers. Please make sure either speaker has entered pairing mode.




2) Press "Bluetooth" Button for 3s of either speaker(Host Speaker) to enter stereo pairing mode.(Press once to exit)



3) If paired successfully, the host speaker will flash blue while vice one will stay blue.

Host Speaker	Bluetooth indicator flashes blue
Vice Speaker	Bluetooth indicator stays blue

4) Search & click "Tronsmart T8 Mini" to connect.



04

Host Speaker	Bluetooth indicator stays blue
Vice Speaker	Bluetooth indicator off

5. Aux-in Mode

Simply connect the speaker with your wired device via the 3.5 mm audio jack cable.(Not included).

Note: After plugging in an audio cable, the speaker will automatically switch to Aux-in mode.

6. TF/Micro SD Card Slot Mode

The speaker will play the music from your TF/Micro SD card when plugging the card into the slot.

7. Dual Audio Modes

a. Search & click "Tronsmart T8 Mini" to connect with device A.
b. Disconnect "Tronsmart T8 Mini" from the device A.(Note that do not clear the pairing record on the device).
c. Tronsmart T8 Mini will re-enter pairing mode.
d. Search & click "Tronsmart T8 Mini" to connect with the device B.
e. Click "Tronsmart T8 Mini" on device A to connect.

8. Tronsmart App

Download "Tronsmart App" via Google Play or App Store.

Download on the App Store
GET IT ON Google Play

Apple & the Apple logo are trademarks of Apple Inc.
Google Play & the Google Play logo are trademarks of Google Inc.

How to Connect "Tronsmart App"

1. Turn on Bluetooth setting on your device, search & click "Tronsmart T8 Mini" to connect.
2. Open "Tronsmart App" & allow to access Bluetooth on your device.
3. Click to find out "T8 Mini" & click to connect.
4. If connected successfully, you could customize Equalizers, lights, etc.

05

9. Indicator

Power indicator flashes red	Battery Low
Power indicator stays red	Charging
Power indicator off	Fully-charged

10. Auto Power Off

The speaker will power off automatically after 30 minutes if it does not pair with any device. When in low battery, the speaker will power off automatically as well.

Care & Maintenance

- Do not use any form of detergents or cleaning material to clean the product as any type of chemical may make this device unusable.
- Do not disassemble this product. It contains no user-serviceable parts.
- Do not drop or jump on it and treat it with care for the best performance.
- Keep the product in a dry location. Dust, dirt & moisture from humidity can accumulate on the body of the product if kept at an uncleanly place.
- Do not dispose this product in fire or batteries may explode or leak.

Warranty Information

Your "Tronsmart T8 Mini Portable Outdoor Speaker", is warranted to the original owner for 12 months from the date of purchase against defects in material and workmanship under normal use and service. Tronsmart is not responsible for the accidental use of this product and its liability will not exceed the purchase price of the product. If you have any problems while using the product, please do not hesitate to contact our customer support team at support@tronsmart.com.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

06

Tronsmart

Herby, Shenzhen Geekbuy E-Commerce Co.,Ltd. declares that the radio equipment type Portable Outdoor Speaker Q3010 is in compliance with Directive 2014/53/EU. The full text of the EU/UK declaration of conformity is available at the following internet address: https://www.mediafire.com/folder/7ev67v85zrc2/Declaration_of_Conformity/Q3010-DE

Hermit erklärt Shenzhen Geekbuy E-Commerce Co.,Ltd. dass der Funkgerättyp Tragbarer Outdoor-Lautsprecher Q3010 der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU/UK-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: https://www.mediafire.com/folder/46yn09nczw0r/Dclaration_of_Conformity/Q3010-DE

SHENZHEN GEEKBUY E-COMMERCE CO., LTD.
Warehouse 101H, No. 49 South Wuhe Avenue, Wuhe Community,
Bantian Street, Longgang District, Shenzhen, China
Email: support@tronsmart.com
800-270-1082 (USA & Canada)
+86-755-23603740 (Global)

CE EAC
www.tronsmart.com FCC ID: 2AV32-Q3010 Made in China

07

产品型号	T8 Mini	工明 尺寸：800x110mm 80g双胶纸+单黑正反印刷+手风琴		设计师	LFS
尺寸明	参文档标注			审核	YUAN
日期/版次				SCALE	1:1
20250224 V1.0 初稿 20250306 V1.1 二稿 20250307 V1.2 三稿				Unit	mm
		备注			

潘通色号：Viole

潘通色号：165C