

Instructions of Remote Control



1. Please pull out the insulation tape from the remote control, before starting to use it.
2. Press the button to select functions. The functions are :

ON : turn on the lights

OFF : turn off the lights

STEADY WW : steady warm white

STEADY MLT : steady multicolor

SLOW FADE W/M : slow fading warm white & multicolor

FAST FADE W/M : fast fading warm white & multicolor

FADE WW : fading warm white

FADE MLT : fading multicolor

SPARKLE WW : twinkle / flash warm white

SPARKLE MLT : twinkle / flash multicolor

DEMO: all functions cycle

Instructions of foot pedal switch control



Press **RUSH** button , select lighting functions below cycle.

Function 1: steady warm white

Function 2: steady multicolor

Function 3: slow fading warm white & multicolor

Function 4: fast fading warm white & multicolor

Function 5: fading warm white

Function 6: fading multicolor off

Function 7: twinkle / flash warm white

Function 8: twinkle / flash multicolor

Function 9: all functions cycle

Function 10: off

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.