

Pin No	Note	Pin No	Note
A1	CAN Low	B1	Rear R+ or Subwoofer +
A2	CAN High	B2	Rear R- or Subwoofer -
A3	Telephone mute low	B3	Front R+
A4	Ignition	B4	Front R-
A5	Antenna Remote	B5	Front L+
A6	Illumination	B6	Front L-
A7	Battery+	B7	Rear L+ or Subwoofer +
A8	Power Ground	B8	Rear L- or Subwoofer -
C1	Rear Aux 2 input Left	C11	SUB Preout GND
C2	Rear Aux 2 input Right	C12	NC
C3	Rear Aux 2 input GND	C13	Line out 1L or Left Front
C4	Internal Can resistance ON/OFF	C14	Line out 1 R or Right Front
C5	NC	C15	Line out 1 Ground
C6	NC	C16	NC
C7	MIC-	C17	NC
C8	SUB Preout Left	C18	SWRC GND
C9	SUB Preout Right	C19	SWRC + PMW
C10	MIC+	C20	SWRC + Resistance