

Mini PC

User Manual

⚠ WARNING

- **UK** Protect the mini pc from being exposed to water or moisture.
- **DE** Schützen Sie den Mini-PC vor Wasser und Feuchtigkeit.
- **FR** Protégez le mini PC de l'exposition à l'eau ou à l'humidité.
- **IT** Proteggere il mini PC dall'esposizione ad acqua o umidità.
- **ES** Proteja la mini PC de la exposición al agua o la humedad.
- **NL** Bescherm de mini-pc tegen blootstelling aan water of vocht.
- **BE** Bescherm de mini-pc tegen blootstelling aan water of vocht.
- **TR** Mini bilgisayarı suya veya neme maruz kalmaktan koruyun.
- **SE** Skydda minidatorn från att utsättas för vatten eller fukt.



⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



CR2032 Battery Safety Warning:

a) Safe Handling: According to local regulations, depleted CR2032 batteries should be immediately removed and recycled or disposed of, and kept away from children. Do not discard the batteries in household waste or incinerate them.

b) Risk of Injury: Even depleted CR2032 batteries can cause serious injury or even death if mishandled.

c) Emergency Assistance: If accidental ingestion or any other emergency situation occurs, please call your local medical control center immediately for necessary treatment information.

d) Battery Type: This product is only compatible with CR2032 type batteries.

e) Voltage Information: The nominal voltage of a CR2032 battery is 3 volts.

f) Charging Warning: CR2032 batteries are not rechargeable.

g) Prohibited Actions: Do not forcibly discharge, recharge, disassemble, heat above the manufacturer's specified maximum temperature (usually 60°C), or incinerate. Improper handling may lead to battery venting, leakage, or explosion, causing personal injury and chemical burns.

Battery Statement:

This product contains a non-replaceable CR2032 button cell battery.
In accordance with local regulations, we remind consumers of the following:

The CR2032 battery inside this product should be removed by a professional and recycled or properly disposed of at the end of its service life.

Please ensure that the battery is kept out of reach of children and pets to prevent accidental ingestion.

Do not dispose of the battery with household waste or incinerate it.

We are committed to environmental protection and consumer safety.

Thank you for your understanding and cooperation.


User Guide

Dear User: Thank you for using our product. For your safety and benefit, please carefully read this manual and all accompanying materials before using the product!


Disclaimer:

1. Please be sure to use the original power adapter. we assume no responsibility for any issues or malfunctions caused by the use of third-party adapters.
2. Users may use third-party music, video, images, and software, but we are not responsible for any copyright issues or software malfunctions.
3. If the product experiences a malfunction, we will strictly adhere to the warranty terms. However, we are not liable for any property damage or financial losses that may occur during use.
4. The device comes with pre-installed software, which can be used after actual testing. However, removing or not removing such software in cases of compatibility or other issues will not affect the machine. Please note that this is not a product quality issue.
5. We reserve the right to improve the product. In case of any changes in specifications or design, the actual product will prevail.
6. Please do not disassemble the product yourself. we assume no liability for damages caused by external physical or chemical damage unrelated to the product's quality.

Quick Installation



Installation of VESA bracket



Note: Some models do not support VESA mounts. Please refer to the actual product.

Tips and FAQ

1. Turn off your Mini PC

If your Mini PC does not respond, press the power button for at least (4–6) seconds until your Mini PC is turned off.

2. Boot into the system for the first time

- When you start-up your PC for the first time, you will be guided to configure your Windows operating system.

- Start-up your Mini PC for the first time: Press the PC's power button. Wait for a few minutes until the installation interface appears.

Step 1: Select language/country (region)

Step 2: Select the inputting method, and clicks confirm

Step 3: Select the second inputting method, which can be “skipped”

Step 4: Networking: After selecting wifi, enter password to connect it. Or choose to plug network cable for connection. (Networking will be updated automatically, and the update process will stay on an interface for a long time, which prolong the start-up time. (Skipping network connections is strongly recommended)

Step 5: Accept License Agreement

Step 6: Set User Name and Password Once the installation process is complete, the desktop will appear.

3. Connect WiFi

- Connect Wi-Fi. Connect PC to the Wi-Fi network using the following steps.
- Select the/icon  from the taskbar.
- Click the wifi icon to turn on the wi-fi.
- Select an access point in the list of available Wi-Fi connections. Select one of the connections to start the network connection.

Note: You may be prompted to enter a security key to activate a Wi-Fi connection.

4. Enter the BIOS setting

- The BIOS (Basic Input/ Output System) is the first software loaded when the Mini PC starts.
- Enter Bios: Click “Del” or “ESC” key.
- Under normal circumstances, the default BIOS settings apply in most cases to ensure optimum performance. Do not change the default BIOS settings. Except for the following situation. (You have installed new system components that require further BIOS settings or update.)
- Warning! Inappropriate BIOS settings may cause instability or startup failure. We strongly recommend that you can only change the BIOS settings with the help of technical service personnel.

Precautions

1. Be cautious when performing operations that may result in file damage or loss.
 2. During use, ensure the device is protected from viruses and try to use antivirus software. If the mini PC will not be used for a long period, turn it off and disconnect the power supply.
 3. Avoid turning the device on and off frequently within short periods. Ensure a minimum interval of 10 seconds between reboots.
 4. Keep the device away from moisture and maintain a clean environment. If there is dust, use a dry, soft cloth to clean it.
 5. Avoid direct exposure to strong light and keep the device away from strong magnetic fields.
 6. Do not spill liquids such as water or food on the device. Do not pull data or power cables forcefully.
- Operating Environment: -10°C to 45°C, 30% to 85% RH
Storage Environment: -20°C to 60°C, 10% to 90% RH

After-Sales Service

Thank you for choosing our mini PC. If you have any questions or need assistance, please contact our support team via the after-sales email or phone number on the device.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.



P/N:1405000296



Scan to view
CE/UKCA-DOC



Exclusive WhatsApp Customer
Service



MADE IN CHINA