

Model No.: MH22173

BLUETOOTH HEADPHONE

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Product Overview

Earphone x 2 (left & right)

Charging Case

USB-C Charging Cable

Quick Start Guide and Warranty Letter

1. LED Indicator

2. Multi Function Button (MFB)

3. Charging contact point

4. Speaker Areas

5. USB-C Charging Port

6. Charging Indicator

Power On/Off

Open the cover of the charging case, take out the earphone, and it will turn on automatically. Put the earphone into the charging case, close the cover, and the earphone will automatically shut down and charge.

Charging Case Charging

Use the USB-C charging cable delivered with the product to charge, and the charging case indicator shows the charging status. When the charging case is fully charged, the charging case indicator lights up.

Pairing

Open the cover of the charging case, take out the earphone, and it will turn on automatically. Later, you can hear "pairing" as a voice prompt. To connect to a new device, please turn on the Bluetooth of your mobile phone and search for "Monster Open Ear 101" to pairing the device. After successfully connecting, you will hear "connected" voice prompt.

Volume Control

Volume down: Double tap the MFB on the left earphone during music streaming. Volume up: Double tap the MFB on the right earphone during music streaming.

Call

Answer / End a call: Single tap the MFB. Reject the call: Press and hold the MFB for about 2 seconds.

Music

Play/Pause music: Single tap the MFB Previous song: Press and hold the MFB on the left earphone for about 2 seconds. Next song: Press and hold the MFB on the right earphone for about 2 seconds.

Voice Control

With the earphones connected to the phone, press the MFB key three times to activate or disable the voice assistant.

Reset

When the earphones is powered on and not connected to the Bluetooth device, press the MFB button of the left and right earphones five times at the same time to restore factory Settings.

Indicator/Voice Prompt Guide

Mode	Description	Voice Prompt
Power On	White LED light on	"Power On"
Power Off	White LED light off	"Power Off"
Pairing	The white LED light in the main ear blinks quickly, and the white LED light in the secondary ear blinks every 6 seconds	"Pairing"
Connected	White LED light off	"Connected"
Charging case	When charging, the indicator light on the charging case breathe, Keep it lit when it's full	-

Cautions

- * After removing the earphones from the charging case, without pressing any buttons, the left and right earpieces will connect automatically. When no connections found, it will enter automatic pairing mode.
- * Please place the earphones in the correct location (L/R) for normal charging.
- * Replacement of battery (on your own) is not recommended.
- * Do not expose battery (battery pack) to excessive heat such as direct sunlight or fire.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2AVD2-MH22173

Model No.: MH22173

BLUETOOTH HEADPHONE

快速指南

请仔细阅读本快速指南并妥善保存以备将来使用。

产品概述

*耳机x 2 (左&右)

*充电盒

*USB-C充电线

*快速指南与保修单

1. led指示灯

2. 多功能触控键 (MFB)

3. 充电触点

4. 发声位置

5. USB-C充电接口

6. 充电指示灯

电源开/关

打开充电盒盖，取出耳机，它将自动开机。将耳机放入充电盒，把盖合上，耳机会自动关机及进行充电。

充电盒充电

使用产品自带的 USB-C 充电线进行充电，充电盒指示灯显示充电状态。当充电盒充满电时，充电盒指示灯长亮。

配对

打开充电盒盖子，取出耳机，它将自动开机。之后您可以听到“pairing” 的语音提示。对于新设备连接，请打开手机蓝牙并搜索“Monster Open Ear 101”进行配对，连接成功后，你会听到“connected” 语音提示。

音量控制

调低音量：在音乐播放状态下，双击左耳机的触摸式多功能按键。调高音量：在音乐播放状态下，双击右耳机的触摸式多功能按键。

通话

接听/结束通话：单击触摸式多功能按键。拒接来电：按住触摸式多功能按键约2秒钟。

音乐

播放/暂停音乐：单击触摸式多功能按键。上一曲：长按左耳机触摸式多功能按键约2秒。下一曲：长按右耳机触摸式多功能按键约2秒。

语音控制

在耳机与手机连接状态下，连按3下MFB键以激活或关闭语音助手。

恢复出厂设置

在耳机开机且未连接蓝牙设备时，同时在左和右耳机的MFB键连按5次，以恢复出厂设置。

指示灯/语音指南

模式	描述	声音提示
开机	白色LED灯亮	"Power On"
关机	白色LED灯灭	"Power Off"
配对	主耳白色LED灯快闪, 副耳白色LED灯每6秒闪一次	"Pairing"
连接	白色LED灯灭	"Connected"
充电盒充电	充电盒充电时, 充电盒上的指示灯闪烁, 充满后长亮	-

注意

*从充电盒中取出耳机后, 无需按任何按键, 左右耳机会自动连接和自动进入配对模式。

*请将耳机放在正确的位置进行充电。

*不建议未经许可私下更换电池。

*电池[电池组或电池组合]不得暴露在照明, 烘烤或类似过热的环境中。

封面

70X95MM 105G双胶+1专1黑+风琴折