

中文

Model No.: MH22181

BLUETOOTH HEADPHONE
OPEN EAR AC210

快速指南 / Quick Start Guide / クイックスタートガイド
請仔細閱讀本快速指南并妥善保存以備将来使用。
本产品由中国平安保险经纪公司承保
Please read this Quick Start Guide carefully and keep it for future use.
このクイックスタートガイドをもよくお読みの上、将来のために大切に保管してください。

产品概述

*耳机x 2 (左&右)
*充电仓
*USB-C充电线
*快速指南与保修单

1. 耳机多功能触控键 (MFB)
2. 耳机LED指示灯
3. 发声位置
4. 耳机充电触点
5. 充电仓充电触点
6. USB-C充电接口

充电仓充电
使用产品自带的 USB-C 充电线进行充电，充电仓指示灯显示充电状态。当充电仓充满电时，充电仓指示灯长亮。

佩戴

拿出耳机，将**Monster Open Ear AC210** 顺着耳后佩戴，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。

电源开/关

打开充电盒盖，拿出耳机，耳机自动开机。将耳机放入充电盒，耳机自动关机及进行充电。

配对
打开充电盒盖，拿出耳机，耳机会自动开机。对于新设备连接，请打开手机蓝牙并搜索**"Monster Open Ear AC210"**进行配对，连接成功后，你会听到系统语音提示。

音量控制
调低音量：在音乐播放状态下，短按左耳的触摸多功能按键。
调高音量：在音乐播放状态下，短按右耳的触摸多功能按键。(默认1级为静音)

通话
接听/结束通话：双击2下 (左右耳均可操作)。
拒接来电：来电时，长按2秒 (左右耳均可操作)。
取消通话：在拨出电话后对方未接听时，双击可取消通话。

音乐
播放/暂停音乐：双击触摸多功能按键 (左右耳均可操作)。
上一曲：已连接手机状态，左耳轻触3下。
下一曲：已连接手机状态，右耳轻触3下。

单耳操作模式
如果只取出一只耳机佩戴，则自动进入单耳模式。使用状态中，再拿起另一只耳机，则退出单耳模式进入TWS模式。
播放/暂停：已连接手机状态，双击2下；
下一曲：已连接手机状态，轻触3下；
调高音量：短按触摸功能键；

语音控制

在耳机与手机连接状态下，长按2秒唤醒语音助手左右耳均可操作。

恢复出厂设置
耳机在开机状态下时，双耳同时快击5下，左右耳机红灯亮1秒，清空耳机与手机的配对记录后 (不清除左右耳)，进入设备搜索配对模式，如3分钟内没有连接新设备则自动关机。

指示灯/语音指南

模式	描述	声音提示
开机	白灯快闪	系统提示音
关机	红灯长亮2S熄灭	系统提示音
配对	白灯快闪	无
连接	白灯长亮1S熄灭	系统提示音
充电仓充电	充电仓充电时，充电仓上的指示红灯慢闪，充满后红灯长亮	-

注意

*从充电仓中取出耳机后，无需按任何按键，左右耳机会自动连接和自动进入配对模式。
*请将耳机放在正确的位置进行充电。
*不建议未经许可私下更换电池。
*电池[电池组或电池组合]不得暴露在照明，烘烤或类似过热、过冷的环境中。

封面

Product Overview

Earphone x 2 (left & right)
Charging Case
USB-C Charging Cable
Quick Start Guide and Warranty Letter

1. Multi-function touch button (MFB)
2. Earphone LED indicator
3. Vocal position
4. Earphone charging contact
5. Charging contact of charging case
6. USB-C charging port

Charging case charging
Use the USB-C charging cable provided with the product to charge, and the charging case indicator shows the charging status. When the charging case is fully charged, the charging case indicator lights up.

Wear

Take out the earphones and place the **Monster Open Ear AC210** behind your ears and gently rotate it to a comfortable position to ensure the best possible wearing and sound quality experience.

Power on/OFF

Open the cover of the charging case, take out the earphone, and the earphone will turn on automatically. Put the earphone into the charging case, the earphone will turn off and charge automatically.

Pairing
Open the cover of the charging case, take out the earphone, and the earphone will automatically turn on. For a new device connection, please Open your phone's Bluetooth and search for **"Monster Open Ear AC210"** for pairing. After successful connection, you will hear the system voice prompt.

Volume control
Turn down the volume: While the music is playing, short press the touch multi-function button on the left earphone.
Turn up the volume: While the music is playing, short press the touch multi-function button on the right earphone. (Level 1 is silent)

Call
Answer/end call: Double click 2 times (both left and right earphones can be operated).
Reject incoming call: Press and hold for 2 seconds (left and right earphones can be operated).
Cancel call: Double click to cancel call when the other person does not answer the call.

Music

Play/pause music: Double click and touch the multi-function button (left and right earphones can be operated).
Previous song: connected to the mobile phone status, left earphone touch 3 times.
Next song: connected to the mobile phone status, right earphone touch 3 times.
Single-earphone operation mode
If only one earphone is removed and worn, the single-earphone mode is automatically entered. If you pick up another earphone while in use, you will exit single-earphone mode and enter TWS mode.
Play/pause: Connected phone state, double click 2 times;
Next song: Connected mobile phone state, touch 3 times;
Turn up the volume: Short press the touch function button;

Voice control
When the earphone is connected to the mobile phone, long press for 2 seconds to wake up the voice assistant.

Factory reset

When the earphone is turned on, click 5 times in both earphones at the same time, and the red light of the left and right earphones will turn on for 1 second. After clearing the pairing record between the earphone and the phone (without clearing the left and right earphones), the device will enter the search and pairing mode. If no new device is connected within 3 minutes, the earphones will automatically turn off.

Indicator light/voice guide

Mode	Description	Voice Prompt
Power On	White light flashes quickly	System tone
Power Off	Red light is on for 2 seconds	System tone
Pairing	White light flashes quickly	-
Connected	White indicator is on for 1S and off	System tone
Charging case	Charging case When charging, the instructions on the charging case The red light blinks slowly. The red light blinks long after it is full	-

Note

* After removing the earphones from the charging case, the left and right earphones will automatically connect and connect without pressing any buttons
Enter pairing mode automatically.
* Please place the earphone in the correct position for charging.
* It is not recommended to replace the battery privately without permission.
* The battery [battery pack or battery combination] shall not be exposed to lighting, baking or similar overheating or undercooling in the environment.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2AVD2-MH22181

製品概要です

*イヤホンx 2(左&右)です。
*充電タンクです
*usb-c充電ケーブルです。
*クイックガイドと保証書です

1. イヤホンのマルチファンクションタッチキー (MFB) です
2. ヘッドフォンLEDインジケータ
3. 発声位置です
4. イヤホン充電接点です
5. 充電ケース充電接点です
6. usb-c充電ポートです

充電ケース充電です
製品に内蔵されたusb-c充電ケーブルで充電を行うと、充電ケースのランプが充電状態を表示します。充電ケースが満充電になると、充電ケースのランプが点灯します。

着用します

イヤホンを取り出し、**Monster Open Ear AC210**を耳の後ろに装着し、快適な位置まで軽く回転させることで、最適な装着効果と音質体験が得られます。

電源オン/オフ

充電ケースの蓋を開けてイヤホンを取り出すと、自動的に電源が入ります。イヤホンを充電ケースに入れたと、自動的に電源が切れて充電が始まります。

ペアリングです
充電ケースの蓋を開けてイヤホンを取り出すと、自動的に電源が入ります。新しいデバイスに接続するには、bluetoothをオンにして「**Monster Open Ear AC210**」を検索してペアリングしてください。接続に成功すると、システムの音声メッセージが届きます。

ボリュームコントロールです
ボリュームを下げる:音楽を再生している状態で、左耳のタッチファンクションボタンを短く押します。
ボリュームを上げる:音楽を再生している状態で、右耳のタッチファンクションボタンを短く押します。(レベル1は静音です)

通話します
通話の受話/終了:ダブルクリック2回(左右の耳で操作可能)です。着信拒否:着信時、2秒間長押しします(左右の耳で操作可能)。通話のキャンセル:電話をかけても相手が出ない場合、ダブルクリックで通話をキャンセルすることができます。

音楽です
音楽の再生/一時停止:マルチファンクションボタンをダブルクリック(左右の耳で操作可能)します。
下一曲:左耳に3回触れます。
上一曲:携帯電話に接続した状態で、右耳に軽く3回触れます。

片耳モードです

イヤホンを片方だけ取り出して装着すると、自動的に片耳モードになります。使用状態でもう片方のイヤホンを持ち上げると片耳モードから抜けてTWSモードになります。
再生/一時停止:すでに携帯電話の状態に接続して、2下をダブルクリックします;
上一曲:私はあなたを愛します
音量を上げます:機能キーをタッチすることを短く押します;
音声制御です
イヤホンとスマートフォンを接続した状態で、2秒長押しして音声アシスタントを起動させることができます。

工場出荷時の設定に戻ります
イヤホンの電源をオンにした状態で、両耳で同時に5回早くクリックし、左右のイヤホンに赤いランプを1秒点灯させます。イヤホンと携帯電話のペアリング記録をクリアした後(左右の耳をクリアしないで)、機器検索ペアリングモードに入ります。3分以内に新しい機器を接続しなければ、機器の電源がオフになります。

インジケータライト/音声ガイド

モード	形容	可聴キュー
ブート	フラッシュライトです	システムトーン
シャットダウン	赤ランプ長く点灯2S消灯します	システムトーン
ペアリング	フラッシュライトです	
繋ぐ	白灯長亮1S消灯します	
充電ケースの充電	充電ケースでの充電の指示です赤いランプはゆっくり点滅し、赤いランプは満タンになります	-

注意します
*充電ケースからイヤホンを取り出すと、ボタンを押すことなく左右のイヤホンが自動的に繋がります。
自動的にペアリングモードになります。
*イヤホンは正しい位置で充電します。
*許可なく電池を交換することはお勧めできません。
*バッテリー[バッテリーパックまたはバッテリーセット]は、照明にさらされてはいけません。
環境の中にいます

70x95mm
100G双胶
专色+黑色印刷 骑马钉