

Model No.: MH 22203

TH300

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Product Overview

Open earphones x2 (L & R)

Charging case x1

USB-C cable x1

Quick start guide and warranty card

Eartips x 3 Pairs
(The M size is installed on the earphones)

Charging

Before using the "Monster TH300", please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.

USB-C Port

Power On/Off

When open the charging case, the earphones will power on automatically. If you want to turn off the earphones, please put the earphones into the charging case and close the cover, the earphones will power off and charge at the same time.

Pairing

When open the charging case, the earphones will power on automatically.

For new device connection, turn on the Bluetooth in your device and choose "Monster TH300" from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device. If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

Wearing

Put the "Monster TH300" onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.

MFB Operation

Reset

In the power on state, touch the MFB of earphones 5 times (two earphones at the same time), and the earphones will automatically shut down and restore the factory settings.

Smart Charging Case Operation

• After the screen is turned off without operation, double-click the screen to light up;
• Short press the MFB button of the charging compartment for 1 time to turn on the screensaver or turn off the screen.
• Open and close the charging cover, you can turn on the screen or turn off the screen

Smart Charging Case function display

Additional Operation

Answer call	Press L or R twice
End call	Press L or R twice
Reject call	Press MFB 3seconds
Pairing is successful	The white light on ls and then turn off
Pairing timed out	The red light on 2s and then turn off
Charging	Red flashes
Fully charged	Red off
Low battery	Red flashes
LED screen (charging case)	
Power on/off	In the power-off state, press and hold the MFB to power on In the power-on state, press and hold the MFB to pop up the shutdown or restart interface, slide left and right to select a language and select Start accordingly (If you cancel, you will return), and the L/R earphone will sound accordingly.
Charging	A white lightning bolt symbol is displayed when the screen is locked When the screen is unlocked, the menu bar displays the percentage of battery in real time
Low battery	When the screen is unlocked, the menu bar displays the charging case in real time, Percentage battery and the icon turns red and flashes slowly

Music playback	Play/Pause: Tap the play icon Next song: Tap the right icon Previous song: Tap the left icon
Volume adjustment	Volume up: Tap the right icon Volume down: Tap the left icon
Ambient sound	Tap the icon to select a ambient sound mode, From left to right: Normal/Noise Reduction/Transparent
Equalizer	Tap the left/right icon to select EQ sounds
Light level	Tap the left/right icon to select screen brightness
Language switch	Tap the left/right icon to select a language
Find my earphone	Tap the left/right ear icon and select Start accordingly (If you cancel, you will return), and the L/R earphone will sound accordingly.
	Tap the stop button to disappear and go back
Time setting	When connected to a mobile phone, the network time is automatically calibrated

Bluetooth to take pictures

When your phone turns on the camera, tap the on-screen camera icon to start the remote photo taking feature on your phone

Answer an incoming call

When the earphones remains connected outside the charging case, tap the storage screen Answer icon

Hang up

When the earphones remains connected outside the charging case, tap the storage screen Hang up icon

Reject an incoming call

When the earphones remains connected outside the charging case, tap the storage screen Hang up icon

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. FCC ID: 2AVD2-MH22203

IC CAUTION

Radio Standards Specification RSS-Gen, issue 5
- English:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device must not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.
RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
- French:
Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.
Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.
IC: 2B087-MH22203

Model No.: MH 22203

TH300

快速指南

请仔细阅读本快速指南并妥善保存以备将来使用。
本产品由中国平安保险公司承保

产品概述

耳机x2 (左&右耳)

充电盒x1

USB-C充电线 x1

快速指南/保修卡

耳套 x3 对 (M号已安装在耳机上)

充电

请在使用此设备前先将耳机和充电盒充满电，此设备可以通过USB-C接口进行充电。

USB-C 接口处

电源开、关

打开充电盒盖，耳机将自动开机。如果想要关闭耳机，请将耳机放入充电盒并关盖，耳机会关机同时进行充电。

配对

打开充电盒，耳机会自动开机。对于新设备连接，请打开蓝牙设备并搜索 "Monster TH300" 进行连接，配对成功后，您会听到系统提示音。如果耳机之前已配对过，开机就会尝试连接上一次的设备。

佩戴

拿出耳机，将 "Monster TH300" 戴在耳朵上，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。

按键操作

恢复出厂设置

开机状态下连续5击耳机触控键（双耳同时），耳机将自动关机，恢复出厂设置。

智能仓操作

• 无操作息屏后，双击屏幕点亮；
• 短按1下充电仓MFB键也可以点亮屏保或熄屏。
• 开合充电盒盖，也可以点亮屏或熄屏

左右滑动可进入功能主界面

智能仓功能展示

更多操作

接听	双击左或右耳
挂断	双击左或右耳
拒接	长按MFB3秒
LED 指示灯 (耳机)	
配对成功	白灯长亮1S熄灭
配对超时	红灯长亮2S熄灭
充电中	红灯慢闪
充满	红灯熄灭
电量低	红灯慢闪
LED 屏 (充电盒)	
开、关机	在关机状态，长按MFB键开机 在开机状态，长按MFB键弹出关机或重启界面，左右滑动则回到主界面
充电	锁屏时显示白色闪电符号 屏幕解锁时菜单栏实时显示百分比电量
低电提醒	屏幕解锁时菜单栏实时显示充电仓百分比电量，同时图标变红色慢闪
音乐播放	播放/暂停：轻点播放图标 下一曲：轻点右侧切歌图标 上一曲：轻点左侧切歌图标
音量调节	加音量：轻点右侧小喇叭图标 减音量：轻点左侧小喇叭图标

环境音	分别轻点对应文字图标选择环境音模式。
均衡器	从左往右依次是：正常、降噪、通透
屏幕亮度	轻点左/右三角标单向选择屏幕亮度
语言切换	轻点左/右三角标单向选择语言
找耳机	轻点左/右耳图标，对应选择“开始”（取消则返回），L/R耳机对应发出提示音，点击停止键声音消失并返回
时间设置	与手机连接时，自动校准网络时间
蓝牙拍照	手机打开相机时，轻点屏幕相机小图标
	启动手机远程拍照功能
接听来电	耳机在仓外保持连接时，轻点仓屏的接听图标
挂断电话	耳机在仓外保持连接时，轻点仓屏的挂断图标
拒接来电	耳机在仓外保持连接时，轻点仓屏的挂断图标

注意

•不建议未经许可私下更换电池。
•电池(电池组或电池组合)不得暴露于照明，烘烤或类似过热的环境中。
•耳机充电仓在外接电源充电时，输入电压电流标准≤ 5V/1A；

封面

75X95MM 105G双胶+4C印刷+风琴折