

Model No.: MH22224

OPEN EAR AC336

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Product Overview

Charging

Before using the "Monster Open Ear AC336", please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.

USB-C Port

Power On/Off

Open the charging case cover and remove the earphones, which will automatically turn on. Put the earphones into the charging case, close the cover, and the earphones will automatically turn off and charge at the same time.

Pairing

The earphones will turn on when taken out of the charging case. For new device connection, turn on the Bluetooth in your device and choose "Monster Open Ear AC336" from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device. If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

Wearing

Put the "Monster Open Ear AC336" onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.

MFB Operation

Reset

In the power on state, touch the MFB of the earphones 5 times (two earphones at the same time), and the earphones will automatically shut down to reset. Put the earphones in the charging case and then take them out, the earphones will turn on automatically, and enter the pairing mode.

Additional Operation

Answer call	Press L or R twice
End call	Press L or R twice
Reject call	Press MFB on the left or right earphone for 2 seconds

LED indicator (earphone)

Power on	White flashes
Power off	The red light on 2s and then turn off
Pairing is successful	The white light on 1s and then turn off
Pairing timed out	The red light on 2s and then turn off
Connection is over distance	White flashes
Disconnect the phone	White flashes
Low battery	Red light flashes slowly
Low power off	The red light on 2s and then turn off

LED indicator (charging case)

Charging	The red light continues to flash slowly, and the red light is full and on
Discharge	When the charging case charges the earphones, the white light stays on and turns off when it is full
Low battery	When the earphones in the charging case, the white light flash

Attention

*Private replacement of batteries without permission is not recommended.
*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.
*The input voltage and current standard 5V/0.5A when charging the headset charging compartment from an external power source;

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received. Including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
FCC ID: 2AVD2-MH22224

Model No.: MH22224

OPEN EAR AC336

快速指南

请仔细阅读本快速指南并妥善保存以备将来使用。
本产品由中国平安保险公司承保

产品概述

充电

请在使用此设备前先给耳机和充电仓充满电，此设备可以通过USB-C接口进行充电。

USB-C 接口处

电源开、关

打开充电盒盖，取出耳机将自动开机。将耳机放入充电盒，把盖合上，耳机会自动关机同时进行充电。

配对

拿出两只耳机，它将自动开机。对于新设备连接，请打开蓝牙设备并搜索 "Monster Open Ear AC336" 进行连接，配对成功后，您会听到系统提示音。如果耳机之前已配对过，开机就会尝试连接上一次的设备。

佩戴

拿出耳机，将 "Monster Open Ear AC336" 顺着耳后佩戴，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。

按键操作

恢复出厂设置

开机状态下连续5击耳机触控键（双耳同时），耳机将自动关机，恢复出厂设置。耳机放入充电盒合盖充电，耳机再取出重新开机，进入配对模式。

更多操作

接听	双击左或右耳
挂断	双击左或右耳
拒接	长按左或右耳MFB键2秒

LED 指示灯（耳机）

开机	白灯快闪
关机	红灯长亮2S熄灭
配对成功	白灯长亮1S熄灭
配对超时	红灯长亮2S熄灭
连接超距	白灯快闪
断开手机连接	白灯快闪
低电提醒	红灯慢闪
低电关机	红灯长亮2S熄灭

LED 指示灯（充电盒）

充电	红灯持续慢闪，充满红灯长亮
放电	仓给耳机充电时白灯长亮，充满熄灭
低电提醒	耳机在仓内，白灯闪烁

注意

*不建议未经许可私下更换电池。
*电池[电池组或电池组合]不得暴露在照明，烘烤或类似过热的环境中。
*耳机充电仓在外接电源充电时，输入电压电流标准 5V/0.5A

封面

75X95MM 105G双胶+4C+186C印刷+风琴折