

105g双胶186C+K 风琴折
双色印刷 75x95mm 英文

正

反

Model: MS62110

S160

PORTABLE BLUETOOTH SPEAKER

Quick Start Guide

Please read this Quick Start Guide carefully and keep it for future use

Product Overview

1. Mode switch
Short press: mode switching
Long press: 3 seconds to clear the paired device records

2. Light mode switch
Short press:Light mode switching
Long press:Turn on/off the light

3.Number button
Short press the number/number combination button to switch songs
Short press: Play/pause/answer a call / end the call
Long press:Reject a call

5.Power On/Off
Long press: Power on/off

6.Recording
Short press: Enter recording mode
Long press: Enter/exit recording playback

7.Delete
Short press:Delete the currently playing recording file

8.Display screen

9.Volume down/Previous song
Short press:Volume down
Long press: Previous song

10.Volume up/Next song
Short press: Volume up
Long press: Next song

11.Charging Indicator
Charging in progress, the charging indicator light stays on
After fully charged, the charging indicator light off

12.USB-C Charging

13.USB (Audio) Input
Connect a USB storage device

14.Micro SD card Input
Connect a Micro SD card mode storage device

115.AUX Input
External audio devices can be connected using audio cables

16.Headphone input

BLUE	Bluetooth mode	TF	Micro SD card Input	FM	FM mode
LINE	AUX Input	USB	USB (Audio) Input		

Charging status: The indicator flashes while charging, stays solid when fully charged, and turns off when the charging cable is unplugged

Low battery indication: The indicator stays solid when powered on and flashes when the battery is low

Power/Charging

For better enjoyment, fully charge the speaker before use.
A USB-C charging cable (charge only) is included for standard USB compatible device.
Please use a 5V/1A or above power adapter (not included).
Caution: - Other incompatible charges may cause damages.
- Do not use if the connector or device is wet or damaged.

Power On/Off

To turn on the speaker, press and hold the power on/off Button for 2 seconds, you will hear a power on tone.
To turn off the speaker, press and hold the power on/off Button for 2 seconds, you will hear a power off tone.
Caution: If no Bluetooth device is connected, the speaker will turn off in 15 minutes.

Bluetooth Connection

- When first used and turned on, the speaker will automatically enter a waiting mode for connection.
- The speaker will automatically enter pairing mode if it is not connected to a Bluetooth device.

When connecting, enable the Bluetooth function of the mobile phone, search for **"Monster S160"** and connect. After the connection is successful, you will hear a voice prompt, "BLUE" characters go from flashing to long bright.

Music Control

Short press "▷" music can be played or paused.
Long press "◀" to go to the previous song.
Long press "▶" to go to the next song.
Fast song selection: Press 0-9 number/number combination button to directly enter the song serial number (this function only supports USB, Micro SD card valid), you can play the song.

Call Mode

Answer a call: Short press the "▷" button.
End the call: Short press the "▷" button.
Reject a call: Long press the "▷" button.

Volume Control

Short press the "◀" button to turn down the volume.
Short press the "▶" button to turn up the volume.

USB IN (Audio) Playback

When speaker is on and USB drive is inserted, USB IN (Audio) is the priority playback source. If you want to use Bluetooth function, press the "≡" button to switch the source.

Micro SD Card Playback

When speaker is on and micro SD card (not included) is inserted, micro SD card is the priority playback source. If you want to use Bluetooth function, press the "≡" button to switch the source.

AUX IN Playback

When speaker is on and audio source is inserted via AUX IN (not included), AUX IN is the priority playback source. If you want to use Bluetooth function, press the "≡" button to switch the source.

FM Playback

When speaker is on and press the "≡" button to switch the FM mode. If you want to use Bluetooth function, press the "≡" button to switch the source.In FM playback mode, Press and hold "▷" for 2 seconds to automatically search for channels,short press the "◀" key to play the previous radio station that has already been searched, and short press the "▶" key to play the next radio station that has already been searched.

Recording

When a micro SD card or USB drive is inserted, pressing the "📁" button in any mode will start recording. Press the "📁" button again to stop recording and automatically play back the current recording. Pressing any key during playback will exit the recording playback mode.

Playback of Recordings

In USB or micro SD card playback mode, press and hold the "📁" button for 2 seconds to play recorded files in sequence (a USB drive or micro SD card must contain recording files, otherwise recording playback cannot be accessed). Press and hold the "📁" button again for 2 seconds to exit recording playback.

Press and hold the "◀" button for 2 seconds to play the previous recording.
Press and hold the "▶" button for 2 seconds to play the next recording.

Delete

When in recording playback mode, press the "📁" button to delete the current recording.

Power Saving Settings

- In Bluetooth mode, when no device is connected, the speaker will be switched off automatically in 15 minutes.
- Micro SD card mode/USB IN (Audio) mode/FM mode, no music playback for 15 minutes, the speaker will be switched off automatically.
- In AUX IN mode, the music that is not being played will not automatically shut off after 15 minutes.

Reset Device

If the speaker needs to be reset, press and hold the "▷" button for 8 seconds.

Caution

- It is not recommended to replace the battery privately.
- The battery (battery pack or battery pack combination) must not be exposed to sunshine, fire or similar overheated environments.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

For service, warranty, or product information,
Please contact: support@mct-audio.com with your order ID.

FCC ID: 2AVD2-MS62110

IC Caution

Radio Standards Specification RSS-Gen, issue 5
- English:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:
Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.
IC: 28087-MS62110