

105g双胶186C+K 风琴折
双色印刷 75x95mm

正

Model: MS62144

M23
便携式扩音器

快速指南

请仔细阅读本快速指南并妥善保管以备将来使用

本产品由中国平安网络公司承保

产品概述

1.多功能旋钮

2.录音

短按:进入录音模式

长按:删除当前播放的录音文件

3.上一曲

4.播放/暂停

短按:上一首歌

双击:断开/回连蓝牙

长按5秒可清除所有已配对的设备记录

5.下一曲

短按:下一首歌

6.模式切换

短按:模式切换

7.MIC输入接口

连接到有线话筒

8.USB (Audio)输入接口

连接USB存储设备

9.USB-C充电接口

或以上适配器(不包含)进行充电

10.指示灯

连接 TF CARD 存储设备

11.TF CARD输入接口

连接 TF CARD 存储设备

12.充电指示灯

LED 指示灯 / 提示音指南

	描述	提示音	状态
指示灯	白色指示灯闪烁	开机提示音	开机
	所有灯熄灭	关机提示音	关机
指示灯	白色指示灯闪烁	-	未连接
	白色指示灯长亮	连接成功提示音	已连接
低电提示	红色指示灯闪烁	低电提示音	-
	充电器 充电	充满电, 红色指示灯熄灭	-

开机/关机

在关机模式下, 顺时针转动旋钮开启扩音器, 可听到开机提示音。
关闭扩音器, 逆时针转动旋钮关机, 可听到关机提示音。

蓝牙配对

- 首次使用并开机时, 扩音器将自动进入配对模式。
- 如已连上蓝牙设备, 双击“”键, 即可断开当前连接, 以便与其它设备进行配对。
- 如没有连上蓝牙设备, 扩音器也会自动进入配对模式。

连接时, 启用手机的蓝牙功能, 搜索“**Monster M23**”进行连接, 连接成功后你会听到提示音, 白色指示灯由闪烁变成长亮。

音乐控制

短按“”键, 可播放或暂停音乐。
短按“”键, 可播放上一首歌。
短按“”键, 可播放下一首歌。

音量控制

逆时针旋转旋钮调低音量。
顺时针旋转旋钮调高音量。

USB IN (Audio) 模式播放

开机时, USB IN (Audio) 插入扩音器后, 会以USB IN (Audio) 为优先播放, 届时如需用蓝牙播放时, 短按“**M**”键来切换音源。

TF CARD模式播放

开机时,TF CARD (不包含) 插入扩音器后, 会以TF CARD 为优先播放, 届时如需用蓝牙播放时, 短按“**M**”键来切换音源。

录音

在有TF卡或者U盘插入时, 短按“”键, 扩音器开始录音, 再次短按“”键退出录音, 并自动播放当前录音 (新录入的文件排序最优先, 且会重复播放新录入的录音文件), 短按任意键将退出录音播放。

录音回放

在U盘或TF卡播放模式下, 双击“”键进入录音回放功能, 依次播放已存录音文件;短按“”键播放上一个录音,短按“”键播放下一个录音;再次双击“”键, 退出录音回放。

删除录音

在进入录音回放后, 播放当前录音时, 长按2秒“”键可删除当前录音。

恢复出厂设置

在开机状态下, 同时长按“”和“”键5秒, 即可恢复出厂设置。

注意

- 不建议未经许可私下更换电池。
- 电池[电池组或电池组合]不得暴露在诸如日照、火烤或类似过热环境中。

产品有毒有害物质或元素表

本表格依据SJ/T11364-2014的规定来编制

部件名称	有害物质					
	六价铬 (Cr(VI))	多溴联苯 (PBBs)	多溴二苯醚 (PBDEs)	镉 (Cd)	汞 (Hg)	铅 (Pb)
外壳	○	○	○	○	○	○
线材	○	○	○	○	○	○
喇叭	○	○	○	○	○	○
主板	○	○	○	○	○	○
电池	○	○	○	○	○	○
其它	○	○	○	○	○	○

○:表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定的限量要求以下。
X:表示该有害物质在该部件的某一均质材料中的含量超出GB/T26572规定的限量要求。

Model: MS62144

PHONIC 20
PORTABLE VOICE AMPLIFIER

Quick Start Guide

请仔细阅读本快速指南并妥善保管以备将来使用

本产品由中国平安网络公司承保

Product Overview

1.Multifunction Knob

2.Recording Function

Short press: Enter recording mode

Long press: Delete the currently playing recording file

3.Previous song

4.Play/Pause

Short press: Previous song

Double click: Disconnect/connect Bluetooth

Hold for 5 seconds to clear all paired device records

5.Next song

Short press: Next song

6. Mode switch

Short press:Mode switching

7.MIC Input Port

Used to connect a wired microphone for voice input

8.USB (Audio) Input

Connect a USB storage device

9.USB-C Charging

Connect a Micro SD card mode storage device

10. Indicator Light

11. Micro SD card Input

Connect a Micro SD card mode storage device

12.Charging Indicator

LED indicator/Prompt tone Guide

	Describe	Prompt tone	Status
Indicator Light	The white light flashing	Power on tone	Power on
	All lights off	Power off tone	Power off
Indicator Light	The white light flashing	-	Not connected
	The white light stays on	Connected tone	Connected
Low battery	The red light flashing	Low battery tone	-
	Charging in progress, the red charging indicator light stays on	-	-
Voice Amplifier charging	After fully charged, the red charging indicator light off	-	-

Power/Charging

For better enjoyment, fully charge the Voice Amplifier before use.
A USB-C charging cable (charge only) is included for standard USB compatible device.
Please use a 5V/1A or above power adapter (not included).
Caution: - Other incompatible charges may cause damages.
- Do not use if the connector or device is wet or damaged.

Power On/Off

To turn on the Voice Amplifier, rotate the multifunction knob clockwise to power it on. A startup tone will be heard.
To turn off the Voice Amplifier, rotate the knob counterclockwise. A shutdown tone will be heard.

Bluetooth Connection

- When first used and turned on, the Voice Amplifier will automatically enter a waiting mode for connection.
- If the Bluetooth device is already connected, double click the “” button to disconnect the current connection so that you can connect to another device.
- The Voice Amplifier will automatically enter pairing mode if it is not connected to a Bluetooth device.

When connecting, enable the Bluetooth function of the mobile phone, search for “**Monster Phonic 20**” and connect. After the connection is successful, you will hear a prompt tone, the white light of stays on.

Music Control

Short press “” music can be played or paused.
Short press “” to go to the previous song.
Short press “” to go to the next song.

Volume Control

Turn counterclockwise to decrease volume.
Turn clockwise to increase volume.

USB IN (Audio) Playback

When Voice Amplifier is on and USB drive is inserted, USB IN (Audio) is the priority playback source. If you want to use Bluetooth function, press the “**M**” button to switch the source.

Micro SD Card Playback

When Voice Amplifier is on and micro SD card (not included) is inserted, micro SD card is the priority playback source. If you want to use Bluetooth function, press the “**M**” button to switch the source.

Recording

When a micro SD card or USB drive is inserted, short press the “” button to start recording. Short press the “” button again to stop recording, and the Voice Amplifier will automatically play the current recording (the newly recorded file will be prioritized and looped). Short pressing any button will exit the recording playback.

Recording Playback

In micro SD card or USB playback mode, double click the “” button to enter the recording playback function, and the saved recordings will be played in sequence.Press the “” button briefly to play the previous recording, and press the “” button briefly to play the next recording.Double click the “” button again to exit the recording playback mode.

Delete Recording

In recording playback mode, while playing the current recording, press and hold the“” button for 2 seconds to delete it.

Reset Device

If the Voice Amplifier needs to be reset, press and hold the “” and “” button for 5 seconds.

Caution

- It is not recommended to replace the battery privately.
- The battery (battery pack or battery pack combination) must not be exposed to sunshine, fire or similar overheated environments.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
· Reorient or relocate the receiving antenna.
· Increase the separation between the equipment and receiver.
· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
· Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

For service, warranty, or product information, Please contact: support@mct-audio.com with your order ID.

FCC ID: 2AVD2-MS62144

IC Caution

Radio Standards Specification RSS-Gen, issue 5
- English:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:
Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.
IC: 28087-MS62144