

Model:MS62145

NANO

便携蓝牙音响

快速指南

请仔细阅读本快速指南并妥善保管以便将来使用
本产品由中国平安保险有限公司承保

产品概述

1.电源开/关机
长按:开机/关机
单击:播放/暂停
双击:模式切换
长按10秒可清除所有已配对的设备记录

2.上一曲/音量减
短按:调低音量
长按:上一首歌

3.指示灯
4.下一曲/音量加
短按:调高音量
长按:下一首歌

5.充电指示灯

6.USB-C充电接口

LED 指示灯 / 提示音指南

	描述	语音提示	状态
指示灯	白色指示灯闪烁	开机提示音	开机
	所有灯熄灭	关机提示音	关机
指示灯	白色指示灯闪烁	-	未连接
	白色指示灯长亮	连接成功提示音	已连接
低电提示	红色指示灯闪烁	低电提示音	-
音响 充电	充电中, 红色指示灯长亮	-	-
	充满电, 红色指示灯熄灭	-	-

电源/充电

为了更好的使用体验,在使用音响前,您需要先为其充满电。
包装中包含了一条USB-C充电线(仅充电,无数据传输功能),使用5V/1A或以上适配器(不包含)进行充电。
注意:- 其它不兼容的充电线可能会造成损坏。
- 如果连接线或设备潮湿、损坏,请勿充电。

开机/关机

在关机模式下,长按“⏻”键2秒开启音响,可听到开机提示音。
关闭音响,请再次长按“⏻”键2秒,可听到关机提示音。
注意:开机后如没有连接到蓝牙设备,音响大约在15分钟后关闭。

蓝牙配对

•首次使用并开机时,音响将自动进入配对模式。
•如没有连上蓝牙设备,音响也会自动进入配对模式。
连接时,启用手机的蓝牙功能,搜索“**Monster Nano**”进行连接,连接成功后你会听到提示音,白色指示灯长亮。

音乐控制

短按“⏻”键,可播放或暂停音乐。
长按“-”键,可播放上一首歌。
长按“+”键,可播放下一首歌。

通话控制

接听来电:短按“⏻”键。
拒接来电:双击“⏻”键。
结束通话:短按“⏻”键。

音量控制

短按“+”键调高音量。
短按“-”键调低音量。

定时模式

在开机状态下,双击“⏻”键即可进入定时模式。如需设置时长短按“⏻”键,30-60-90-无限-30分钟循环设置;30分钟绿色指示灯亮,60分钟白色指示灯亮,90分钟蓝色指示灯亮,无限指示灯熄灭。再次双击“⏻”键即可切换到蓝牙模式。

省电设置

•音响开机后,如没有连接到蓝牙设备,大约在15分钟后自动关机。

恢复出厂设置

在开机状态下,长按“⏻”键10秒,即可恢复出厂设置。

注意

•不建议未经许可私下更换电池。
•电池(电池组或电池组合)不得暴露在诸如日照、火烤或类似过热环境中。

有害物质或元素表

有害物质名称	有害物质		有害物质		有害物质		有害物质	
	铅(Pb)	镉(Cd)	汞(Hg)	六价铬(Cr(VI))	多溴联苯(PBBs)	多溴二苯醚(PBDEs)	邻苯二甲酸酯类(PHTHALATES)	
外壳	○	○	○	○	○	○	○	
线材	○	○	○	○	○	○	○	
喇叭	○	○	○	○	○	○	○	
主板	○	○	○	○	○	○	○	
电池	○	○	○	○	○	○	○	
其它	○	○	○	○	○	○	○	

○表示该有害物质在指定部件中的含量均在GB/T2657规定的限量要求以下。
X表示该有害物质在指定部件中的含量超过GB/T2657规定的限量要求。

Model:MS62145

NANO

PORTABLE BLUETOOTH SPEAKER

Quick Start Guide

Please read this Quick Start Guide carefully and keep it for future use

Product Overview

1.Power On/Off
Long press: Power on/off
Short press: Play/pause
Double click: Mode switch
Hold for 10 seconds to clear all paired device records

2.Previous song/Volume down
Short press: Volume down
Long press:Previous song

3. Indicator Light
4.Next song/Volume up
Short press: Volume up
Long press: Next song

5.Charging Indicator Light

6.USB-C Charging Input

LED indicator/Prompt tone Guide

	Describe	Prompt tone	Status
Indicator Light	The white light flashing	Power on tone	Power on
	All lights off	Power off tone	Power off
Indicator Light	The white light flashing	-	Not connected
	The white light stays on	Connected tone	Connected
Low battery	The red light flashing	Low battery tone	-
	Charging in progress, the red charging indicator light stays on	-	-
	After fully charged, the red charging indicator light turns off	-	-

Power/Charging

For better enjoyment, fully charge the speaker before use.
A USB-C charging cable (charge only) is included for standard USB compatible device.
Please use a 5V/1A or above power adapter (not included).
Caution: - Other incompatible charges may cause damages.
- Do not use if the connector or device is wet or damaged.

Power On/Off

To turn on the speaker, press and hold the Power On/Off Button for 2 seconds, you will hear a power on tone.
To turn off the speaker, press and hold the Power On/Off Button for 2 seconds, you will hear a power off tone.
Caution: If no Bluetooth device is connected, the speaker will turn off in 15 minutes.

Bluetooth Connection

• When first used and turned on, the speaker will automatically enter a waiting mode for connection.
• The speaker will automatically enter pairing mode if it is not connected to a Bluetooth device.
When connecting, enable the Bluetooth function of the mobile phone, search for “**Monster Nano**” and connect. After the connection is successful, you will hear a voice prompt, the white light of stays on.

Music Control

Short press “⏻” music can be played or paused.
Long press “-” to go to the previous song.
Long press “+” to go to the next song.

Call Mode

Answer a call: Short press the “⏻” button.
Reject a call: Double click the “⏻” button.
End the call: Short press the “⏻” button.

Volume Control

Short press the “+” button to turn up the volume.
Short press the “-” button to turn down the volume.

Timer Mode

When the device is powered on, double click the “⏻” button to enter Timer Mode. To set the timer duration, short press the “⏻” button to cycle through 30-60-90-Infinite-30 minutes.30 minutes: green indicator light on,60 minutes: white indicator light on,90 minutes: blue indicator light on,Infinite: indicator light off. Double click the “⏻” button again to switch to Bluetooth mode.

Power Saving Settings

•In Bluetooth mode, when no device is connected, the speaker will be switched off automatically in 15 minutes.

Reset Device

If the speaker needs to be reset, press and hold the “⏻” button for 10 seconds.

Caution

•It is not recommended to replace the battery privately.
•The battery (battery pack or battery pack combination) must not be exposed to sunshine, fire or similar overheated environments.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

For service, warranty, or product information,
Please contact: support@mct-audio.com with your order ID.

FCC ID: 2AVD2-MS62145

IC Caution

Radio Standards Specification RSS-Gen, issue 5
- English:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
This device may not cause interference.
This device must accept any interference, including interference that may cause undesired operation of the device.
RF exposure statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
- French:
Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:
Cet appareil ne doit pas causer d'interférences.
Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.
Déclaration d'exposition RF:
L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.
IC: 28087-MS62145

105g双胶186C+K 风琴折
双色印刷 70x75mm