

AT&T - 4.75" x 3 - QSG - Generic Version

AT&T Fusion® Z

Let's get started

What else is in the box?

- AT&T Fusion® Z Smartphone
- AT&T PREPAID™ SIM Card (Pre-installed)
- Power Adapter
- USB Type-C Cable
- 3,300mAh Battery (Non-removable)
- Safety Information Guide
- Quick Start

Connect Wi-Fi & Other Devices

Connect to Wi-Fi Network

1. Swipe up on the Home screen, tap **Settings** > **Network & Internet**
2. Select **Wi-Fi**
3. Tap **Use Wi-Fi**, and select the desired network.
4. Enter the password, and tap **Connect**.

Use Bluetooth

1. Swipe up on the Home screen, tap **Settings** > **Connected devices**
2. Tap **Pair new device** +, and then tap on the desired device.
3. Enter the PIN or passkey, and tap **PAIR**.

Useful Apps*

AT&T Visual Voicemail

Receives voicemail messages in an email-like inbox. You can easily play and delete messages, return calls and manage voicemail features.

AT&T ProTech

Allows Mobile Protection Pack and Multi-Device Protection Pack subscribers to click-to-call as well as click-to-chat so you can quickly get help from one of our ProTech support experts.

AT&T Smart Wi-Fi

Helps you make your data plan last longer. It also remembers and connects to your favorite hotspots and finds more Wi-Fi options when you're on the go.

HBO Max

The streaming platform that bundles all of HBO together with even more of your favorite TV series, blockbuster movies, plus new Max Originals.

Find More Information

Manage Your Account with myAT&T

- On the web: att.com/myATT

Compatible device and online account required. Data and messaging rates may apply for downloads and app usage.

Need More Help?

- On your phone: **Apps > AT&T > Device Help**
- On the web: att.com/DeviceHowTo

Give us a Call

- 611 from any AT&T wireless phone.
- 800.331.0500 or prepaid 800.901.9878.

How to replace the SIM

Insert a SIM/microSD

1. Lift the back cover at the notch on the lower left corner of the device, then firmly peel back the flexible cover to remove it.
2. Slide the small red lever at the bottom of the SIM slot from left to right to remove the pre-installed SIM.
3. Hold the new SIM with metallic contact facing down and the cut at the lower left corner. Slide the card into the SIM slot.
4. Hold the microSD card (sold separately) with metallic contacts facing down and the cut side on the right. Slide the card into the microSD slot.
5. Replace the cover on the back of the phone and ensure proper assembly by pressing and clicking around the cover's edges.
6. Press and hold the **Power/Lock key** until the device turns on.

Call Family & Friends

Make a Call

1. From the Home screen, tap **Phone**
2. Make a call by selecting one of the following options:
 - Enter a phone number into the keypad, and tap **Call**
 - Choose a recently called contact in **Recents**
 - Choose a saved contact in **Contacts**
 - Choose a favorite contact in **Favorites**

Check voicemail

1. From the Home screen, tap **Phone** > **Phone**
2. Press and hold the **1 key** or hit the Voicemail
3. Follow voice prompts to listen to messages.

Visual voicemail

1. Swipe up on the Home screen and tap **Visual Voicemail**
2. Select a message to play.

Your New Phone

Proximity and light sensor, Front camera, Touchscreen, Back key, Microphone, Home key, Headset port, Microphone, Volume keys, Power/Lock key, Recent apps key, Charging port.

Email & Messaging

Create a new conversation

1. From the Home screen, tap **Messages**
2. Tap + to create a new message.
3. In the **To** field, enter a contact, phone number, or email, and then tap or select from frequent or all contacts.
4. Tap + to attach a file. Send photos, videos, contact information, sound recordings, or files
5. Tap to send message.

Email Setup

5. Swipe up on the Home screen, tap **Gmail**
6. Follow instructions on the screen to set up your account.

Capture Life's Moments

Take a photo

1. From the Home screen, tap **Camera**
2. Tap to adjust Camera settings.
3. Tap or press a **Volume Key** to take a photo.

Record a video

1. In Camera mode, tap **Video**
2. Tap to start/stop recording.
3. Tap to take a picture when taking a video.

Share a photo or video

1. From the Home screen, tap **Gallery**
2. Tap a photo or video, then tap **Share**. Choose to send via text messaging, email or more.

Easily Adjust Settings

Settings Menu

- Swipe up on the Home screen, tap **Settings**

Quick Settings

1. Swipe your finger down on the Home screen to open the Notifications panel.
2. Swipe down again to see the Quick Settings menu.
3. Tap a setting to toggle it on or off.

Printed in USA

DOC20200405

Flat

Folded - Front

Folded - Back

Blank size: 9.5in x 9in or 241.3mm x 228.6mm

Folded size: 4.75in x 3in or 120.65mm x 76.2mm