

110±1

272±0.50

68±0.50

What else is in the box?

- Vsmart One Smartphone
- Power Adapter
- USB Type-C Cable
- Ejector Pin
- Headset
- Case cover
- Quick Start Guide (ENG & ESP)
- Anti-viral screen protection film
- Safety Information Guide

Find More Information

Visit our website: www.vsmart.net/us/warranty

Data and messaging rates may apply for downloads and app usage.

How to replace the SIM

Insert a SIM

1. Insert the SIM card eject tool into the small hole in the SIM card tray.
2. Press to eject the tray, but don't force it.
3. To replace the preinstalled SIM, remove it from the tray and replace it with the new SIM.
4. Insert the SIM tray back into the device completely and in the same orientation that you removed it.

Your New Phone

Labels: Proximity and light sensor, Sub Microphone, Front camera, Receiver, SIM Tray, Volume keys, Touchscreen, Power/Lock key/Fingerprint, Recent apps key, Headset port, Home key, Back key, Speaker, Main microphone, Charging port.

Vsmart One

V740S

Quick Start Guide

Printed in Vietnam
A07F01114

Connect Wi-Fi & Other Devices

Connect to Wi-Fi Network

1. Swipe up on the Home screen, tap **Settings** > connect.
2. Select **Wi-Fi**.
3. Tap **On**, and select the desired network.
4. Enter the password, and tap **Connect**.

Use Bluetooth

1. Swipe up on the Home screen, tap **Settings** > connect.
2. Select **Bluetooth**.
3. Tap **On**, and select the desired device.
4. When Bluetooth pairing code appear, and tap **Pair**.

Call Family & Friends

Make a Call

1. From the Home screen, tap **Phone**.
2. Make a call by selecting one of the following options:
 - Enter a phone number into the keypad, and tap **Call**.
 - Choose a recently called contact in **Recents**.
 - Choose a saved contact in **Contacts**.
 - Choose a favorite contact in **Favorites**.

Email & Messaging

Create a new conversation

1. From Home screen, tap **Messages**.
2. Tap **+** to create a new message.
3. In the **To** field, enter a contact, phone number, or email, and then tap **✓** or select from frequents or all contacts.
4. Tap **+** to attach a file. Send photos, videos, contact information, or files.
5. Tap **✓** to send message.

Email Setup

5. Swipe up on the Home screen, tap **Gmail**.
6. Follow instructions on the screen to set up your account.

Easily Adjust Settings

Settings Menu

- Swipe up on the Home screen, tap **Settings**.

Quick Settings

1. Swipe your finger down on the Home screen to open the Notifications panel.
2. Swipe down again to see the Quick Settings menu.
3. Tap a setting to toggle it on or off.

COPYRIGHT OF VINSMART RESEARCH & MANUFACTURING.		DESIGN BY	N.T.B.Ngan		 VinSmart Research & Manufacturing., JSC			
ROHS		DATE	06.01.2021					
		DRAWN BY	T.V.Tu		VINCODE: A07F01071			MASS (g)
(Restriction Of Hazardous Substances)		DATE	15.07.2020		PART NAME: Quick Start Guide			
THIRD ANGLE PROJECTION		CHECKED BY	M.T.TU		MODEL NAME: Aris_V740			REVISION
		DATE	15.07.2020					
		APPROVE BY	H.V.Loi		SIZE	UNIT	SCALE	SHEET
		DATE	15.07.2020			MM	1.00	