




Band38-15MHz-16QAM-38000-1RB#0-30~1000-PASS



Band38-15MHz-16QAM-38000-1RB#0-1000~3000-PASS



Band38-15MHz-16QAM-38000-1RB#0-3000~18000-PASS



Band38-15MHz-16QAM-38000-1RB#0-18000~27000-PASS



Band38-15MHz-16QAM-38000-1RB#74-0.009~0.15-PASS



Band38-15MHz-16QAM-38000-1RB#74-0.15~30-PASS

