



Band38-20MHz-QPSK-38000-1RB#0-30~1000-PASS



Band38-20MHz-QPSK-38000-1RB#0-1000~3000-PASS



Band38-20MHz-QPSK-38000-1RB#0-3000~18000-PASS



Band38-20MHz-QPSK-38000-1RB#0-18000~27000-PASS



Band38-20MHz-QPSK-38000-1RB#99-0.009~0.15-PASS



Band38-20MHz-QPSK-38000-1RB#99-0.15~30-PASS











