



Band38-5MHz-16QAM-38225-1RB#24-30~1000-PASS




Band38-5MHz-16QAM-38225-1RB#24-1000~3000-PASS



Band38-5MHz-16QAM-38225-1RB#24-3000~18000-PASS




Band38-5MHz-16QAM-38225-1RB#24-18000~27000-PASS





Band38-5MHz-16QAM-38225-25RB#0-0.009~0.15-PASS



Band38-5MHz-16QAM-38225-25RB#0-0.15~30-PASS









Band38-10MHz-QPSK-37800-50RB#0-30~1000-PASS



Band38-10MHz-QPSK-37800-50RB#0-1000~3000-PASS



Band38-10MHz-QPSK-37800-50RB#0-3000~18000-PASS



Band38-10MHz-QPSK-37800-50RB#0-18000~27000-PASS



Band38-10MHz-QPSK-38000-1RB#0-0.009~0.15-PASS



Band38-10MHz-QPSK-38000-1RB#0-0.15~30-PASS

