






Band38-10MHz-16QAM-38200-1RB#0-30~1000-PASS



Band38-10MHz-16QAM-38200-1RB#0-1000~3000-PASS



Band38-10MHz-16QAM-38200-1RB#0-3000~18000-PASS



Band38-10MHz-16QAM-38200-1RB#0-18000~27000-PASS



Band38-10MHz-16QAM-38200-1RB#49-0.009~0.15-PASS



Band38-10MHz-16QAM-38200-1RB#49-0.15~30-PASS




Band38-10MHz-16QAM-38200-1RB#49-30~1000-PASS



Band38-10MHz-16QAM-38200-1RB#49-1000~3000-PASS



Band38-10MHz-16QAM-38200-1RB#49-3000~18000-PASS




Band38-10MHz-16QAM-38200-1RB#49-18000~27000-PASS





Band38-15MHz-QPSK-37825-1RB#0-0.009~0.15-PASS




Band38-15MHz-QPSK-37825-1RB#0-0.15~30-PASS









Band38-15MHz-QPSK-38000-1RB#0-30~1000-PASS



Band38-15MHz-QPSK-38000-1RB#0-1000~3000-PASS



Band38-15MHz-QPSK-38000-1RB#0-3000~18000-PASS



Band38-15MHz-QPSK-38000-1RB#0-18000~27000-PASS



Band38-15MHz-QPSK-38000-1RB#74-0.009~0.15-PASS



Band38-15MHz-QPSK-38000-1RB#74-0.15~30-PASS