

Bluetooth Speaker

USER MANUAL

Safety Instructions

Read this manual carefully before using the device and keep this manual for future reference.

- Keep the device away from heat, direct sunlight and sharp edges.
- Keep the device away from naked flames.
- Do not insert any metal object into the device.

Risk of short circuit!

- To avoid a static charge, do not use the device in an extremely dry climate.
- Do not repair the unit yourself but contact an authorized specialist.

How to use

1. **M** button : Short Press to change the mode(BT /FM/TF/USB),long press to switch on/switch off the lights.

2. **+** button: short press for next song, long press to increase volume.

3. **-** button: short press for previous song, long press to decrease volume.

4. **▶** button: 1)Bluetooth mode: short press to control PLAY/PAUSE music

2) FM mode: long press to search the channel automatically.

3) Bluetooth call: short press to answer/hang up the phone,
double-press to call back.



5V/IN : charging port

ON/OFF : Switch on/Switch off

TF: TF card connection

USB: USB connection

5. How to match Bluetooth

- 1) Switch on the speaker with BT mode.
- 2) Turn on your mobile phone and activate the BT function.
- 3) Search for BT device. "D03+" will show up.
- 4) click "D03+" ,it will match successfully.

Notes & Tips:

Once this speaker is matched and connected to your mobile phone, when you switch on this speaker next time, it will connect to your mobile phone automatically as long as the Bluetooth in your mobile phone is on.

6.TF/USB Function

Insert the TF card/USB, the speaker will play music automatically. Short press ► button to PLAY/PAUSE, Short press+/-button to change song. And short press M button to change the mode(BT/FM/TF/USB mode).

7.FM Function

Change to FM mode, insert the charging cable as antennae, long press ► button to

search the channel automatically.

Short press **+/-**-button to change channel.

8. TWS interconnection

1) Switch on two speakers on BT mode.

2) Double press **M** button of one speaker, Hear the voice prompt for about 10 seconds.

3) then search and match the BT device with your phone, and two speakers can be played the same song synchronously.

9. Indicator light

The red light keeps on when charging, turn off after a full charge.

Specifications:

Power rating: 5W

The rated voltage: 3.7V

Frequency response:

100HZ-18KHZ

S/N Ratio: >65db

Support TF card、USB to
play MP3 directly

Built-in rechargeable battery

Continuous working: 3H

Support Mobile phone
hands-free function

Accessories included

1 * USB charging cable

Troubleshooting

Symptoms	Causes	Solutions
Can not switch the speaker on	Battery empty	Charge the battery
Unable to pair the speaker	Speaker is already switched on, and it is not in pairing mode.	Refer to the section of "Pairing D03+ to mobile phone or other device"

MADE IN CHINA

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.