

尺寸278x68mm 双面

Instructions



Wireless Earphones

Specification

Bluetooth version: TWS+EDR
Support protocol: A2DP1, 3/HFP1, 6/HSP1, 2/AVRCP1, 6/D1 1, 3
Frequency: 2.4GHz
Capacity: Earbuds 30mAh, charging case: 200mAh
Transmit distance: 10m
Mobile name: TW300

Operation instruction

1. pairing and connection: Open the cover of charging tank and take out all earphones, then left and right earphones will be turned on and paired automatically, and then bluetooth name will be showed in bluetooth searching area of mobile phone, click bluetooth name to finish connection
2. Turn on: Open the cover, take out all earphones, connect previous devices automatically
3. Turn off: Put all earphones back into charging tank, shut cover and then earphones will be turned off and charged automatically
4. Turn off manually: Press left/right earphone for 5 seconds.
5. Answer the phone: short press the touch key once in the calling state
6. Hang up the phone: short press the touch key once in the call state
7. Refuse to listen to the phone: press and hold the touch key for 2 seconds To release
8. Pause playing songs: press the touch key once in the connects state (the mobile phone player is on)

9. Volume plus/down: double click.
10. Last / Next song: three strikes .
11. Call Siri: Press left/right earphone for 3 seconds. (iOS only)

(Please note that you must use the 5V1A charging cable charge
The bluetooth headset charging box or use the charging cable
Delivered when you purchased the product)

Note

1. Do not disassemble. Press the product with heavy thing, for away from high temperature and humidity environment
2. Far away from wifi and route etc. Radiation equipment
3. Please keep within 10m distance between device and earbuds
4. Recharging the product every month if it is not used long time
5. Restart the earbuds if some issue happened to avoid the operation caused The issue

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Made in China



使用说明书



真无线蓝牙耳机

参数配置

蓝牙版本: TWS+EDR超低功率
支持协议: A2DP1, 3/HFP1, 6/HSP1, 2/AVRCP1, 6/D1 1, 3
蓝牙使用频段: 2.4GHz
电池容量: 左右耳内置30mAh, 充电盒电池200mAh
蓝牙传输距离: 10m
蓝牙名称: TW300

使用说明

1. 配对连接: 充电仓打开盖子, 左右耳同时开机, 两边耳机自动配对, 并在手机蓝牙搜索处出现该蓝牙名称, 点击蓝牙名连接
2. 开机: 开盖, 拿起自动开机, 配对连接先前设备
3. 关机: 放回充电仓, 关盖, 自动关机充电
4. 手动开关机: 左右声道长按5秒
5. 接听电话: 来电状态下短按触摸键一次。
6. 挂断电话: 通话状态下短按触摸键一次。
7. 拒听电话: 来电状态下长按触摸键2秒放开。
8. 展厅播放歌曲: 链接状态下短按一次触摸键 (手机播放器有打开)。
9. 音量加減: 双击。
10. 上下曲: 三击。
11. 召唤Siri: 左右声道长按3秒 (仅支持iOS系统)

(请注意务必使用5V1A的充电器对蓝牙耳机充电盒进行充电或
使用购买产品时配送的充电线进行充电)

注意事项

1. 请勿暴力对待本产品, 不要重物挤压, 远离高温高湿环境。
2. 远离WiFi及路由器及高频发射设备。
3. 请在有效环境 (10米) 内使用本产品, 并且蓝牙设备与耳机直接不要有实体阻挡 (例如墙体等)
4. 产品长期不使用的, (一个月内) 将耳机和底座进行充电。
5. 若出现故障, 请重启耳机按1/2点操作 (避免因误操作引起)