인쇄내용확인! 인증이미지확인!

제품상자에 넣기에 적합한 사이즈는 접은 상태의 정사이즈(95X160mm)이며,
오차범위는 +- 1mm입니다.

전면

285

160,00

QUICK START GUIDE





バッテリー挿入及び交換方法

1. 製品のハンドル底部キャップを回し、
   内部にあるバッテリーハウジングを取出ください。
2. 図のようにバッテリー(AAA)3個をハウジングに組み合わせください。
   バッテリーを組み合わせする際に、(+、ー)を確認ください。
   スプリングが有る方向が(ー)、
   スプリングが無い方向が(+)になります。
3. バッテリーを入れたハウジングを製品のハンドルに表示された矢印の方向に入れ、
   底部キャップを閉めください。

使用方法

1. 電源ON/OFF：ボタン①を1〜2秒間押しください。
2. ブルートゥースモードON/OFF：ボタン①、②を同時に1〜2秒間押しください。
3. 色カラーモード
   - ボタン①を短く押すとLEDカラーが変ります。
   - ボタン①を長く押すと電源がOFFになります。
   - ボタン②を短く押すとLED点滅速度(遅め＞普通＞早め)が変ります。
   - ボタン②を長く押すと複数カラーモードに変ります。
4. 複数カラーモーモ
   - ボタン①を短く押すとLEDカラーが変ります。
   - ボタン①を長く押すと電源がOFFになります。
   - ボタン②を短く押すとLED点滅速度(遅め＞普通＞早め)が変わります。
   - ボタン②を長く押すと1色カラーモードに変わります。

* 会場内では本製品の無線コントロールの為、スマートホンと応援棒をペアリングしチケット情報とマッチングしてください。
* スマートホンとブルツースのペアリングには無線で繋がる為、使用中にペアリングが解除される場合もあります。
* スマートホンとブルツースのペアリング出来ない場合、ヘルプデスクにお問い合わせください。
* ブルツースはBLUETOOTH 4.2以上対応です。

取扱時、注意事項

1. 高温多湿の場所は避け、保管する際には常温で保管ください。
2. LEDの光を近付いて直接観るのはおやめください。
3. 製品を落としたり、無理やり衝撃を加える場合、LED色に影響ある可能性がありますのでご注意ください。
4. 部品を食べたり、口の中に入れないでください。
5. 製品に強い衝撃を加えたり、沈水されると故障の原因になりますのでご注意ください。DE
6. 製品にダメージがある際には、使用をおやめください。製品を改造及び分解をおやめください。
7. バッテリーの寿命が値が付いと新しいバッテリーに変更ください。長時間、未使用の場合、バッテリーを取り出しください。
8. 廃バッテリーは子供の手の届かない場所に保管ください。必ず回収ボックスに処分ください。
9. 必ずAAAバッテリーを使用し、挿入する際には+、ーを確認ください。そうでは無いと故障、やけど、火災が起る場合があります。
10. 本製品は無線のため、混線する可能性があります。

品質保証書

1. 本製品は厳密な品質管理及び検査を実施し、製造した製品です。
2. 消費者の正常な使用状態で故障が発生した場合、保証期間中に無償修理を致します。
3. 修理する際には必ず保証書を提示ください。
4. 保証書は韓国で有効になります。
5. 保証期間は購入してから三ヶ月になります。

* 不注意による故障はA/S対象外になります。

有償アフターサービス処理規定

1. 保証期間が過ぎた場合。
2. 不注意による故障、破損する場合。
3. 洪水、火災、地震など天災地変により故障が発生した場合。
4. 使用中に生じた傷等によりケースの取替えを希望する場合。
5. 正式なアフターサービスセンター以外のアフターサービスセンターを利用したり、製品を任意に分解、修理、改造した場合。

製品ドキュメント

なまえ | ENHYPENオフィシャルライトスティックVER.1
モデル | EN- OFFICIAL 0320IP
サイズ | 218 x 96 x 90 mm
重量 | 148g(バッテリーを除く)
材料 | PC
コンポーネント | 応援棒、ダストバッグ、ストラップ、商品取扱説明書、フォトカード
パワー | アルカリ単4電池3本(推奨), DC 4.5V⎓
認定(JAPAN-MIC) | 211-210111
使用温度 | 0°C〜50°C(32°F〜122°F)
製造企業 | PARTRON Co.,Ltd
製造国 | KOREA

A/Sアドレス、連絡先情報、メールアドレス | Big Hit IP Co., Ltd | 02-3444-0150 | light-stick.support@bighitcorp.com
保証期間 | 購入日から3ヶ月(レシート認証が必要)

QUICK START GUIDE





如何插入及更換電池

1. 轉動產品手柄底部的蓋子並取出裡面的電池盒。
2. 如圖所示，將三節電池(AAA)連接到外殼中。
(連接電池時，請檢查正極和負極，外殼的彈簧部分是電池的陰極，
沒有彈簧的部分是陽極)
3. 將電池盒和電池一起插入在產品手柄上箭頭所指的方向，並關閉底蓋。

如何使用

1. 電源開/關 = 按下按鈕① 1.5秒鐘。
2. 藍牙模式開/關=同時按下按鈕①和② 1.5秒鐘。
3. 單色模式
   - 短按按鈕①更改LED顏色。
   - 長按按鈕①，終端機將關閉。
   - 短按按鈕②可以更改LED閃爍速度。(慢速>正常>快速)
   - 長按按鈕②切換到混合色模式。
4. 混合色模式
   - 短按按鈕①更改LED顏色。
   - 長按按鈕①，終端機將關閉。
   - 短按按鈕②可以更改LED閃爍速度。(正常>快速)
   - 長按按鈕2切換到單色模式。

* 在會場內無線控制此產品時，請通過智能手機和應援棒配對匹配門票信息。
* 由於智能手機和藍牙之間的連接是無線，因此在使用過程中可能會間歇性斷開連接。
* 如果您無法將智能手機與應援棒配對，請聯繫幫助台(配對攤位)。
* 藍牙僅支持 BLUETOOTH 4.2 或更高版本。

處理時注意事項

1. 避開潮濕的地方，存放時保持室溫。
2. 避免直接靠近LED燈。
3. 注意不要掉落本產品或施加過大的衝擊力可能會導致LED燈光顏色的變異。
4. 注意不要吞下零件或將其放入嘴中。
5. 如果產品受到強烈衝擊或與水接觸，可能會引起故障，請務必小心。
6. 如果產品損壞，請停止使用，並且請勿改裝或拆卸產品。
7. 當電池使用壽命結束時請更換新電池，如長時間不使用時請取出電池。
8. 當電池達到使用壽命時，請將其放在嬰兒和兒童接觸不到的地方，或將其放在指定的處置場所。
9. 接收時，請使用原裝的AAA電池，並且在插入電池時，請務必檢查正極和負極，否則會導致產品損壞，灼傷和火災的危險。
10. 在無線操作過程中，本產品可能會引起混亂。

產品質量保證

1. 該產品已通過嚴格的質量控制和檢查過程而製造。
2. 如果消費者在正常使用期間發生故障，我們將在保修期內提供免費維修。
3. 要求維修時，請務必提供此保修證。
4. 保修僅在韓國有效。
5. 保修期為自購買之日起3個月。

* 因消費者過失和過失造成的故障不包括在 A/S中。

A/S 收費處理規定

1. 保修期到期。
2. 因過度使用或使用疏忽而導致的產品故障或損壞。
3. 因自然災害(如洪水，火災，地震等)導致的故障。
4. 由於在使用過程中發生刮擦，需要更換外殼。
5. 使用官方保修中心以外的其他本地保修中心提供的服務，或隨意拆卸，修理或改造產品。

產品說明書

名称 | ENHYPEN OFFICIAL LIGHT STICK VER.1
模型 | EN- OFFICIAL 0320IP
尺寸 | 218 x 96 x 90 mm
重量 | 148g (不含電池)
材料 | PC
组件 | 應援棒，垃圾袋，背帶，產品手冊，照片卡
电源 | 3节碱性AAA电池(推荐)，DC 4.5V⎓
認證 |
操作温度 | 0°C to 50°C(32°F to 122°F)
制造商 | PARTRON Co.,Ltd
制造国 | KOREA

A/S地址，聯繫信息和電子郵件 | Big Hit IP Co., Ltd | 02-3444-0150 | light-stick.support@bighitcorp.com
保修期 | 自購買之日起3個月(需要收據驗證)

LAONZ

ENHYPEN OFFICIAL LIGHTSTICK VER.1

© BELIFT LAB Inc. All Rights Reserved.

95

95

95

후면

285

160,00

QUICK START GUIDE





배터리 삽입 및 교체 방법

1. 제품 손잡이 하단의 캡을 돌려 내부에 있는 배터리 하우징을 꺼내 주세요.
2. 그림과 같이 배터리(AAA) 3개를 하우징에 결합하여 주세요.
   (배터리 결합 시, +, ㅡ극을 확인하여 주세요.
   하우징에 스프링이 있는 부분이 배터리의 ㅡ극, 스프링이 없는 부분이 +극 입니다.)
3. 배터리를 결합한 배터리 하우징을 제품의 손잡이에
   표시된 화살표 방향으로 넣고, 하단 캡을 닫아 주세요.

사용 방법

1. 전원 On/Off : 버튼 ①을 1.5초 누르세요.
   [처음 전원을 켜면 공연 모드 진입]
2. 블루투스 모드 On/Off : 버튼 ①, ②을 동시에 1.5초 누르면,
   스마트폰과 블루투스 연결을 시도합니다.
3. 기본모드[공연 모드]
   - Button ①을 짧게 누르면 LED 컬러가 변경 됨
   - Button ①을 길게 누르면 단말기 Off 됨
   - Button ②을 짧게 누르면 LED 점멸 속도(Slow>Normal>Quick)가 변경됨
   - Button ②을 길게 누르면 오로라 모드로 전환
4. 오로라 모드
   - Button ①을 짧게 누르면 오로라 컬러가 변경됨
   - Button ①을 길게 누르면 단말기 Off 됨
   - Button ②을 짧게 누르면 LED 점멸 속도(Normal>Quick)가 변경됨
   - Button ②을 길게 누르면 오로라 모드 해제하고, 기본모드[공연모드] 진입

* 공연장 내에서 본 제품의 무선 컨트롤을 위하여 스마트폰과 응원봉의 페어링을 통해 티켓 정보와 매칭시켜 주세요.
* 스마트폰과 블루투스의 연결은 무선으로 연결되므로, 사용 중 연결이 간헐적으로 해제될 수 있습니다.
* 스마트폰과 응원봉의 페어링이 안 될 경우, HELP DESK(페어링 부스)에 문의하여 주세요.
* 블루투스는 BLUETOOTH 4.2 이상만 지원합니다.

취급 시 주의 사항

1. 고온 다습한 곳을 피하고, 보관 시에는 상온에서 유지하여 주세요.
2. LED 빛을 가까운 곳에서 직접 보는 것을 피해 주세요.
3. 제품을 떨어뜨리거나, 무리하게 충격을 가할 경우, LED 색에 영향을 줄 수 있으므로 주의하여 주세요.
4. 부품을 삼키거나, 입에 넣지 않도록 주의하여 주세요.
5. 제품에 강한 충격을 가하거나, 물에 닿으면 고장의 원인이 될 수 있으니 주의하여 주세요.
6. 제품에 손상이 있을 시, 사용을 중단하시고, 제품을 개조하거나, 분해하지 마세요.
7. 배터리 수명이 다 되었을 경우, 새로운 배터리를 사용하여 주시고, 장시간 미 사용시, 배터리를 분리하여 주세요.
8. 수명이 다 된 배터리는 영/유아의 손이 닿지 않는 곳에 보관하거나, 지정된 폐기장소에 버려 주세요.
9. 반드시 정품 AAA배터리를 사용하시고, 배터리 삽입 시, +, ㅡ를 꼭 확인하세요, 그렇지 않을 경우 제품 손상, 화상 및 화재의 위험이 있습니다.
10. 본 제품은 무선 운용 중 혼선의 가능성이 있습니다.

품질 보증서

1. 본 제품은 엄밀한 품질 관리 및 검사 과정을 거쳐 만들어진 제품입니다.
2. 소비자의 정상적인 사용 상태에서 고장이 발생했을 경우, 보증기간 동안 무상수리를 해 드립니다.
3. 수리를 의뢰하실 때에는 반드시 이 보증서를 제시하시기 바랍니다.
4. 보증서는 대한민국 내에서만 유효합니다.
5. 보증 기간은 구매일로부터 3개월입니다.

* 소비자의 부주의 및 과실로 인한 고장은 A/S대상에서 제외됩니다.

유상 A/S처리 규정

1. 보증 기간이 경과된 경우
2. 사용상의 과실, 부주의로 인한 고장, 파손이 발생한 경우
3. 홍수, 화재, 지진 등 천재지변으로 인해 고장이 발생한 경우
4. 사용 중 발생한 흠집 등으로 케이스 교체를 원하는 경우
5. 정식 A/S센터 외 다른 A/S센터를 이용하거나 제품을 임의로 분해, 수리 또는 개조한 경우

제품 설명서

NAME | ENHYPEN OFFICIAL LIGHT STICK VER.1
MODEL | EN- OFFICIAL 0320IP
SIZE | 218 x 96 x 90 mm
WEIGHT | 148g (배터리 제외)
MATERIAL | PC
COMPONENTS | 응원봉, 더스트 백, 스트랩, 제품 설명서, 포토 카드
POWER | 알카라인 AAA건전지 3개 (권장), DC 4.5V⎓
CERTIFICATIONS (KC) | R-R-Lnz-EN-0320IP
OPERATION TEMPERATURE | 0°C to 50°C (32°F to 122°F)
제조사 | (주) 파트론
제조국가 | 대한민국

A/S 주소, 연락처 및 이메일 | Big Hit IP Co., Ltd | 02-3444-0150 | light-stick.support@bighitcorp.com
품질 보증기간 | 구매일로부터 3개월 (영수증 인증 필요)

QUICK START GUIDE





How to insert and replace the battery

1. Turn the cap at the bottom of the product handle to take out the battery housing inside.
2. Connect 3 batteries (AAA) into the housing as shown in the picture.
   (When connecting the battery, please check anode and cathode,
   the spring part of the housing is the cathode of the battery,
   the part without spring is anode)
3. Insert the battery housing combined with the battery in
   the direction of the arrow marked on the handle of the product,
   and close the bottom cap.

How to use

1, Power On/Off = Press Button ① for 1.5 seconds.
2. Bluetooth mode On/Off = Press buttons ① and ② simultaneously for 1.5 seconds.
3. BASIC mode [ENT. mode]
   - Short press Button ① to change LED color
   - Long press Button ① to turn the terminal off
   - Short press of Button ② to change the LED blinking speed (Slow>Normal>Quick)
   - Long press Button ② to switch to mixed color mode
4. AURORA mode
   - Short press Button ① to change LED color
   - Long press Button ① to turn the terminal off
   - Short press of Button ② to change the LED blinking speed (Normal>Quick)
   - Long press Button ② to switch to Basic mode

* For wireless control of this product in the venue, match ticket information through pairing of a smartphone and a light stick.
* The connection between the smartphone and Bluetooth is wireless, so the connection may be disconnected intermittently during use.
* If you cannot pair your smartphone with the light stick, please contact HELP DESK (pairing booth).
* Bluetooth only supports BLUETOOTH 4.2 or higher

Precautions for handling

1. Avoid hot and humid places and keep it at room temperature when storing.
2. Avoid looking directly at the LED light up close.
3. Please note that dropping the product or applying an excessive impact may affect the color of the LED.
4. Be careful not to swallow the parts or put them in your mouth.
5. Be careful as it may cause malfunction if a strong impact is applied to the product or if it meets water.
6. If the product is damaged, stop using it and do not modify or disassemble the product.
7. When the battery life is over, use a new battery, and when not in use for a long time, remove the battery.
8. Keep the used batteries out of reach of infants and children or dispose of them at a designated disposal site.
9. Use genuine AAA batteries and be sure to check anode and cathode when inserting the battery, otherwise there is a risk of product damage, burns and fire.
10. This product may cause confusion during wireless operation.

Product warranty

1. This product is manufactured through a strict quality control and inspection process.
2. In the event of a breakdown during the normal use of the consumer, we provide free repair during the warranty period.
3. When requesting repairs, be sure to present this warranty.
4. The warranty is valid only in Korea.
5. The warranty period is 3 months from the date of purchase.

* Failures caused by consumer negligence is excluded from A/S.

Paid A/S processing regulations

1. When the warranty period has elapsed.
2. In case of failure or damage due to excessive use or carelessness.
3. In case of failure due to natural disasters such as flood, fire, earthquake, etc.
4. If you want to replace the case due to scratches that occurred during use.
5. In case of using an A/S center other than the official A/S center or disassembling, repairing, or remodeling the product at will.

Product documentation

NAME | ENHYPEN OFFICIAL LIGHT STICK VER.1
MODEL | EN- OFFICIAL 0320IP
SIZE | 218 x 96 x 90 mm
WEIGHT | 148g (Excluding battery)
MATERIAL | PC
COMPONENTS | Cheering stick, dust bag, strap, product manual, photo card
POWER | 3 alkaline AAA batteries (recommended), DC 4.5V⎓
CERTIFICATIONS (FCC) | 2AVJVEN-0320IP
OPERATION TEMPERATURE | 0°C to 50°C (32°F to 122°F)
MANUFACTURER | PARTRON Co.,Ltd
COUNTRY OF MANUFACTURE | KOREA

A/S address, contact information and email | Big Hit IP Co., Ltd | 02-3444-0150 | light-stick.support@bighitcorp.com
Warranty Period | 3 months from the date of purchase (receipt certification required)

Bluetooth™

FCC warning

Federal Communications Commission Statement

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by doing one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC exposure compliance requirement, please follow operation instruction as documented in this manual.

NCC warning

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

95

95

95