



RIG 800 PRO HS


1 FIT / AJUSTEMENT



2 CHARGE / CHARGER




CHARGE / CHARGER




OR

3 CHARGE INDICATION


INDICATION DE CHARGE



4 CONNECT / CONNEXION



CONNECT / CONNEXION




To adjust system audio settings,
check your console's user guide.

RIG 800 PRO HS


QUICK START GUIDE

GUIDE DE DÉMARRAGE RAPIDE




Headset model: RIG800PRO-HS, Dongle model: RIG 800PRO-HS.
100-1346-99 06.21
TW D1846598; patents pending.
Patents: US D766,206; D800,092; CN ZL201630297792.3; EM 002814079; 003494897;
Inc. All rights reserved. All other trademarks are the property of their respective owners.
"PlayStation", "PS5" and "PS4" are registered trademarks of Sony Interactive Entertainment
other countries. All trademarks are the property of their respective owners.
©2021 NACON. NACON and RIG are trademarks of NACON, registered in the US and



5 POWER / ALIMENTATION



6 DISCONNECT / DÉCONNEXION



MUTE / MODE DISCRÉTION



SOUND / SON
PS4™ PS5™ PC