



RIG 800 PRO HX


1 FIT / AJUSTEMENT



2 CHARGE / CHARGER




CHARGE / CHARGER




OR


3 CHARGE INDICATION INDICATION DE CHARGE



4 CONNECT / CONNEXION



CONNECT / CONNEXION



OR


To adjust system audio settings,
check your console's user guide.

RIG 800 PRO HX


QUICK START GUIDE

GUIDE DE DÉMARRAGE RAPIDE

5 POWER / ALIMENTATION



6 DISCONNECT / DÉCONNEXION




MUTE / MODE DISCRÉTION




MIC MONITORING

Mic monitor level
Short press:
Off
Medium
High



SOUND / SON

XBOX



©2021 NACON. NACON and RIG are trademarks of NACON. Registered in the US and other countries. All trademarks are the property of their respective owners.
Headset model: RIG800PRO-HX, Dongle model: RIG800PRO-HX
Patents: US D766,206; D800,091; CN ZL201630297847.0;
EM 002814079; 003494863; TW D184697; patents pending.
Recyclable where facilities exist.

100-1345-99 06.21