

Packed Party
SLEIGH THE TUNES!
BLUETOOTH® SING-ALONG MICROPHONE
PKMC140RD



BUTTON FUNCTIONS

 **+** **-**
Press to adjust volume*
Press and hold to turn ON/OFF

VOICE
Press to switch between Reindeer,
Santa, or auto-tune voice
changing effects

SONG
Press to pause/play songs during playback
Press twice to skip to the next song**
Press and hold to turn on Bluetooth®

*Volume level increases, then decreases
**Microphone's preloaded songs will not
play when in Bluetooth® mode

VOICE EFFECTS




Press the VOICE button to switch between
Reindeer, Santa or auto-tune effects

BLUETOOTH® CONNECTION



1. Press and hold the SONG button to turn on Bluetooth® mode.
2. Enter the Bluetooth® settings on your Bluetooth® device, and search for "Rudolph Mic". Tap to connect.

CHARGING




Use the included micro USB cable to
charge the microphone.

The charging port is located under the head of the
microphone.

AUDIO RECORDING

Using the included micro USB to 3.5mm AUX
cable, connect the microphone to your
mobile device.



On your mobile device, open a song
recording app of your choice and start
recording. Select the song you wish to record
and play it through the microphone. Once
finished, go back to your song recording app
and stop recording.

NOTE: The audio recording function is compatible with
Android™ devices. Apple™ users need to use an Apple™
compatible cable or adapter for recording (sold
separately).

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is
subject to the following two conditions: (1) This device may not
cause harmful interference, and (2) this device must accept any
interference received, including interference that may cause
undesired operation. Any changes or modifications not expressly
approved by the party responsible for compliance could void the
user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the
limits for a Class B digital device, pursuant to part 15 of the FCC
Rules. These limits are designed to provide reasonable protection
against harmful interference in a residential installation. This
equipment generates, uses and can radiate radio frequency energy
and, if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However,
there is no guarantee that interference will not occur in a particular
installation. If this equipment does cause harmful interference to
radio or television reception, which can be determined by turning
the equipment off and on, the user is encouraged to try to correct
the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from
that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure
requirement. The device can be used in portable exposure
condition without restriction.

The Bluetooth® trademarks—including the BLUETOOTH word
mark, the figure mark (the runic "B" and oval design), and the
combination mark (Bluetooth word mark and design)—are
owned by the Bluetooth SIG. USB is used to solely describe the
compatibility of our technology and in no way is intended to
infringe on any intellectual property rights of any respective
protected marks.

Packed Party®

FOLLOW THE PARTY
@PACKEDPARTY

LIFE'S A PARTY
WHEN YOU MAKE IT ONE!®
WWW.PACKEDPARTY.COM



2231B | FCC ID: 2AVRVPKMC140RD