

65MM

80MM

TWINS  
Pairable Dual Wireless Speakers



Item NO: TPS-6/1754

INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY  
AND RETAIN FOR FUTURE USE

1

Getting Started

- Remove the speaker from the box.
- Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

- Twins - Pair of Portable Ture Wireless Speaker
- USB rechargeable cable x 2
- Auxiliary cable x 2
- Instruction Manual

Key Features

- Twins - Pair of Portable Ture Wireless Speaker
- Wirelessly connect both speakers for true right & left stereo play back
- Stream music wirelessly and enjoy music from both left & right speakers
- Words independently or together as paired true wireless speaker
- Delivers rich sound with bass
- Bluetooth transmission range up to 33 feet

SAFETY INSTRUCTIONS

- Keep the speaker away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the speaker if it has been exposed to water, moisture or any other liquids to prevent against electric

2

shock, explosion and/or injury to yourself and damage to the speaker.

- Do not use the speaker if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the speaker with wet hands.
- Do not put objects into any of the openings.
- Keep the speaker free from dust, lint etc.
- Do not use this speaker for anything other than its intended use.
- Keep the speaker out of reach of children.
- This appliance is not a toy.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat place, such as sunshine, fire or the like.

Description of Parts

3



|   |                |
|---|----------------|
| 1 | Auxiliary Port |
| 2 | Charging Port  |
| 3 | LED Indicator  |
| 4 | ON/OFF Switch  |

INSTRUCTIONS FOR USE

Charging the speaker

The speaker has built-in rechargeable battery. When the battery is drained out, speaker would turn OFF automatically. Please recharge the battery every time it drains out.

Plug the Micro USB end of the included USB rechargeable cable into the charging port. Plug the other end into a USB port on your computer or other devices made for USB charging. Red LED Light illuminates indicating that the device is being charged.

4

It takes 3-5 hours to fully charge the speaker. Once the speaker is fully charged, LED Light would turn OFF.

Turning ON/OFF the Speaker –

Before Turning ON the speaker, please ensure that it is fully charged. Slide the ON/OFF Switch to ON or OFF position to turn on or off the unit.

TWS pairing use –

TWS stands for True Wireless Stereo. This feature enables 2 separate speakers to play music from one source at the same time, without any wires connecting both speakers.

1. Make sure both the speakers are turned on and not paired with any Bluetooth device. An indication tone would be heard from each speaker and the LED flashes blue rapidly. After few seconds, another indication tone would be heard if they pair together automatically. The LED light indicator on one speaker will flash blue rapidly, and the LED light indicator on the other speaker will stay on.
2. Activate the Bluetooth function on your source device (Mobile Phone, Tablet etc). Please refer to manufacturer's instructions for instructions on enabling Bluetooth on your device.
3. Search for available Bluetooth devices and you would find "SL TWINS" – Pair it with this device.

5

4. If required, enter the password "0000" to pair with the device.
5. Once paired successfully, another indication tone would be heard and the LED light indicator on both units will stay blue.
6. You can now stream wireless music on your speakers through your source device.

**Note:** Other functions including volume increase/decrease, play/pause, next/previous track, you will need to control through your source device.

Play music through "Auxiliary" mode

- Turn ON any one speaker.
- Insert one end of the Auxiliary cable (included) into the Auxiliary port, and an indication tone would be heard. Insert the other end to the audio device (such as phone / MP3 Player / computer / tablet / .....etc.).
- Select your favourite song at the source device to play.

**Note:** Other functions including volume increase/decrease, play/pause, next/previous track, you will need to control through your source device.

Tips!!

When the speaker is not in use, turn it OFF in order to save the battery power.

Specifications –

Bluetooth version: 5.0  
Unit size: Dia. 3.1"x3.8" H

6

Unit weight (each speaker): ~8 oz  
Power input: DC 5V  
Charging time: 3-5 hours  
Play time: 3-4 hours (maximum volume)  
Bluetooth range: 33 feet  
Built-In Rechargeable Battery (each speaker): 3.7V 1200mAh  
(Note: Battery life & charging time may vary based on usage, types of devices connected & wireless distance.)

Troubleshooting

| Problem          | Possible Cause                                                                                                                     | Solution                                                                                        |
|------------------|------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| Low sound level  | Source (Tablet, Mobile Phone, Laptop, etc.) volume too low.<br>Battery dead                                                        | Adjust source volume.<br>Charge Battery.                                                        |
| Sound distorted  | Battery nearly dead                                                                                                                | Charge Battery.                                                                                 |
| No sound at all. | Source (Tablet, Mobile Phone, Laptop.) turned off.<br>Speaker turned off.<br>Volume turned down source.<br>Media paused on source. | Turn the source on.<br>Turn the speaker on.<br>Adjust volume source.<br>Play media from source. |

7

Care and maintenance

Read the following recommendations before using the Bluetooth Speaker. Following these you will be able to enjoy the product for many years.

- Do not expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the unit.
- Do not expose the unit to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the unit in fire as it will result in an explosion.
- Don't expose the unit to contact with sharp objects as this will cause scratches and damage.
- Don't let the unit fall down onto the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the unit as it may get damaged if you are not professional.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

**NOTE:** This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable

8

protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the product and receiver.  
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any

9

other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

**WARRANTY DURATION:** All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

**WARRANTY COVERAGE:** This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in USA and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

**WARRANTY DISCLAIMERS:** This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no

10

circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

**WARRANTY PERFORMANCE:** During the above 90-day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90-day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

**SERVICE AND REPAIR:** If service is required for this product, you should first contact Midwest Trading Group Customer Service at [info@mtradinggroup.com](mailto:info@mtradinggroup.com) or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

**NOTE:** Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

RF Exposure Requirement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

11