

User Manual

(Note: please check whether the above accessories are complete after unpecking. If not, please contact the dealer.)

The Status Bar will turn into an obvious low-power state as well. During the low-power state, some functions of the device may not work properly. When the battery state is below the 7.0C, the device will automatically shut down to protect the data. Restarting the device will need sufficient charging.

• Make up the device by short pressing on the Power button.

Home screen

The home screen of the device is the entrance to the core functions: Transfers, Recording, Conversations, Buttons.

Voice recognition:

- Long press the A/B Button on the device to trigger the Speech Recognition mode (A Button for the language on the left side, B Button for the language on the right side).
- After releasing the A/B Button, the speech will

- After releasing the A/B button, the speech will be automatically recognized and translated to the specified target language. The translation starts automatically if voice broadcast is enabled in the application settings.
- The list presents previous voice translation results. Swipe up and down to review when there are many records.

- Tap the red 'stop' icon at the bottom right to prompt for confirmation.
- Tap "OK" to stop and automatically save the recording file.
- Tap the thumbnail icon at the bottom right to view the last recording.

- Tap the red 'stop' icon at the bottom right to prompt the confirmation.
- Tap "OK" to stop and automatically save the recording file.
- Tap the three-dots icon at the top right to view the list of saved recording files.

- Tap **OK** to complete the invitation.

Voice recognition:

- Long press on the **Alt** Buttons in the conversation page to enter voice recognition mode.
- Speak in the language that you have set in the system as spoken input.

- Long press on the A/B Buttons in the conversation page to enter voice recognition mode
 - Speak in the language that you have set in the system as spoken input.
 - When you finish, then release the A/B Buttons, the translation is done automatically.

Instant camera translation

Language selection:

- Tap the button at the top of the instant camera translation page and select "Select language" option.

Language selection:

- Tap the button at the top of the instant camera translation page and select "Select language" option.
- Tap to choose the source language / target language needed.

- Tap the "Favorites" option, with a notice, the specific transaction result is marked as favorite.

- Long pressing on the specific item in the list of translated results will prompt with a dialog.
- Tap the "Favorites" option, with a notice, the specific translation result is marked as favorite.
- Short click on any speed, the pronunciation starts automatically, to show the record, tap and hold it.

When there is a new upgradeable version, the device will check for it when the user switches language, reboots the device, or 24 hours after the previous check. GoDaddy will enable network auto-updates for the update.

If you have any issues with the GoDaddy 1, please go to [GoDaddy.com/support](#).

If you have any issues with the DaDaCheck 1, please give us the version number so we can help you fix the problem.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.