


AI NOTE

使用手册 INSTRUCTIONS

中文----- 1-7
English-----8-14

一、按键说明



序号	名称	序号	名称
①	显示屏	⑤	Type-C 接口
②	CALL/NOTE 模式切换推扭	⑥	麦克风孔
③	电源键	⑦	磁吸吸附
④	麦克风孔	⑧	复位孔

-1-

二、使用说明

1. 扫码或应用商店搜索“悦会 / Vadiutor” APP，下载安装 APP 并注册登录；




2. 按界面提示注册，创建一个账户，该APP支持手机号码和邮箱注册。



-2-

3.绑定设备，录音卡电源键长按 3S 开机；开机状态下，进入 APP，打开蓝牙和位置信息，点击文件一连接，搜索设备并连接。




三、APP 操作说明


开始录音/保存录音

- 1.点击界面下方录音图标
- 2.点击界面下方开始录音按钮
- 3.点击右下角保存按钮

-3-



录音播放及转写
点击进入对应文件，点击三角形按钮进行播放，点击正下方立即转写，可选择模版进行转写总结。



-4-


四、操作说明

开机状态

长按电源键 3 秒机器开机
蓝牙未连接 三分钟无操作进入关机

关机状态

长按电源键 3 秒机器关机




CALL 模式（通话录音模式）

非录音状态时，推扭上推是
CALL 模式



NOTE 模式（普通录音模式）

非录音状态时，推扭下推是
NOTE 模式



待机状态（10s 熄屏）

黑屏时短按电源键亮屏



-5-


开始录音

双击电源键，开始录音，显示屏出现"Rec..."表示开始录音



结束录音

录音状态下，双击电源键，显示屏恢复默认状态表示保存且结束录音



暂停录音和继续录音

在录音状态，单击电源键机器出现" paused"表示暂停录音。再单击电源键出现"Rec..."开启继续录音。



-6-

查看 SN 号

三击电源键可查看设备 SN 号




五、安全警告及使用

- 1.在第一次使用产品时，需使用标准的 5V/2A 的充电器给产品充电。
- 2.在多人说话且噪音很大环境下会影响录音效果。
- 3.保存产品因放在干燥通风的环境下(请勿在高温环境中使用及存放)该产品组内包含有机易燃物，如果不正确使用产品，会发生破裂，漏液，过热等，使产品永久地损坏。
- 4.不要短路电源，禁止使用不正规的充电器为本产品充电。
- 5.不要在靠近在有火或者火炉或者温度高于 60°C 的地方使用产品。因为高温会融解塑胶壳及对内部电池造成危害。
- 6.如果把产品放置在水里面，产品的安全保护参数及指标会损坏，从而使该产品不能正常使用，甚至会因此发生过热而引发火灾及爆炸。
- 7.不能使用重物或者其他的物体挤压产品使其变形。
- 8.如果使用非标准的充电器，或者修改指定的充电器参数，会使电池发生过热燃烧和爆炸。
- 9.如果一旦发现产品存在隐患，或者其它的问题，更立即终止使用。

-7-

1. Button Guide



No.	Name	No.	Name
①	Display Screen	⑤	Type-C Port
②	CALL/NOTE Mode Switch	⑥	Mic Hole
③	Power Button	⑦	Magnetic Mount
④	Mic Hole	⑧	Reset Hole


-8-

2. Instructions for Use

1.Scan the QR code or search for the APP named Vadiutor in app stores to download, install, register and log in to the APP.




2.Complete registration as prompted on the interface to create an account.Register with phone number or email.



-9-


3.Device Binding Press and hold the power button of the recording card for 3 seconds to power on. After power-on, launch the APP, enable Bluetooth and Location Services, tap File 1 for connection to search and pair with the device.



3. APP Operation Instructions


- 1.Tap the recording icon at the bottom of the screen.
- 2.Tap the Start Recording button at the bottom of the screen.
- 3.Tap the Save button in the lower right corner.

-10-



Recording Playback & Transcription

Tap to open the target file. Tap the triangular play button to start playback. Tap the Instant Transcribe button at the bottom, then select a template for transcription and summary.



-11-

4. Operation Instructions

Powered-on Status

Hold the power key for 3 seconds to restart the device. If Bluetooth remains disconnected, the unit will auto power off after 3 minutes of inactivity.




Powered-off Status

Hold the power key for 3 seconds to power off the device.


CALL Mode

Slide the toggle switch upward to enter CALL Mode when not in recording status.




NOTE Mode

Slide the toggle switch downward to enter NOTE Mode when not in recording.



Standby Mode (Screen turns off after 10 seconds)

Short press the power button to wake the screen when it is black/off.



-12-


Start Recording

Double-tap the power button to start recording. The display shows "Rec..." to indicate recording is in progress.




Stop Recording

Double-tap the power button during recording. The display returns to its default interface, indicating the recording is saved and stopped.



Pause & Resume Recording


While recording, short-press the power button; the screen shows "paused" to indicate recording pause. Press the power button again, and "Rec..." appears to resume recording.



-13-

Check SN Number

Triple-press the power button to view the device SN number.



5. Safety Warnings and Usage

1. When using the product for the first time, charge it with a standard 5V/2A charger.
- 2.In environments with multiple speakers and high noise levels, recording quality may be affected. Store the product in a dry, well-ventilated place (do not use or store in high-temperature environments). This product contains flammable organic materials. Improper use may cause cracking, fluid leakage, overheating, and other damage that could permanently destroy the product.
- 3.Do not short-circuit the power supply and do not use unauthorized chargers to charge this product.
- 4.Do not use the product near open flames, stoves, or in areas with temperatures above 60 °C. High temperatures can melt the plastic casing and damage the internal battery.

-14-

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.