品名：	HW2说明书	**材料**	105g哑粉纸，双面彩色印刷，12P，骑马钉
时间：	2021-2-4	**工艺：**	成品尺寸: 100*140mm
制作：	许结媛		
料号：	SM-EJ-HW2-V1		

英

底面

FCC ID: 2AW9K-HW2

NOTE: This equipment has been tested and found to comply with the limits for Class B digital devices, in alignment with section 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

SM-EJ-HW2-V1

EU | REP
Europe business name: AMZLAB GmbH
Europe business address: Laubenhof 23, 45326 Essen, Germany
Europe phone number: +49 745290066

正面

HW2
Wireless TV Headphones
User Manual



CONTENTS

In the Box — 1
Product Overview — 2
LED Indicators Guide — 3
Turn on/off the Headphones — 3
Charge the Headphones — 3
Connect the Transmitter to TV — 5
FAQs — 7
Warranty — 8
Care and Maintenance — 8
Technical Specifications — 8
Important Safety Instructions — 9

In the Box



Product Overview

Headphones



Charging Dock/Transmitter



LED Indicators Guide

Power on	The power indicator on the right ear cup stays red.
Power off	The power indicator on the right ear cup goes off.
Charging	The charging indicator on the charging dock flashes green.
Fully Charged	The charging indicator on the charging dock stays green.
Connected	The signal indicator on the charging dock stays red, and the signal indicator on the left ear cup stays green.
Disconnected	The signal indicator on the charging dock and the signal indicator on the left ear cup goes off after 5 minutes.

Turn on/off the Headphones

Power on/off: Slide the power switch to "ON" / "OFF".

Charge the Headphones

1. Connect the charging dock to a power source.

2. Place the headphones on the charging dock and make sure the charging contacts on the ear cup match well with the charging pins on the charging dock.
3. Check whether the charging indicator on the charging dock flashes green.



Notes:

- Before charging the headphones for the first time, please remove the insulating sheet from the headphones.
- Fully charge the headphones before the first-time use.
- A complete charging cycle takes 4-5 hours, and the headphones can play approximately 8 hours on a full charge.

Connect the Transmitter to TV

Connect the Transmitter to a TV with RCA Audio Cable



①
Connect the power adapter to the transmitter and plug the mains charger into a power source.



②
Plug the RCA connectors into the RCA inputs on the charging dock and plug the 3.5 audio connector into the audio-out port on your TV.



③
Pick up the headphones, and then the signal indicator on the transmitter stays red.



④
Turn on the headphones.

Connect the Transmitter to a TV with RCA Adapter Cable

①
Connect the power adaptor to the transmitter and plug the mains charger into a power source.



②
Plug the provided RCA adapter cable into the RCA outputs on your TV and the 3.5 audio connector of the RCA audio cable into the audio jack of the adapter cable.



③
Pick up the headphones, and then the signal indicator on the transmitter stays red.



④
Turn on the headphones.

FAQs

Q: No sound comes from headphones, what should I do?

A: Check whether the signal light on the transmitter stays red, if not, please try the following:

- Make sure the charging dock is connected to a power source.
- Make sure the headphones have been turned on.
- ***Do not plug into any ports labeled as "AV IN".***
- If your TV has a 3.5mm audio output, please make sure the 3.5mm audio cable is plugged into the audio-out port behind the TV. ***Do not plug it into any audio-in port behind the TV.***
- If your TV has RCA outputs, please make sure the RCA adapter cable is plugged into RCA output ports behind the TV. ***Do not plug it into any RCA input ports behind the TV.***
- Please make sure that your audio device is turned on and in play mode.
- If connecting the transmitter to a TV with a 3.5mm audio-out port, please do not mute your TV.
- Instead of TV, connect to your phone to test.
- If the steps above did not resolve your issue, contact us for help.

Q: The headphones cannot be connected, what should I do?

A: Check whether the signal light on the left ear cup stays green. If not, please try the following:

- Make sure the transmission distance between the headphones and the transmitter is within 30 meters.
- Slide the channel switch on the charging dock to change a channel, then press the tuning button on the left ear cup to sync channel.

Q: The volume is not loud enough, what should I do?

A: Turn up your TV's volume to the maximum level.

Q: Headphones HW2 cannot get charged, what should I do?

A: Check whether the charging light on the charging dock flashes green, if not, please try the following:

- Make sure the charging dock is connected to a power source.
- Make sure the charging contacts on the ear cup match well with the charging pins on the charging dock. The charging indicator flashes green once charging starts and it stays green when the headphones are fully charged.

Q: How to pair two or more headphones HW2 with one transmitter?

A: After a pair of TV headphones HW2 is successfully paired with the transmitter, turn on the second headphones HW2, and the power indicator on the right earcup stays red, and then the signal indicator on the left earcup stays green, indicating a successful connection.

Warranty

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of a defect, so we are happy to offer a ONE-year hassle-free warranty to all our devices as we continue to make amazing products. Please contact us if you have any questions about our devices.

Care and Maintenance

Only clean this product with a slightly damp, lint-free cloth and do not use aggressive cleaning agents.

Technical Specifications

Frequency Response	20Hz-20KHz
Operating Voltage	Transmitter (8V) Receiver (2.4V)
Transmission Range	Up to 30 meters (open area)
Charging Time	4-5 hours
Operating Time	Approximately 8 hours

Important Safety Instructions

- Use of headphones will impair your ability to hear other sounds. Use caution while using your headphones when you are engaging in any activity that requires your full attention.
- If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product.
- This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy — never allow children to play with this product. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.
- Avoid exposing your product to heat and humidity to protect against damage to the product or injury to you.
- Keep all products, cords, and cables away from operating machinery.
- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact us.
- Do NOT use in areas where there are explosive hazards.
- Do NOT submerge the headphones in water. Do NOT expose the headphones to moving water (e.g., from a faucet, etc.).
- Do NOT wear the headphones while showering or bathing, or when participating in water sports, e.g., swimming, water skiing, surfing, etc.
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the headphones.
- Dispose of the product according to local standards and regulations.
- **Remember:** Always drive safely, avoid distractions and follow local laws!

  Using the headphones while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of the headphones with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws. Use with caution while using your headphones when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the headphones from your ear or turning off your headphones will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.