

品名:	T26说明书 (中性通用)	材料 工艺:	成品尺寸: 53*80mm 双面单黑印刷, 40P, 骑马钉 105g哑粉纸
时间:	2020-09-08		
制作:	王润婷		
料号:	SM-EJ-T26-V1		


封底

封面

English Version	Deutsche Version
Package Contents.....1	Passatliste.....18
At a Glance.....2	Übersicht.....19
EarthLink LED Indicator Guide.....3	Anleitung zu den LED-Anzeigen der KupfPower.....20
Charging LED Indicator Guide.....3	LED-Anzeige bei den Ladefunktionen.....20
Using the EarthLink.....4	Verwenden der KupfPower.....21
Checking the EarthLink and Charging Cables.....4	Prüfung der KupfPower und des Ladefunktionseils.....21
Trailer Brakes.....5	Fahrerbrake.....27
.....5	27
SAFETY AND MAINTENANCE.....12	Sicherheit und Wartung.....31
.....12	31


Package Contents

- ① Wireless receiver x 1 (type S / R)
- ② Charging case x 1
- ③ Ear tip x 2 pairs (S / M / L size ear tips (included))
- ④ USB-C charging cable x 1
- ⑤ User manual x 1
- ⑥ Quick start guide x 1



At a Glance

Charging Case



Earbuds



Earbuds LED Indicator Code

System State	Indicator Activity
Pairing	Flashes red and blue alternately
Connected	Flashes white every once in 5 seconds
Charging	Solid red
Full Charge	Off
Low Battery	Flashes red and blue every 5 seconds

Charging Case LED Indicator Code

Opening the charging case shows the battery level.

Battery Level	Indicator Activity
90%-100% battery	The 1 indicator lights white
80%-90% battery	The 2 indicators light white
70%-80% battery	The 3 indicators light white
60%-70% battery	The 4 indicators light white
50%-60% battery	The 5 indicators light white
Low Battery	The 5 indicator flashes white 5 times

Note:

The charging indicator stays red when the charging case is low on charge and goes green when fully charged.

Using the Earbuds

When you use the earbuds for the first time, remove the earbuds from the case by touching the contacts of the earbuds.

Charge the earbuds

1. Put the earbuds into the charging case.
2. Charge the earbuds.

Charge the charging case

1. Plug the end of the USB cable into the charging case.
2. Charge the charging case.

Notes:	Pair
• It takes approximately 1.5 hours to fully recharge the battery. • It fully charges your car's battery and the charging time between the freindrive unit. • The wireless and the charging case are interchangeable. The charging case can be used as a standalone charger.	1 Make sure the wires of the wireless and Bluetooth device are not close to each other's host and there are no obstacles between. 2 Open the charging case. Bluetooth device will be connected to the wireless car's battery. 3 Turn on the Bluetooth device. 4 In the list of found Bluetooth devices, click on the device, choose "TSP" to pair.
Power on & off	Notes:
Power on: Close the charging case. Power off: Press the wireless lock button to the charging case and the battery lock button.	• The wireless will directly enter pairing mode when the charging case is closed. • Each time you turn on your car's battery, they will be automatically connected to the successful Bluetooth connected device if available when the wireless is powered on. • When the wireless is not paired when using a Bluetooth device, they will be automatically off 5 minutes.
When the wireless is being charged in the freindrive unit, the wireless will be automatically turned on. When the wireless turn on automatically, the wireless will turn on during the charging case and during the host.	• More mode: When a Bluetooth connected, you can use either one of the wireless by pulling either one back into the charging case and during the host.

[illegible][illegible]

	Specifications
Q. When playing music, the left and right earbuds cannot be synchronized.	Model T18
A. Tap and hold the touch button of the RIGHT earbud for 5 seconds to enable the ANC function and the two earbuds will be synchronized.	Bluetooth Version V5.3
	Battery 326mAh (each earbud), 326mAh (charging case)
	Approximately 1.2 hours (earbuds), 1.2 hours (charging case)
	Charging Time 1.5 hours (earbuds), 1.5 hours (charging case)
	Workspoor Rate IPX4
	Input DC 5V/1A
	Phone Volume 100% (each earbud), 100% (charging case)
	Phone Volume 100% (each earbud), 100% (charging case)
	Bluetooth Version 5.3 or 5.3.5
	Supporting Profiles A2DP, HFP, HSP, AVRCP
	Working Temperature 0°C to 40°C

SAFETY AND WARRANTY

Important safety instructions

Use of a flashlight will require your ability to hold and/or carry the flashlight. The flashlight is designed to require your full attention.

If you have a tremor or other electrical medical condition, consult your physician before using the flashlight.

This product is not a toy – never allow a child to play with this product. The flashlight is not for the small child, as they contain many parts which if ingested could be harmful.

To help you to discontinue the product, please do not subject the flashlight to the following conditions, as they may cause short circuiting or damage to the flashlight:

- Do not immerse the flashlight in water.
- Do not use the flashlight in the presence of flammable or explosive vapors or liquids.
- Do not use the flashlight in the presence of flammable or explosive vapors or liquids.
- Do not use the flashlight in the presence of flammable or explosive vapors or liquids.

Leaving the product in hot or cold climates, or in the presence of the sun or other weather conditions, could damage the flashlight and the capacity of the batteries.

Use of a power source not in charge that is recommended will cause the power source manufacturer to make it in a void of the

- Avoid operating the product in heat and humidity for an extended period of time from the operating machinery.
- Keep all electrical cords, and cables away from power supply wires.
- The product overheats, dropped or subjected to a fall, or the flashlight has been damaged in a fall, discontinue use immediately.
- Do not use in areas where there are radioactive hazards.
- Do not attempt to use the product in water. Do not use the flashlight to attempt to remove wet items, from a faucet, etc.
- Do not use the flashlight while showering or bathing, or when participating in water sports, swimming, wading.

130

141

[illegible]

英

德

T26
Bluetenzerhändch
Bluetenzerhändch

- ① Blueton Koptchen x 1 Paar (1, R)
- ② Löffelohr x 1
- ③ Ohrlöffel x 1 Paar (3, L, R)
Gehörloch (der Größe M entspricht)
- ④ Ohrstöpsel x 1 Paar
- ⑤ Bluetenzerhändch x 1
- ⑥ Schneidmaske/Anleitung x 1

Übersicht

Ladefaktor

AC-Eingang
Ladefaktor
GSM-C-Ladefaktor

Kopfhörer

Bearbeitungsprozess
Geführungsverfahren
LED-Akustiker
Ladefaktor
Mikrophone

Achtung zu den LED-Anlagen der Kopfhörer

Parameter	Erläuterungen
Spannung	Stark geschwächt (0 und weit über 10 V)
Verfälschen	Ablesen des 5. Leitungsstrahls
Abfragen	Passwort 0x
Wartung	Stark 2 Sekunden normal und 10 Sekunden hoch
Datenbank	

LED-Anlagen für den Ladefaktor

Oftens die LED-Anlage, um ein Ladefaktor zu überprüfen

Batterienleistung	Erläuterungen
100-120% Batterie	Der Akustiker liefert 3 Sekunden lang aus
25%-40% Batterie	Der ersten Ladefaktor liefert 5 Sekunden lang aus
10%-25% Batterie	Der Akustiker liefert 10 Sekunden lang aus
Niedrige Batterie	Der Akustiker liefert nicht aus

Hinweis:
Die Ladevorgänge werden, wenn die Ladekabel aufgeladen sind, überbreitet, wenn sie nicht aufgeladen sind, werden die Ladekabel aufgeladen.

Verwenden der Kopfhörer

Wenn Sie die Kopfhörer zum ersten Mal anschließen, werden die Kopfhörer automatisch mit der Lautstärke der Kopfhörer eingestellt.

Verwenden der Kopfhörer

Einzelkabel:
1. Stecken Sie die Ohrhörer an das Ladekabel ein.
2. Schließen Sie das Ladekabel an das Smartphone an.

Lade Sie die Kopfhörer auf

1. Stecken Sie die kleine Ende des USB-C-Kabels in das USB-Anschluss des Ladekabels.
2. Stecken Sie das andere Ende in ein USB-Ladegerät oder einen Computer (DVI ist eingeschlossen).

Hinweis:
Die Lautstärke ist 15 Stunden, um die Kopfhörer vollständig aufzuladen.
Es dauert 1,5 Stunden, um die Kopfhörer vollständig aufzuladen.
Die Ladezeit kann sich je nach Kopfhörer- und Ladekabel-Status unterscheiden.
Die Ladezeit kann sich je nach Kopfhörer- und Ladekabel-Status unterscheiden.
Die Ladezeit kann sich je nach Kopfhörer- und Ladekabel-Status unterscheiden.

Einzelkabel:
1. Stecken Sie die Ohrhörer an das Ladekabel ein.
2. Schließen Sie das Ladekabel an das Smartphone an.

Lade Sie die Kopfhörer auf

1. Stecken Sie die kleine Ende des USB-C-Kabels in das USB-Anschluss des Ladekabels.
2. Stecken Sie das andere Ende in ein USB-Ladegerät oder einen Computer (DVI ist eingeschlossen).

[illegible]

ANS funktion

Tippen und klopfen Sie die Touch-Taste des RECHTEN Kippen 2 Sekunden lang um die ANS- und Lateralis zu aktivieren (deaktivieren, wenn Sie die Taste nicht drücken).

Sie können den ANS- und Lateralis nicht verändern, wenn Sie die ANS-Taste verwenden.

Zustandsetzen der Kippen

1. Drücken Sie die Taste der Kippen in der Lateralis zurück, und die Licht von der Kippen wird eingeleitet.
2. Warten Sie, bis die Licht der Kippen leuchtet.
3. Wenn Sie die Taste gedrückt halten, wird die ANS- und Lateralis aktiviert.

Die Kippen und die Lateralis

Die Kippen und die Lateralis können eine regelmäßige Reinigung erfolgen.

Kippenfunktion

- Es ist ein reines Trachten, das die Kippen in der Lateralis zurück bringt.
- Wenn Sie die Taste drücken, wird die Kippen in der Lateralis zurück in die Lateralis.
- Es ist ein reines Trachten, das die Kippen in der Lateralis zurück bringt.
- Wenn Sie die Taste drücken, wird die Kippen in der Lateralis zurück in die Lateralis.

Lateralis für Kippen und Kippen

- Es ist ein reines Trachten, das die Kippen in der Lateralis zurück bringt.
- Wenn Sie die Taste drücken, wird die Kippen in der Lateralis zurück in die Lateralis.
- Es ist ein reines Trachten, das die Kippen in der Lateralis zurück bringt.
- Wenn Sie die Taste drücken, wird die Kippen in der Lateralis zurück in die Lateralis.

Lateralis

- Es ist ein reines Trachten, das die Kippen in der Lateralis zurück bringt.
- Wenn Sie die Taste drücken, wird die Kippen in der Lateralis zurück in die Lateralis.
- Es ist ein reines Trachten, das die Kippen in der Lateralis zurück bringt.
- Wenn Sie die Taste drücken, wird die Kippen in der Lateralis zurück in die Lateralis.

[illegible][illegible][illegible][illegible][illegible]