

User Manual



Cautions

To prevent fire, electric shock, and damage to the product, keep it away from rain, moisture, or liquids. vase or Do not place other water bottles on top of the player.

Do not place the product in a bookshelf, cabinet, or other confined space for good ventilation. To prevent fire or electric shock due to overheating of the product, provide good ventilation. Keep lit candles and other lit subjects away from the player. Do not open the case of the product. Only experts can do this.

Product cleaning

Unplug the power cord before cleaning the product. Use a slightly damp cloth instead of liquid detergent to clean the product. Do not use solvents such as gases as they can damage the case of the product.

Moisture management

Keep the product away from humid places such as basements. Moisture condensation may damage the product. In this case, turn on the product and the heat of the product may cause moisture.

About User Manual

If necessary, read the user manual carefully and keep the manual in a safe place. Illustrations in this user's manual may differ from those shown on the screen due to differences in firmware.

What's in the box

Item	Count
Product	1
User manual	1



Name	Mstick2
Model	MG-S02
OS	Android 9
CPU	ARM big.LITTLE A73/A53 Hexa core
RAM	4GB LPDDR4
Storage	64GB eMMC
Connectivity	Wi-Fi 2.4G+5GHz
Power	DC 5V / 5W
Operating Temp.	0°C ~ 60°C
Dimensions	1.38" x 4.09" x 0.59" (35 x 04 x 15mm)
Weight	1.8 ounces (50gram)

Connection

PC connection


1. Connect the product to your PC.
2. Run the viewer app on your PC.

Start




Wi-Fi settings

Click the "Setup" button, click "Wi-Fi" and click Wi-Fi in the upper right corner.




Install the app

Go to AppInstaller and press OK to enter. You can install software with this AppInstaller feature. First, download the software of your choice. Click OK to install the desired software. After installation is complete. The software icon is displayed in the application menu.




My App.

Go to My App and press OK to enter.
You will see the app icons.



Storage and reset

Go to "Storage and Reset" and press OK to enter.



How to solve the problem

Warning

Under no circumstances should you attempt to repair the Android dongle yourself. Warranty will be void. To reduce the risk of electric shock, do not open the case. In the event of a product malfunction, first check the items listed below before sending the product in for repair. If you cannot solve the problem by following the hints, please contact your dealer for help.

Problem	Solution
No power	- Check if the USB port is supplying enough power
No sound or distortion	- Try adjusting the volume
	- Make sure the speakers are connected correctly.
No sound while playing a movie	- The audio codec may not be supported by android dongle. You can change to supported audio when playing notes.
	- Check the volume.
When the USB flash drive is slow	- It takes a long time to read a large file or a high-resolution USB flash drive or display it on a TV screen

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.