




BLUETOOTH IRRIGATION WATERING CONTROLLER

USER MANUAL

TTV102B



WEB: www.rainpointus.com

Email: service@rainpointus.com

Free Hotline (US): 833 3815659

Catalog

i. Product Overview

1. Product Appearance
2. Product Specifications

ii. Main Functions

iii. Installations

1. Connection and Basic Information
2. Version Upgrade
3. Manual Operation
4. Weather Delay
5. Plans and Settings
6. Irrigation History


iv. Tips for Operation

v. Warranty & Warnings

vi. Customer Support

Product Overview

1. Product Appearance



2. Product Specifications

Working Pressure	0.5bar-8bar (7.25 psi-116 psi)
Flow Rate	5L/Min-35L/Min
Working Temperature	3°C-50 °C (37.4 °F-122 °F)
Waterproof	IP54
Power By	3 AAA alkaline batteries (not included)
Inlet	NH(US) for 3/4" faucet / hose BSP(EU) for 1" or 3/4" faucet / hose
Outlet	For 3/4" standard garden hose

Main Functions

- Set and check irrigation schedule through smart phone APP, connecting with Bluetooth
- Manually ON/OFF the water timer
- With 2 schedule types: Normal Schedule and Cycle & Soak
- Weather delay 24/48/72 hours
- Irrigation history track to avoid operation error
- Low power indicator
- Built-in filter

Installations

1、 Connection and Basic Information




- 1 Search for RainPoint on Google Play or App Store or scan the QR code to download the RainPoint APP. Follow the prompts to register a RainPoint account or log in with an existing account.
- 2 Insert 3*AAA batteries first, then press and hold the rubber button until the blue LED light rapid blink, which means the device is ready for connection.



- 3 Please hold the button on the timer for 6 seconds to ensure that the blue light flashes quickly. Select **"Add Device"** to start connection and then find **"Bluetooth Smart"** in the series of **"Smart Irrigation"**. Turn on Bluetooth on your phone. Then, confirm the prompt at the bottom and click **"Next"** to start the device search.



- 4 Press the “+” button on the right of the found device and tap the “**Next**” button after connection finished.



- 5 Press “**Done**” for final confirmation after device is added successfully.



- 6 After connected, the paired devices will show on the Home page. Click the Bluetooth Water Timer and get into main page of the device.



- 7 The following information is shown on the page: **Weekdays**, **Battery status**, **Device status**, **Weather Information**, **Irrigation Duration**, **Last Run Time**, **Next Run Time**.

- 8] At the bottom, there is an operating panel with several options: **Manual button, Weather Delay, Schedule Setting, Irrigation History.**



-  Manual Button for instant watering need.
-  Weather Delay for 24/48/72hours.
-  Schedule Setting with normal schedule and cycle & soak schedule for options.
-  Irrigation history for irrigation track and avoid false operation.



- 9] Press the button on the top right  corner to enter device information page.

2、Version Upgrade

- 1 Enter the timer app interface, if there is a version update, the system will automatically push the update version notification
- 2 Click "Update Now" to enter the update version interface. The version number of this update will be displayed here. Please click "Update" again.



- ③ When upgrading, please do not exit the upgrade page, keep the Bluetooth on, and the distance between the phone and the device is not too far.
- ④ The progress bar can check the update progress.
- ⑤ If the device has been upgraded to the latest version, the product information page will display "No update available".



3、Manual Operation


Manual mode: Click the "▶" to manually turn ON the water timer to start watering. The default time is 10 mins. Click the "||" to manually turn off water timer.

Tap the central circle to set manual watering time, from 1 min to 24 hours.




4、Weather Delay

Tap the **“Weather Delay”** to enable the rain delay function. The weather delay can set with **24H, 48H, 72H and closed delay**.



5、Schedule and Settings

5.1 Schedule Type



On the schedule page, after select  button, there are two types for selection: Normal type and Cycle & Soak type.

Normal Schedule: means device watering at a specific time.

Cycle & Soak: means the device will run the watering schedule repeatedly in this period.

5.2 Schedule Settings

Click and choose the schedule type you need and confirm the watering start time, duration, weekdays to water, and save the all settings.

The Soak & Cycle type have different setting options. It needs to set the start time, end time of irrigation, the cycle duration and soak duration.

Remark

- The minimum period cannot be greater than the total time period
- There will be time conflict notice when the time schedules overlap, causing plans fail of setting.

Add Timer
Please set your plan's start and end time

Start Time	End Time
1	11
2	12
13	30
14	40
15	41
16	42
17	43

Impulse Duration [Please see here >](#)

☒ **Impulse to Show**

(Sun) (Mon) (Tue) (Wed) (Thur) (Fri) (Sat)

Save


(Normal Type)

Add Cycle Timer
Cycle & Soak

Start Time	End Time
1	11
2	12
3	20
4	21
5	22
6	23
7	24
8	25
9	26
10	27
11	28
12	29
13	30
14	31
15	32
16	33
17	34
18	35
19	36
20	37
21	38
22	39
23	40
24	41
25	42
26	43
27	44
28	45
29	46
30	47
31	48
32	49
33	50
34	51
35	52
36	53
37	54
38	55
39	56
40	57
41	58
42	59
43	60
44	61
45	62
46	63
47	64
48	65
49	66
50	67
51	68
52	69
53	70
54	71
55	72
56	73
57	74
58	75
59	76
60	77
61	78
62	79
63	80
64	81
65	82
66	83
67	84
68	85
69	86
70	87
71	88
72	89
73	90
74	91
75	92
76	93
77	94
78	95
79	96
80	97
81	98
82	99
83	100
84	101
85	102
86	103
87	104
88	105
89	106
90	107
91	108
92	109
93	110
94	111
95	112
96	113
97	114
98	115
99	116
100	117
101	118
102	119
103	120
104	121
105	122
106	123
107	124
108	125
109	126
110	127
111	128
112	129
113	130
114	131
115	132
116	133
117	134
118	135
119	136
120	137
121	138
122	139
123	140
124	141
125	142
126	143
127	144
128	145
129	146
130	147
131	148
132	149
133	150
134	151
135	152
136	153
137	154
138	155
139	156
140	157
141	158
142	159
143	160
144	161
145	162
146	163
147	164
148	165
149	166
150	167
151	168
152	169
153	170
154	171
155	172
156	173
157	174
158	175
159	176
160	177
161	178
162	179
163	180
164	181
165	182
166	183
167	184
168	185
169	186
170	187
171	188
172	189
173	190
174	191
175	192
176	193
177	194
178	195
179	196
180	197
181	198
182	199
183	200
184	201
185	202
186	203
187	204
188	205
189	206
190	207
191	208
192	209
193	210
194	211
195	212
196	213
197	214
198	215
199	216
200	217
201	218
202	219
203	220
204	221
205	222
206	223
207	224
208	225
209	226
210	227
211	228
212	229
213	230
214	231
215	232
216	233
217	234
218	235
219	236
220	237
221	238
222	239
223	240
224	241
225	242
226	243
227	244
228	245
229	246
230	247
231	248
232	249
233	250
234	251
235	252
236	253
237	254
238	255
239	256
240	257
241	258
242	259
243	260
244	261
245	262
246	263
247	264
248	265
249	266
250	267
251	268
252	269
253	270
254	271
255	272
256	273
257	274
258	275
259	276
260	277
261	278
262	279
263	280
264	281
265	282
266	283
267	284
268	285
269	286
270	287
271	288
272	289
273	290
274	291
275	292
276	293
277	294
278	295
279	296
280	297
281	298
282	299
283	300
284	301
285	302
286	303
287	304
288	305
289	306
290	307
291	308
292	309
293	310
294	311
295	312
296	313
297	314
298	315
299	316
300	317
301	318
302	319
303	320
304	321
305	322
306	323
307	324
308	325
309	326
310	327
311	328
312	329
313	330
314	331
315	332
316	333
317	334
318	335
319	336
320	337
321	338
322	339
323	340
324	341
325	342
326	343
327	344
328	345
329	346
330	347
331	348
332	349
333	350
334	351
335	352
336	353
337	354
338	355
339	356
340	357
341	358
342	359
343	360
344	361
345	362
346	363
347	364
348	365
349	366
350	367
351	368
352	369
353	370
354	371
355	372
356	373
357	374
358	375
359	376
360	377
361	378
362	379
363	380
364	381
365	382
366	383
367	384
368	385
369	386
370	387
371	388
372	389
373	390
374	391
375	392
376	393
377	394
378	395
379	396
380	397
381	398
382	399
383	400
384	401
385	402
386	403
387	404
388	405
389	406
390	407
391	408
392	409
393	410
394	411
395	412
396	413
397	414
398	415
399	416
400	417
401	418
402	419
403	420
404	421
405	422
406	423
407	424
408	425
409	426
410	427
411	428
412	429
413	430
414	431
415	432
416	433
417	434
418	435
419	436
420	437
421	438
422	439
423	440
424	441
425	442
426	443
427	444
428	445
429	446
430	447
431	448
432	449
433	450
434	451
435	452
436	453
437	454
438	455
439	456
440	457
441	458
442	459
443	460
444	461
445	462
446	463
447	464
448	465
449	466
450	467
451	468
452	469
453	470
454	471
455	472
456	473
457	474
458	475
459	476
460	477
461	478
462	479
463	480
464	481
465	482
466	483
467	484
468	485
469	486
470	487
471	488
472	489
473	490
474	491
475	492
476	493
477	494
478	495
479	496
480	497
481	498
482	499
483	500
484	501
485	502
486	503
487	504
488	505
489	506
490	507
491	508
492	509
493	510
494	511
495	512
496	513
497	514
498	515
499	516
500	517
501	518
502	519
503	520
504	521
505	522
506	523
507	524
508	525
509	526
510	527
511	528
512	529
513	530
514	531
515	532
516	533
517	534
518	535
519	536
520	537
521	538
522	539
523	540
524	541
525	542
526	543
527	544
528	545
529	546
530	547
531	548
532	549
533	550
534	551
535	552
536	553
537	554
538	555
539	556
540	557
541	558
542	559
543	560
544	561
545	562
546	563
547	564
548	565
549	566
550	567
551	568
552	569
553	570
554	571
555	572
556	573
557	574
558	575
559	576
560	577
561	578
562	579
563	580
564	581
565	582
566	583
567	584
568	585
569	586
570	587
571	588

6、Irrigation History

Every irrigation plan will be recorded. It's convenient for users to track the implementation of irrigation plans.



Tips for Operation

- 1 Please make sure the smart phone is near the Bluetooth water timer when connecting or setting the watering plan. The best range for connection and operation is within 60 meters in the open area.
- 2 The watering timer will follow and perform the preset watering schedule after application set successfully, even if the phone is out off the best connecting range.
- 3 For a better experience, it is recommended to update the device version of the timer to the latest version before use.
If there is a push to update the device version later, please upgrade to use the latest version to optimize and upgrade some functions.

Warranty & Warnings

1. Warranty

The warranty aims for the problem of non-artificial damage and provides a one-year warranty from the date of leaving the factory.

2. Warnings


- 1 Under freezing temperatures, timers should be removed from the faucet and stored indoors to avoid potential freezing damage.
- 2 Please clean filters regularly and replace if it is worn in order to prolong life of timer.



BLUETOOTH BEWÄSSERUNG BEWÄSSERUNGSSTEUERUNG

BENUTZERHANDBUCH

TTV102B



WEB: www.rainpointus.com

Email: service@rainpointus.com

Kostenlose Hotline (US): 833 3815659

Katalog

i. Produktübersicht

1. Erscheinungsbild des Produkts
2. Produkt Spezifikationen

ii. Wichtigste Funktionen

iii. INSTALLIERUNG

1. Anschluss und grundlegende Informationen
2. Upgrade der Version
3. Manuelle Bedienung
4. Wetterverzögerung
5. Pläne und Einstellungen
6. Bewässerungshistorie


iv. Tipps zum Betrieb

v. Garantie und Warnhinweise

vi. Kundenbetreuung

Produktübersicht

1. Erscheinungsbild des Produkts



2. Produkt Spezifikationen

Min/Max Betriebsdruck	0.5bar-8bar (7.25 psi-116 psi)
Durchflussrate	5L/Min-35L/Min
Arbeitstemperatur	3°C-50 °C (37.4 °F-122 °F)
Wasserdichte Rate	IP54
Leistung durch	3 AAA Alkalibatterien (nicht enthalten)
Einlass	NH(US) für 3/4" Wasserhahn / Schlauch BSP(EU) für 1" oder 3/4" Wasserhahn/ Schlauch
Auslass	For 3/4" standard garden hose

Wichtigste Funktionen

- Einstellen und Überprüfen des Bewässerungsplans über die APP des Smartphones, Verbindung mit Bluetooth
- Manuelles Ein- und Ausschalten der Bewässerungszeitschaltuhr
- Mit 2 Zeitplan-Typen: Normaler Zeitplan und Zyklus & Einweichen
- Wetterverzögerung 24/48/72 Stunden
- Bewässerungshistorie zur Vermeidung von Fehlbedienungen
- Anzeige für niedrigen Stromverbrauch
- Eingebauter Filter

INSTALLIERUNG

1、Anschluss und grundlegende Informationen




- 1 Suchen Sie nach RainPoint auf Google Play oder im App Store oder scannen Sie den QR-Code, um die RainPoint APP herunterzuladen. Folgen Sie den Aufforderungen, um ein RainPoint-Konto zu registrieren oder sich mit einem bestehenden Konto anzumelden.
- 2 Legen Sie zuerst 3*AAA-Batterien ein, und halten Sie dann den Gummiknopf gedrückt, bis die blaue LED-Lampe schnell blinkt, was bedeutet, dass das Gerät bereit für den Anschluss ist.



- 3 Bitte halten Sie die Taste am Timer 6 Sekunden lang gedrückt, damit das blaue Licht schnell blinkt. Wählen Sie "**Gerät hinzufügen**", um die Verbindung zu starten, und suchen Sie dann "**Bluetooth Smart**" in der Reihe "**Intelligente Bewässerung**". Schalten Sie Bluetooth auf Ihrem Telefon ein. Bestätigen Sie dann die Aufforderung am unteren Rand und klicken Sie auf "**Weiter**", um die Gerätesuche zu starten.



- 4 Drücken Sie auf die Schaltfläche " + " auf der rechten Seite des gefundenen Geräts und tippen Sie auf die Schaltfläche "**Weiter**", nachdem die Verbindung hergestellt wurde.



- 5 Drücken Sie auf "**Fertig**", um zu bestätigen, dass das Gerät erfolgreich hinzugefügt wurde.





- 6 Nach der Verbindung werden die gekoppelten Geräte auf der Startseite angezeigt. Klicken Sie auf die Bluetooth-Bewässerungsuhr und rufen Sie die Hauptseite des Geräts auf.



- 7 Die folgenden Informationen werden auf der Seite angezeigt: **Wochentage**, **Batteriestatus**, **Gerätestatus**, **Wetterinformationen**, **Bewässerungsdauer**, **letzte Laufzeit**, **nächste Laufzeit**.

- 8 Am unteren Rand befindet sich ein Bedienfeld mit mehreren Optionen: **Manuelle Taste, Wetterverzögerung, Zeitplaneinstellung, Bewässerungshistorie.**



-  Manuelle Taste für sofortigen Bewässerungsbedarf.
-  Wetterverzögerung für 24/48/72 Stunden.
-  Zeitplan Einstellung mit normalem Zeitplan und Cycle & Soak Zeitplan für Optionen.
-  Bewässerungshistorie zur Verfolgung der Bewässerung und Vermeidung von Fehlbedienungen.



- 9 Drücken Sie die Taste in der rechten oberen  um die Seite mit den Geräteinformationen aufzurufen.

2、Upgrade der Version

- 1 Rufen Sie die Schnittstelle der Timer-App auf; wenn es eine Versionsaktualisierung gibt, wird das System automatisch eine Benachrichtigung über die aktualisierte Version .
- 2 Klicken Sie auf "Jetzt Upgrade", um die Schnittstelle für die Update-Version zu öffnen. Die Versionsnummer dieses Updates wird hier angezeigt. Bitte klicken Sie erneut auf "Aktualisieren".



- ③ wenn Sie das Upgrade durchführen, verlassen Sie bitte nicht die Upgrade-Seite, lassen Sie Bluetooth eingeschaltet, und der Abstand zwischen dem Telefon und dem Gerät ist nicht zu weit.
- ④ Mit dem Fortschrittsbalken können Sie den Aktualisierungsfortschritt überprüfen.
- ⑤ Wenn das Gerät auf die neueste Version aktualisiert wurde, zeigt die Produktinformationsseite Informationsseite die Meldung "Neueste Version Schon!".



3、Manuelle Bedienung

Manueller Modus: Klicken Sie auf "▶", um den Bewässerungstimer manuell einzuschalten und mit der Bewässerung zu beginnen. Die Standardzeit beträgt 10 min. Klicken Sie auf "||", um den Bewässerungstimer manuell auszuschalten.

Tippen Sie auf den mittleren Kreis, um die manuelle Bewässerungszeit einzustellen, von 1 Minute bis 24 Stunden.




4、Wetterverzögerung

Tippen Sie auf "**Wetterverzögerung**", um die Regenverzögerungsfunktion zu aktivieren. Die Wetterverzögerung kann mit **24H, 48H, 72H** und **geschlossener Verzögerung** eingestellt werden.



5、Pläne und Einstellungen

5.1 Zeitplan Typ



Auf der Seite "Zeitplan" können Sie nach Auswahl der Schaltfläche " + " zwischen zwei Typen wählen: Normaler Typ und Zyklus & Einweichen.

Normaler Zeitplan: bedeutet, dass das Gerät zu einer bestimmten Zeit bewässert.

Cycle & Soak: bedeutet, dass das Gerät den Bewässerungsplan in diesem Zeitraum wiederholt ausführt.

5.2 Zeitplan-Einstellungen

Klicken Sie auf und wählen Sie den gewünschten Zeitplantyp aus, bestätigen Sie die Startzeit für die Bewässerung, die Dauer und die zu bewässernden Wochentage und speichern Sie alle Einstellungen.

Der Typ Einweichen & Zyklus hat unterschiedliche Einstellungsmöglichkeiten. Sie müssen die Startzeit, die Endzeit der Bewässerung, die Dauer des Zyklus und die Dauer des Einweichens einstellen.

Bemerkung

- Der Mindestzeitraum kann nicht größer sein als der Gesamtzeitraum
- Wenn sich die Zeitpläne überschneiden, kommt es zu Zeitkonflikten, was dazu führt, dass die Pläne nicht eingestellt werden können.

Add Timer
Please enter your input duration

1	11
2	10
3	9
4	8
5	7
6	6
7	5
8	4
9	3
10	2
11	1
12	0

Input your Duration Repeat: none

☒ **Repeatable** ☐ **One Shot**

☐ Sun ☐ Mon ☐ Tue ☐ Wed ☐ Thur ☐ Fri ☐ Sat

Save

(Normaler Typ)

Add Cycle Timer
Cycle # 1 of 4

	Start Time	End Time
1	---	---
2	---	---
3	---	---
4	---	---
5	---	---
6	---	---
7	---	---
8	---	---
9	---	---
10	---	---
11	---	---
12	---	---
13	---	---
14	---	---
15	---	---
16	---	---
17	---	---
18	---	---
19	---	---
20	---	---
21	---	---
22	---	---
23	---	---
24	---	---

☐ Stop ☐ 100% ☐ 100% ☐ 100% ☐ 100% ☐ 100% ☐ 100%

Repeatable
This timer is a Cycle timer, it will be running for a fixed duration and will repeat for a fixed number of cycles.

Cycle Duration Please Enter >

Start Duration Please Enter >

Save

(Zyklus- und Einweichtyp)

Wenn alle Pläne eingerichtet sind, werden sie in der Timerliste angezeigt.

Timer

Normal Schedule 10:24 Toggle

10:24
Input duration 22 min
Work Days

Cycle&Book 10:38 - 11:38 Toggle

10:38 - 11:38
Cycle&Book 10:38-11:38
Mon, Wed, Fri

Cycle&Book 7:42 - 9:44 Toggle


7:42 - 9:44
Cycle&Book 7:42-9:44
Mon, Wed, Fri

+

Hinter jeder Gruppe von Plänen befindet sich eine Verknüpfungstaste, mit der der Plan direkt gestartet oder gestoppt werden kann.

6、 Bewässerungshistorie

Jeder Bewässerungsplan wird aufgezeichnet. Es ist bequem für die Benutzer, die Umsetzung der Bewässerungspläne zu verfolgen.



Tipps für den Betrieb

- 1 Achten Sie darauf, dass sich das Smartphone in der Nähe der Bluetooth-Bewässerungsuhr befindet, wenn Sie die Verbindung herstellen oder den Bewässerungsplan einstellen. Die beste Reichweite für die Verbindung und den Betrieb liegt innerhalb von 60 Metern im freien Gelände.

- 2] Der Bewässerungstimer folgt dem voreingestellten Bewässerungsplan und führt ihn nach erfolgreicher Anwendung aus, auch wenn sich das Telefon außerhalb des besten Verbindungsbereichs befindet.
- 3] Um eine bessere Erfahrung zu machen, wird empfohlen, die Geräteversion der Zeitschaltuhr vor der Verwendung auf die neueste Version zu aktualisieren.
Wenn die Geräteversion zu einem späteren Zeitpunkt aktualisiert werden soll, aktualisieren Sie bitte auf die neueste Version, um einige Funktionen zu optimieren und zu verbessern.

Garantie und Warnhinweise

1. Garantie

Die Garantie zielt auf das Problem der nicht künstlichen Beschädigung und bietet eine einjährige Garantie ab dem Datum des Verlassens der Fabrik.

2. Warnhinweise

- 1] Bei Temperaturen unter dem Gefrierpunkt sollten die Zeitschaltuhren vom Wasserhahn abgenommen und in einem Raum aufbewahrt werden, um mögliche Frostschäden zu vermeiden.
- 2] Bitte reinigen Sie die Filter regelmäßig und tauschen Sie sie aus, wenn sie abgenutzt sind, um die Lebensdauer der Zeitschaltuhr zu verlängern.

Kundenbetreuung

Wenn Sie Schwierigkeiten bei der Einrichtung haben und sich das Video mit den Einstellungen ansehen möchten, abonnieren Sie bitte unseren YouTube-Kanal: **RainPoint**, oder besuchen Sie den Link <https://rainpointus.com/pages/playlist>

Wenn die App und das Benutzerhandbuch nicht das enthalten, was Sie suchen, und Sie Hilfe benötigen, halten Sie bitte die Modell- und Losnummer Ihres Geräts bereit und kontaktieren Sie uns, bevor Sie die Produkte in den Laden zurückbringen.

Kostenlose US-Hotline: 1-833-3815659

E-Mail: service@rainpointus.com

Modell-Nr.: xxxxxxxxxx(auf dem Etikett der Zeitschaltuhr)

LOT NO.: xxxxxxxxxxxxxxxx(Auf dem Etikett der Zeitschaltuhr)



Scannen Sie den QR-Code, um
das Einrichtungsvideo zu sehen

Brauche Hilfe? Rufen Sie 1-833 3815659
Oder per E-Mail an service@rainpointus.com

Customer Support

If you find it difficult to set up and want to watch the setting tutorial video, please subscribe to our YouTube channel: **RainPoint**, or visit the link <https://rainpointus.com/pages/playlist>

If the app and the user manual don't have what you're looking for, and you need some help, please prepare the Model NO. and LOT NO. of your device and contact us before returning the products to the store.

US Free Hotline: 1-833-3815659

Email: service@rainpointus.com

Model NO.: xxxxxxxxxx(On the timer label)

LOT NO.: xxxxxxxxxxxxxxxx(On the timer label)



Scan the QR code to
visit the setup video

Need Help? Call 1-833 3815659
Or email to service@rainpointus.com

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.