


FAQ

- Q:** How to turn on the camera?
- A:** Turn the switch of the camera to ON, and see the camera starts flashing red and blue alternately.
- Q:** How to turn off the camera?
- A:** Turn the switch of the camera to OFF.
- Q:** How to reset the camera?
- A:** Open the silicone cover at the bottom of the camera sphere and press the reset button about 10 seconds until you hear the voice prompt.
- Q:** Why the camera cannot connect to the WIFI?
- A:** Please ensure the camera has been turned on and the indicator light is flashing red and blue alternately. Please also make sure your WiFi network is a 2.4GHz wireless network.


Product Specification

|                         |                                                         |
|-------------------------|---------------------------------------------------------|
| Video Resolution        | 3MP                                                     |
| Lens Field of View      | 100°                                                    |
| Audio                   | Full Duplex 2 way Audio                                 |
| Pan tilt rotation angle | Horizontal: 270°    Vertical: 90°                       |
| Microphone              | Microphone with noise and echo cancellation             |
| Night Vision            | IR & Spotlight                                          |
| Motion Detection        | PIR, adjustable sensitivity, detects up to 26 feet (8m) |
| Networking              | 2.4GHz 802.11 b/g/n/ac/ax                               |
| Power                   | Battery & Solar                                         |
| Battery                 | 4000mAh rechargeable lithium battery                    |
| Operating Temperature   | 14°F to 140°F (-10°C to 60°C)                           |

Packing List



Camera Guide




HG Cam

Wireless PTZ Security Camera

Quick Start Guide

## Step 1: Charge your camera battery

Fully charge your camera battery. Plug into a USB power source (5V) using the provided cable.




## Step 2: Download the APP

Please scan the QR code or search "HG Cam" in Google Play Store or APP Store to download the APP.



## Step 3: Add your camera into APP

Entering the App, sign up for a free account and log in. Go to the home page and Click the "+" icon on the top right corner. Connecting the camera via Bluetooth, or following the instructions to add the camera.



## FCC Warning Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.