

SD7000

Quick Start Guide

GETTING TO KNOW YOUR HOTSPOT



Touch Screen Icons and Interfaces

Icons	Description
	Network signal strength
4G 5G	Network type
	New SMS
	Battery power level
	Settings: To configure the device settings.
	Wi-Fi status
	Show the number of connected users.
	Connect with your computer via a USB Type-C cable.




Airplane mode

GETTING STARTED

Charge the Device

Your device battery should have enough power for the Mobile hotspot to turn on and find a signal. You should fully charge the battery as soon as possible.




IMPORTANT! Use only approved chargers and USB cables.

Insert the SIM card

Press and hold the **Power key** to power on the Hotspot. After a moment the device will connect to the Internet automatically.

To install the 4G LTE SIM card

1. Take out the card sticker from the packing box.
2. Align the card sticker with the SIM area on the metal-free side of the card and then stick it.
3. Open the SIM card slot cover.
4. Insert your SIM card.



Caution!

Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.

To avoid damage to the device, do not use any other kind of SIM cards, or any non-standard SIM card cut from a SIM card. You can get a standard SIM card from your service provider.

Start Your Device

Press and hold the **Power Key** to turn your Mobile Hotspot on.

Press and release the **Power Key** to wake the Mobile Hotspot display.




NOTE:

If the battery is extremely low, you may be unable to power on the device. Please charge your device first.

Access the Internet

Wi-Fi: Connect to the Wi-Fi network with your mobile device and then access the Internet.

1. Press and hold the **Power Key** to turn on the Mobile Hotspot . The welcome logo is displayed on the screen, and the Wi-Fi is ON.
2. Use your terminal device to search for the wireless network connection with the Wi-Fi's SSID **"START-xxxx"**.
3. Enter the password.




NOTE: The default Wi-Fi SSID and password can be found on the Wi-Fi Information screen. From the Home screen, tap **Wi-Fi ON** or tap **Menu** to view the default Wi-Fi SSID and password.

USB Type-C cable: Connect with the computer via USB port and then access the Internet.

Change Your Device Settings

You can change the device settings by logging in to the Mobile Hotspot configuration web page.

1. Launch the Internet browser. Enter the Device Manager Website IP address <http://192.168.1.1> in the Address bar.
2. Input the **Password** and then click **Log In**.



3. After the Mobile Hotspot configuration web page is opened, you can change the default settings.

NOTE: The default password can be found on the Help Information screen. From the Home screen, tap **Help >Admin Website** to view the default username and password.

Troubleshooting

Problem	Recommended Action
The connection between your device and a client through Wi-Fi cannot be established.	■ Ensure that the Wi-Fi function is enabled. ■ Refresh the network list and select the correct SSID. ■ Check the IP address, and ensure that your client can automatically obtain an IP address. ■ Enter the correct network key (Wi-Fi password) when you connect the client to your device.

The client connected to the device cannot access the Internet.	■ Ensure that the Wi-Fi function is enabled. ■ Ensure that your SIM card is available. ■ Change the location and find a place with good signal. ■ Contact your service provider and confirm your APN settings.
---	---

SAFETY PRECAUTIONS

- Do not disassemble or open crush, bend or deform, puncture or shred.
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.

Only authorized service providers shall replace battery.

(If the battery is non-user replaceable).

- Promptly dispose of used batteries in accordance with local regulations.
- Avoid dropping the hotspot or battery. If the hotspot or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion or other hazard.

FCC RF Exposure Information (SAR)

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage near the body with the separation of 10mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value.

This is because the hotspot is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR.

The SAR limit set by the FCC is 1.6 W/kg.

This device is complied with SAR for general population / uncontrolled exposure limits in ANSI/IEEE C95.1-2019 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model hotspot with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model hotspot is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: 2AWF6-SD7000.

For this device, the highest reported SAR value for usage near the body is 0.727W/kg.

While there may be differences between the SAR levels of various hotspots and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 10 mm between the unit and the human body. Carry this device at least 10 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 10 mm between this device and your body.

RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and using such body-worn accessory should be avoided.

FCC COMPLIANCE

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the User's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Federal Communication Commission (FCC) Radiation Exposure Statement.


When using the product, maintain a distance of 10mm from the body to ensure compliance with RF exposure requirements. Operations in the 5150-5250MHz and 5925-6425MHz band are restricted to indoor usage only.

The operation of this device is prohibited on oil platforms and aircraft, except that operation of this device in 5.925-6.425GHz is permitted in large aircraft while flying above 10,000 feet. Installation on outdoor fixed infrastructure is prohibited. Controlling or communications with unmanned aircraft systems, including drones, is prohibited.

Step 1:
Press the Menu Button.



Step 2:
Press the About Button.



Step 3:
The device information is shown on the display screen and cannot be changed by user.

