



Product Description


First of all, thank you very much for choosing our product!
Before using this device, please read the instructions carefully and check that the package contains all the accessories: a translator machine, a charging cable and an operating manual. If the accessories are not complete, please contact the seller.



Translator x1



Type-C data cable x1



Operation Manual x1

1

Key Description




Diagram showing the device with labels: Type-C Charging Port, Power Button, Vol+, Vol-, Touch Screen, Translation Key A, and Translation Key B.

Key description:

[Power button]: long press to turn on/off, short press to lock/wake up the screen
[Volume key]: adjust the volume level
[Type-C charging port]: connect to Type-C cable or charge
[Translation key A/B]: First, select the language A/B corresponding to the A/B key. Long press the translation key A to say language A, when released it will translate to the corresponding language B. Similarly, long press the translation key B to say language B, when released it will translate to the corresponding language A.

2

Function Description

• Power On/Off

1. Power on: Press and hold the power button for 3 seconds to turn on the device. It takes some time to initialize the device, please wait patiently.
2. Power off: Press and hold the power button for 3 seconds, the screen pops up with a power off/reboot icon, select the [power off] icon and the device turns off. If you select [reboot], the device will reboot.

• Unlock Screen

1. Slide up the screen to unlock.

• Turning the screen on and off

1. Manually
1) When the screen is on, short press the power button to turn off; when it is off, short press to light up.
2. Automatically
1) The screen will be turned off automatically if no action is taken on the device during the system set sleep time (sleep time can be set in Settings - Display)
2) Short press the power button to light up the screen.

• Connect to the Internet

1. Support network mode: WiFi & Mobile Hotspot;
2. Click Settings-WLAN, select the network to be connected, enter the password. If you enter the wrong password, please click "Reset Password" to re-enter the password.

3

Function Description

PS: If there is no WIFI outside, it is recommended to connect to the mobile phone hotspot network or use offline translation. If you cannot find your mobile phone hotspot, please turn on "Maximize Compatibility" on the Personal Hotspot Page on your mobile phone.

• Voice Translation

1. In the initial state, press and hold Translation Key A to speak Chinese, release to translate into English; Press and hold Translation Key B to speak English, release to translate into Chinese.
2. Click [▼] on the screen to select the language.

• Photo Translation

1. Click on the selection box [▼] at the top of the screen to choose the source and target languages to be translated.
2. Aiming at the text, click "Shutter" at the bottom of the screen to take a photo, then it will automatically translate the contents recognized in the photo.

• Offline Translation

1. Offline translation refers to the ability to translate even without an internet connection, supported in select languages.

• Sound Recording

1. Tap Sound Recording to record. When recording is finished, save and click the top right corner [📁].

4

Function Description

to play back and manage the recording file, and long press to delete the recording file.

• Recording file export

1. Connect the device to your computer with a data cable to copy the recording files from the device to your computer. The recording files are stored in the RecordingFiles folder.

• Favorites (Voice Collection)

1. Long press on the voice translation result to add the frequently used dialogue to Favorites for easy re-use and improve the communication efficiency.

• Bluetooth

1. Connect the translator to earbuds via Bluetooth, the voice is output through the earbuds without external amplification.

• Dual world clocks

1. Click on the world clock icon in the main screen to set time and time zone, convenient for international travel.

• Settings

📶 Connect/Change Wi-Fi
🗑️ Clear translation record: clear all voice or photo translation data with one click
⚙️ Language setting: Set the system interface display language

5

Function Description

🔄 Online upgrade: If there is a new version, the user will be automatically reminded to upgrade when they connect to WIFI. Or manually click on "Online Upgrade" to check if there is a new version

⚙️ Display: adjust the screen brightness and set the sleep time; You can choose 30S, 1 minute, 3 minutes and never

🕒 Time and date: set time, time zone and 12 or 24 hour system

🖼️ Change wallpaper: change the wallpaper that comes with the system

🔊 Keypad tone: turn on or off the "beep" sound when holding the translation key

🗣️ Voice broadcast: switch male or female voice

🔄 Restore factory settings: Restores the device to original settings (All user data on the device will be deleted, which is irreversible)

ℹ️ Terminal information: view device information

Troubleshooting Tips

• Inaccurate translation

1. The accuracy of translation mainly depends on the accuracy of recognition. Please note: pronunciation should be as standard, clear and loud as possible, with appropriate pauses after each sentence.

6

Troubleshooting Tips

• Slow translation

1. Translation speed mainly depends on the Network status. It is best to use it under smooth network.
2. In case of poor network, you can download the offline translation package for free in advance.

• Fail to Start

1. Check if the power has been exhausted. Please plug in the charging cable to charge the device and the charging signs will be displayed on screen.
2. Restart the device and reconnect the network.

• Weak Signal

1. Check the hotspot connection and the network environment of router.
2. Restart the device and reconnect the network.

• Fail to connect to the network

WiFi/Hotspot
1. Check if other devices can connect to the current WiFi/Hotspot network and get online.
2. Check if the password is entered incorrectly.
3. Check the connections limit of router.
PS: If you cannot find your mobile phone hotspot, please turn on "Maximize Compatibility" on the Personal Hotspot Page on your mobile phone.

7

Charging/Battery safety and precautions

• Charging/Battery safety and precautions

1. This product contains sensitive electronic components, please do not disassemble, repair or modify it by yourself, avoid using it in an environment with too high or too low temperature, and avoid prolonged exposure to strong sunlight or high humidity environment. Dangerous chemicals and strong magnetic fields.
2. It is strictly forbidden to use this product in environments such as gas stations, fuel depots, chemical plants, fuel or chemical transportation or storage facilities, otherwise it may cause explosion and fire.
3. Please do not use high volume for a long time to prevent possible hearing damage.

• Environmental instructions

Parts Name	Toxic and harmful substances or elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ether (PBDE)
Shell	○	○	○	○	○	○
Battery	○	○	○	○	○	○
Charging cable	○	○	○	○	○	○
Circuit boards and components	○	○	○	○	○	○

This form is compiled according to the regulations of SJ T11364.
○Indicates that the content of hazardous substances in all homogeneous materials of this part is below the limit requirements stipulated in GB/T26572.
XIndicates that the content of hazardous substances in at least one homogeneous material of this part exceeds the limit requirements specified in GB/T26572.

8

FCC Statement

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

9

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure information
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition, compliance with exposure requirements.

10

Warranty Card

• For dealers / users

Customer name (Mr./Ms.): _____
Contact number: _____
Customer address: _____
Postal code: _____
Product Model: _____
Origin: _____
Shop: _____
Store address: _____
Store phone number: _____
Postal code: _____
Purchase Date: _____
Invoice number: _____
Annex: _____

11