

YS-BS0553 (PBS-48/6)

Portable Light Up Bluetooth Speaker



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY

AND RETAIN FOR FUTURE REFERENCE

Getting Started

- Remove the product from the packaging.
- Please retain all packaging until you have checked and counted all the parts and the contents against the Package Contents list.

Package Contents

- Portable Bluetooth Speaker With RGB Lights
- Type-C Charging Cable
- 3.5mm Aux Cable
- Instruction Manual


Key Features

- Portable Bluetooth Speaker With RGB Lights
- Connect & stream wireless music
- Dual 5W speakers
- RGB lighting effects
- Multi-function: Bluetooth, FM Radio, USB, Micro-SD, Aux, TWS
- Built-in 1200mAh rechargeable battery
- USB charging cable included

SAFETY INSTRUCTIONS

- Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.
- Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent electric shock, explosion and/or injury to yourself and damage to the speaker.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs of electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Do not put objects into any of the openings.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach for children.
- This unit is not a toy.

Description of Parts



1	Mode button	7	Charging indicator
2	Previous track/volume decrease button	8	Charging port
3	Power on/off button	9	Micro-SD card slot
4	Light/TWS button	10	USB slot
5	Next track/volume increase button	11	Aux in
6	Play/Pause / Scan / Phone button		

INSTRUCTIONS FOR USE

Charging the Speaker

For best results, fully charge the unit before use.

- Fully charge before first use (4–6 hours).
- Connect Type-C cable to DC 5V port; red LED indicates charging and turns off when complete.

Turn On/Off the Speaker

Long press the power on/off button to turn on the unit with color changing RGB lights or turn off the unit.

Pairing your device with the Speaker –

Your **Wireless Speaker** can stream audio from any Bluetooth-enabled device within the range of up to 33 feet. Simply follow the steps below.

1. Turn ON the speaker.
2. RGB lights will turn on, and an indication tone will be heard. The speaker is now entering “pairing” mode.
3. Turn on the Bluetooth on your Mobile Phone or Tablet or Computer.
4. It will search for available Bluetooth devices.
5. The Bluetooth Speaker would appear as “**AUTRIX_PBS48**”, in the list of searched devices. Select it from the available list of devices.
6. You might be prompted with “Pair with **AUTRIX_PBS48**?” message on your source device, with “Cancel” and “OK” options. Please click “OK”.
7. If required, enter the password ‘0000’ to confirm pairing.
8. Once paired successfully, another indication tone would be heard.
9. If you fail to pair it within a few seconds or want to pair it with a new device, please repeat above steps.

Play your favorite song on the Bluetooth source device and music would now stream through the speaker.

Talking using Bluetooth Speaker

Please ensure that you are paired with the Bluetooth Speaker to use the below functions.

Function	Operation	Button
Answer Incoming Call	Incoming Call	Press the Phone once to answer an incoming call.
Reject incoming call	Incoming Call	Long press the Phone button
End Call	Incoming Call	After your phone conversation, short press the Phone button once
Increase Volume	During a call	Press and hold the + button to increase the volume
Decrease Volume	During a call	Press and hold the - button to decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

Listening to Wireless Music

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the speaker to stream wireless music. Once it is paired, play music from your device.

Function	Operation	Button
Increase / Decrease Volume	Playing music	Press and hold the volume increase/decrease button
Pause	Playing music	Short press Play/Pause button once to pause music
Play	Pause	Short press Play/Pause button once to resume music
Previous track	Playing music	Short press the Previous track button to the previous track
Next track	Playing music	Short press the Next track button to the next track

Note: An indication tone will alert you when the volume is adjusted to maximum level.

TWS pairing use (if you own 2 ATRIX Portable Bluetooth Speakers)

- Make sure both speakers are “ON” and not paired with any Bluetooth device. An indication tone would be heard from each speaker.
- Choose either one as your master speaker.
- Long press the TWS button on master unit.
- Both units will wirelessly connect with each other, and you would hear an indication tone after they pair together successfully.
- Activate the Bluetooth function on your source device (Mobile Phone, Tablet etc.). Please refer to manufacturer’s instructions for instructions on enabling Bluetooth on your device.
- Search for available Bluetooth devices and you would find “**ATRIX_PBS48**” – Pair it with this device.
- You might be prompted with “Pair with **ATRIX_PBS48**?” message on your source device, with “Cancel” and “OK” options. Please click “OK”.
- If required, enter the password “0000” to pair with the device.
- Once paired successfully, an indication tone would be heard.
- You can now stream wireless music on your speaker through your source device.

Note: TWS stands for True Wireless. If you want to separate 2 speakers again for individual use, long press the TWS button on any one speaker.

Listening to Music using USB / Micro-SD Card Slot

1. Turn on the speaker.
2. Insert USB flash drive into the USB slot or Micro-SD card into the Micro-SD card slot accordingly. An indication tone would be heard, and music would play automatically.
3. Short press the Next track or Previous track button to move forward or backward on your playlist.
4. Short press Play/Pause button to Play or Pause a track.

Note: USB / Micro-SD card: Supports up to 32GB; Supports music file format: MP3, WAV. USB Flash Drive or Micro-SD card not included.

Listening to Music using AUX-In

1. Turn on the speaker.
2. Plug the 3.5 mm Aux-in cable (included) into the AUX-In port of the speaker, and the other end of the cable to the audio device (such as computer / tablet / MP3 Player etc.).
3. Select your favorite song at the source device to play.

(Note: While using AUX-In function, except volume function, all functions such as playing next/previous track can be controlled only through your source device).

Listening to FM radio

1. Turn on the speaker.
2. Insert the Type-C end of the included Type-C charging cable into the charging port and leave the other end of the cable open. The Type-C charging cable serves as FM antenna while in FM radio mode.
3. Short press the Mode button each time until it reaches FM radio mode with sound from a FM

radio frequency.

4. Short press the Scan button to search and record all radio stations within frequency range 87.5-108MHz.
5. Short press the Next track or Previous track button for listening next or previous already saved radio station.

Tips!!

1. Short press the Mode button to switch different functions of the speaker. The functions are – Bluetooth / FM radio / AUX / USB-Micro-SD.
2. When the speaker is not in use, turn OFF the device to save the battery power.
3. Do not overcharge the speaker.

RGB Light Mode

1. Turn on the speaker.
2. Short press the “Light” button each time to change 6 different RGB light patterns (including off light mode).

Dos and Don'ts

- Do not play music at excessive levels as damage to hearing and/or equipment may result.
- Do not use outdoors in wet or in damp surroundings.

Care and maintenance

Clean the unit with a soft, dry cloth. Never use chemicals or hard abrasives.

Keep this unit away from wet or damp surroundings.

Product Specifications:

Bluetooth version : 5.1

Speaker output : 2x5W

Unit size : 8.66" (L) x 3.66" (D) x 3.81" (H)

Unit weight : ~22.1 oz

FM frequency range : 87.5-108MHz

Power input : DC 5V

Charging time : About 4-6 hours

Play time : Up to 2 hours (max volume)

Built-In Rechargeable Lithium Battery: 3.7V / 1200mAh

USB / Micro-SD card: Supports up to 32GB, supports music file format: MP3, WAV

(Note: Battery life & charging time may vary based on usage, types of devices connected & wireless distance.)

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.