


3.1101.618929.00000000

原材料 机乐堂 JR-CB7 蓝牙接收器 说明书（亚马逊） V1.0

尺寸：78x60mm

材质：105g铜版纸+正反单色印刷+风琴折

JOYROOM



使用说明书 / User Manual / Instrukcja obsługi / Manual del usuario / Manuale dell'utente / دليل المستخدم

I. Product picture

USB power input connector

3.5mm audio output plug

Bass button

LED ring

Multifunctional button

TF card slot

Microphone

II. Basic parameters

Name: Car-B Series Wireless Receiver

Model: JR-CB7

BT version: V5.3

Audio decoding: AAC, SBC

Supported protocols: HFP, A2DP, AVRCP

Supported modes: TF card, BT mode

TF card capacity limit: <32G

Working frequency: 2400MHz-2483.5MHz

Max output power: ≤20dBm (EIRP)

BT range: 10m (barrier-free open environment)

Frequency response range: 20Hz-20KHz

Microphone sensitivity: -38dB±2

Input port: USB+AUX

Cord length: 100cm

Power input: 5V ≍ 1A

Material: ABS+PC+aluminum alloy

Size: 55mm*24mm*12mm

Net weight: 21g

III. Pairing operation

1. Turn on

Insert the USB power input connector, the receiver will turn on automatically

when used in a car, it will turn on automatically with the startup of the car

2. Ready for pairing

When the LED ring slowly breathes ice-blue, purple and orange at the same time, it means the receiver is ready for pairing

3. Connected

Turn the phone's BT function on and search for the BT device "JR-CB7", connect with it

4. Turn off

The receiver will turn off automatically once disconnected from power

when used in a car, it will turn on automatically with the startup of the car

IV. Operation instructions

Music function

Play/Pause: Click the call button to pause or play music under music status

Call function

Answer/end call: Click the call button to answer or end an incoming call

Reject call: Press and hold the call button for 1s to reject an incoming call

Redial last number: Double-click the call button under standby status

Voice assistant

Activate voice assistant: Press and hold the call button for 1s under music or standby status

LED ring

Turn on/off LED ring: 5-click the bass button quickly under turned on status

Multifunctional button

For FAQs and more information, please scan



Lifetime Warranty Code

794318

support@joyroom.com

»

Factory reset

Restore factory settings: Press and hold the bass button for 8s under turned on status

Bass mode

Turn on/off bass: Click the bass button under music status

Mode switch

TF card, BT mode switch: Double-click the bass button

Dual connection

Dual device connection: After device 1 is successfully connected to the receiver, manually turn off its BT function and connect device 2. After device 2 is successfully connected to the receiver, turn on device 1's BT function and reconnect it to the receiver manually, so as to connect the receiver to two devices simultaneously

Auto sleep/wake-up function

Auto sleep/wake-up: The receiver will automatically enter sleep mode if not connected for 10min. Click the call button to wake it up

Bass button

Reconnect function

1. If the receiver is out of the connection range and returns to the effective range within 10min, it will automatically reconnect to the connected device

2. If you manually turn off your phone's BT function, you need to click the BT device name again to connect with it

V. Indicator light

Turn on: The LED ring has constant ice-blue, purple and orange light for 1s

Turn off: The LED ring turns off

Ready for pairing: The LED ring slowly breathes ice-blue, purple and orange at the same time

Connected to phone: The LED ring has constant ice-blue, purple and orange light

Factory reset: The LED ring quickly flashes ice-blue, purple and orange at the same time for 5 times

VI. FAQ

Q: Why can't the receiver be connected?

A: ① The USB charging port and cable may not be connected properly, please pull the cable out and plug it in again repeatedly to make sure it is well inserted.

② Please use adapters or car chargers that conform to national/regional safety standards to supply power for the product. Adapters with excessive power may be incompatible.

② The product does not support PD protocol, when using PD power adapters to supply power for the product, it may be incompatible.

VII. Safety Criterion

1. Please follow the instructions, do not disassemble the product or refit it for any reason, otherwise it may break down or burn down.

2. Do not immerse it in any liquid or wash it with water.

3. Please use adapters that conform to national/regional safety standards together with the included charging cable to charge the product, otherwise its battery may be damaged or cause safety problems.

4. Please use and store it in normal temperatures, too low or too high temperature (below 0℃ or above 35℃) is not permitted.

5. Do not block the openings of the product, such as charging port, audio port and microphone, etc.

6. Do not use it under thunderstorm which may lead to abnormal performance and signal interruption.

FCC NOTE:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

3.1101.618929.00000000