机乐堂 JR-ZS246 车载支架 出风口款 中英文版 说明书
尺寸：55x80mm
材质：128g铜版纸 正反单色印刷 风琴折

JOYROOM



User Manual

Dual-coil wireless car charger holder

Parameter

Model: JR-ZS246
Name: Dual-coil wireless car charger holder
Color: Black
Material: ABS+PC
Input: 5V⎓2A 9V⎓2A 12V⎓2A
Output: 5W/7.5W/10W/15W (max)
Input port: Type-C
Applicable phone size: 4.7-6.8"
Induction: ≤8mm

LED indicator lights

Power on	Side LED light keeps on, panel LED ring flashes once then keeps on
Standby	Side LED light keeps on, panel LED ring keeps on
Charging	Side LED light flashes slowly, panel LED ring turns off
Abnormality	Both side LED light and panel LED ring flash quickly

Product diagram



Outlet clamp



Operating steps



1. Put the universal ball into the nut first, then insert it into the socket on the back of the holder.

2. Fasten the nut clockwise to its position.

3. Loosen the knob and open the clip, insert the clip onto vent blade, then fasten the knob.



4. Connect phone holder to car charger using the included Type-C charging cable, the clamp arms will open automatically.





5. Place your phone, the clamp arms will lock it automatically.

6. Press the clamp arms control button to open the arms and retrieve your phone.



Warning

1. Do not disassemble or refit the product.
2. Do not store it in a wet environment.
3. Please keep the product away from heat and do not charge it near a heat source.
4. Please prevent water or other liquid from entering the product interface. Otherwise the product may be damaged.
5. Do not install the wireless car charger mount over an air bag cover or within the air bag deployment zone.
6. During charging, make sure to remove the metallic/magnetic protective case or cards (like bank cards), etc. from your device.
7. During charging, the charger may heat up. This is a normal occurrence and won't affect the its performance. If the charger or your phone is too hot, please disconnect the power supply and let it cool down before restarting the charging process.
8. Avoid using bent or damaged USB cables.

After-sales service instructions

Dear users, thank you very much for using our products. In order to protect your rights and interests, and to clarify the company and its distributors' responsibilities, i.e. product maintenance, replacement and return, please read the following items carefully:

1. Warranty Card is the necessary certificate for our company to provide free after-sales service during the warranty period of our products.

2. According to the principle of "who sells who takes responsibility", you can, with the Warranty Card, contact the distributor in case of any quality problem. The company will provide service support for its distributors.

3. The company promises that if a quality problem occurs within seven days since the date of purchase (the date on valid bills shall prevail), the customer may choose to return, replace or maintain the product freely. For products beyond warranty period, life-long maintenance service is also provided (the after-sales service offices only charge for components/parts). Please fill in the Warranty Card carefully upon purchase.

4. The following cases are not included in the after-sales service:
① Beyond the warranty period;
② Product damage caused by failure to follow the use, maintain and preserve instructions;
③ Product damage caused by dismantling or repairing the product without authorization;
④ Failure to provide Warranty Card;
⑤ The product differs with that on the Warranty Card, or there's alteration on the Warranty Card.
⑥ Damage caused by other force majeure.

5. JOYROOM reserves the right of final interpretation.

Warranty Card

Model:_____

Purchase Date:_____

Distributor:_____

Invoice Date:_____

Tel.:_____

Customer Name:_____

Zip code:_____

JOYROOM



使用说明书

绚光无线充车载支架

产品参数

产品型号：JR-ZS246
产品名称：绚光无线充车载支架
产品颜色：黑色
产品材质：ABS+PC
输　　入：5V⎓2A 9V⎓2A 12V⎓2A
输　　出：5W/7.5W/10W/15W（MAX）
输入接口：Type-C
适用手机尺寸：4.7-6.8英寸
充电距离：≤8MM

LED显示

上电显示	侧LED灯常亮，面板LED灯呼吸闪一次后常亮
待机显示	侧LED灯常亮，面板LED灯常亮
充电显示	侧LED灯呼吸闪，面板LED灯熄灭
异常显示	侧LED灯和面板LED灯同时快速闪烁

产品示意图



出风口夹



产品使用



1. 将仪表台配件连接到本产品，先把万向球放入螺母内再插入到设备背部的螺栓。

2. 顺时针方向拧紧螺母。

3. 拧松旋钮打开夹子，插入出风口，在拧紧旋钮。



4. 使用包装内的Type-C充电线连接支架与车充，夹臂自动张开。





5. 放上手机，夹臂自动夹紧。

6. 按压侧开关按键，夹臂自动打开，此时即可取走手机。



警告

1.请勿自行拆开或改装本产品。
2.请勿将本产品放在潮湿环境中。
3.请勿将本产品靠近热源或于热源附近充电。
4.请勿将水或其他液体流入本产品介面内部，导致本产品损坏。
5.不要将无线充电器安装在气囊盖上或安全气囊展开区域
6.充电时请务必从你的设备上取下金属,磁性保护外壳或卡（如银行卡等）。
7.充电时有可能产生热量，此乃正常现象，并不会影响产品表现，如果感到手机或本产品过热请断开电源供应，待冷却后再尝试充电。
8.避免使用折曲或损坏的USB线材。

售后服务说明

尊敬的用户，非常感谢您使用我们的产品，为了切实保障你的权益，明确经销代理商和公司应当承担产品的维修、更换、退货（简称 三包）责任义务，敬请阅读以下事项：

1. 产品保修卡，是我公司对其产品提供保修期内免费售后服务的必要凭证。

2. 按照谁销售谁负责三包原则，产品出现质量问题凭《产品保修卡》与经销商联系，由经销商对客户提供服务，我公司则对经销商提供服务支持。

3.公司承诺，自售出之日（日期以有效，票据日期为准）起七日内出现质量问题，客户可以选择退货更换及维保修，产品超过保修出现质量问题享受终身维修（各售后服务点只收取元器件材料费）；请客户在购买时与经销商认真填好（产品保修卡）；

4. 下列情形不享受三包服务
① 超过三包期限的
② 未按产品使用说明书要求使用、维修、保管而造成损坏的
③ 非承担三包的维修者拆动造成损坏的
④ 无《产品保修卡》
⑤ 《产品保修卡》上的内容与产品实物不符或涂改的
⑥ 因不可抗力造成的

5. 以上各事项最终解释权属于本公司所有。

产品保修卡

产品型号：_____

购买日期：_____

代 理 商：_____

发票日期：_____

电　　话：_____

顾客姓名：_____

邮政编码：_____

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

-RF warning for WPT device:

-The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15cm surrounding the device and 20 cm above the top surface of the device must be respected.