

北通鲲鹏40


游戏手柄用户手册

请仔细阅读使用说明书并妥善保管

BEITONG KunPeng 40

Intelligent Gaming Controller User Manual

Please read the manual carefully before using the product and keep it for reference



基本操作

键位	功能解释
HOME键	短按开机
BACK+短 (长按3秒)	关机
HOME键 (长按3秒)	进入当前模式下的功能配对
短按/LT/RB	无线 配对灯
TURBO+L/R/X/Y/LB/LT/RT/RB	连发开火/连发
RB+BACK+RS+HOME键开机	连发开火/连发
BACK+START+HIS	进入街机及街机校准模式
Y+X+HOME键关机	进入街机校准模式
自动关机	1. 手柄在任意模式下, 当手柄无操作时, 某项手柄功能被禁用, 可在任意模式
唤醒休眠	手柄在任意模式下, 当手柄无操作时, 某项手柄功能被禁用, 可在任意模式
更新固件设备	手柄在任意模式下, 当手柄无操作时, 某项手柄功能被禁用, 可在任意模式
固件/固件校准	手柄在任意模式下, 当手柄无操作时, 某项手柄功能被禁用, 可在任意模式
校准模式	手柄在任意模式下, 当手柄无操作时, 某项手柄功能被禁用, 可在任意模式


Basic Control

BUTTON	FUNCTION
HOME BUTTON	SHORT PRESS TO POWER ON
BACK+B (press more than 3s)	POWER OFF
HOME BUTTON (long press 3s)	FORCE PAIRING IN CURRENT MODE
SHORT PRESS TURBO BUTTON	TURN HANDLE LIGHT ON/OFF
TURBO+L/R/X/Y/LB/LT/RT/RB	TURBO TURN ON/OFF
POWER ON WITH RB+BACK+RS+HOME	CLEAR ALL PAIRING DATA
BACK+START+HS	CALIBRATION MODE FOR TRIGGERS AND STICKS
POWER ON WITH Y+X+HOME	CALIBRATION MODE FOR MOTION SENSORS
AUTO POWER OFF (PC)	Power off after 10 minutes (adjustable) if no inputs while connected
AUTOPWEROFF (PC)	Power off after being disconnected with no user inputs for 2 minutes
SWITCH PARED DEVICE	Using game specific button for it will force the gamepad to reset the pairing in the current mode
CALIBRATION STICKS	While connected, press BACK+START+HIS to enter the calibration mode. Once entered, the light will turn yellow. Then set the calibration mode for the left and right sticks. In full game play mode, this gamepad will automatically return to the calibration mode after the calibration.
CALIBRATE MOTION SENSORS	While powered off, press Y+X+HOME to enter the calibration mode. Once entered, the light will turn yellow. Then set the calibration mode for the left and right sticks. In full game play mode, this gamepad will automatically return to the calibration mode after the calibration.

阻尼摇杆使用说明




Damping Stick Guide



连接电脑



PC



有线连接



Wired Connection



无线连接



Bluetooth Connection




有线连接




Wired Connection



连接SWITCH



Switch




无线连接



Bluetooth Connection



连接手机/平板设备



Phone/Tablet



有线连接




Wired Connection



安卓电视及安卓映射



Android TV/Android Mapper



无线连接



Bluetooth Connection



WIRELESS/BLUETOOTH MODE SWITCH

This gamepad can switch among 4 wireless modes: Receiver, Input Bluetooth, Switch Bluetooth, and BT APP Mode.
You may know setting is correct mode by long pressing HOME button for 5 seconds.
The gamepad will attempt reconnecting to the previous connected device on each mode at once switch.

Switch	Mode	Light	Reconnect	Reconnect	SUCCESSFUL CONNECTION
Receiver Mode	Normal	Normal	Normal	Normal	Light stays red for 2 seconds after it connects. (Blue light stays red for 2 seconds after it disconnects.)
Input Bluetooth	Normal	Normal	Normal	Normal	Light stays Yellow for 2 seconds after it connects. (Blue light stays red for 2 seconds after it disconnects.)
Switch Bluetooth	Normal	Normal	Normal	Normal	Light stays Blue for 2 seconds after it connects. (Blue light stays red for 2 seconds after it disconnects.)
BT APP Mode	Normal	Normal	Normal	Normal	Light stays Green for 2 seconds after it connects. (Blue light stays red for 2 seconds after it disconnects.)

CHARGING GUIDE


BATTERY STATUS	LIGHT INDICATION
Less Than 20%	Fast Flashing: user-defined light
Charging	User-defined light: stays in and out
Charging complete	When powered off: user-defined light stays on for 7 seconds then off

*By default, charging light will keep flashing when the battery is low.

MORE SMART CUSTOMIZATION THROUGH BEITONG GAMEPAD ASSISTANT

Go to BEITONG official website www.beitong-cn.com and download BEITONG Gamepad Assistant for more customization options.

1. STICK ADJUSTMENT ADJUST SENSITIVITY ACCORDING TO GAME GENRES



FAQ

1. MY GAMEPAD IS NOT CONNECTING WIRELESS. WHY?

1. Usually it's caused by jammed signals or insufficient battery. Please try the following:

1. Make sure that the gamepad is sufficiently charged. Try reconnecting after charging it for more than 1 hour.
2. Try a different USB port on the same device. A USB 3.0 port is recommended.
3. If nothing works, please contact our online technical support. Support Email: beiting-overseas@beitong-cn.com

2. WHAT KIND OF CHARGER SHOULD I USE?

1. The standard charger is 5V 1A/2A.

3. HOW DO I UP GRADE FIRMWARE ARE?

1. Please install BEITONG Gamepad Assistant and follow the instructions provided by the software.

4. THE ANALOG STICK IS STUCK IN A DIRECTION / DOES NOT CENTER PROPERLY?

1. Try forcing it back to the center and pressing down the stick slightly hard, which should go to center back.
2. If it did not help, please contact customer support through: beiting-overseas@beitong-cn.com

PRODUCT SPECS

PRODUCT NAME	BEITONG Running 40 Intelligent Gaming Controller
PRODUCT MODEL	BTW-K740
PRODUCT DIMENSIONS	156x107x69mm
PRODUCT WEIGHT	~245g
COMPATIBILITY	PC, Nintendo Switch, Smartphone, Android TV, Smart Projector, etc. For PC: Download support software from our website. PC support that requires drivers and game, download drivers and game from our website.
CONNECTION COMPATIBILITY	Wired, Wireless, Bluetooth
BATTERY CAPACITY	600mAh
RANGE	Wired: 1.5 meters, Wireless: less than 10 meters

FC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:

This equipment has been tested and found to comply with the limits for a Class C digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limit set forth for uncontrolled environment.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CE

This equipment has been tested against the listed standards and found to comply with the requirements of EMC Directive 2014/30/EU, EU LVD Directive 2014/35/EU, and CE Directive 2014/53/EU. The CE marking can be used to certify that a product complies with European Union (EU) health, safety, and environmental requirements.
This product, its battery, or the packaging may bear this symbol, indicating that this product and any contained batteries must not be disposed of with your household waste. Instead, you are responsible for handing them over to applicable collection points for the recycling of batteries and electrical electronic equipment. This separate collection and recycling will help protect natural resources and prevent potential negative consequences for human health and the environment due to harmful substances that may be present in batteries and electrical electronic devices, which could arise from improper disposal. For more information on where to dispose of batteries and electronic waste, please contact your local city/municipal office, your household waste disposal service, or the store where you purchased this product. For more information about the disposal of electrical electronic equipment and waste batteries, please contact beiting-overseas@beitong-cn.com.

Customer Service

Dear Customer,
Thank you for choosing BEITONG gaming peripheral product. We aim to provide every gamer a better gaming experience. To submit a warranty claim, please include the following information in your email: a. Vendor information b. Buyer ID c. Order Number d. Product Model
Please describe the problems you're having and how we can be of assistance:
1. What problems are you having?
2. How would you like to proceed?
a. Replace b. Repair c. Return d. Others
Support Email: beiting-overseas@beitong-cn.com
Your feedback is highly appreciated and will help us to improve our product. Please tell us your thoughts on our product through our support email. Customers who provided valuable feedback may be eligible for free tech demos from us in the future.
Sincerely,
BEITONG Customer Service Team

无线/蓝牙模式切换

本手柄支持4种无线模式：接收器模式、输入蓝牙模式、切换蓝牙模式、BT APP模式。
你可长按HOME键5秒来确认手柄是否切换到了正确模式。
手柄每次切换模式时都会尝试连接到上次连接的设备。

模式名称	模式	指示灯	连接状态	连接说明	连接说明
接收器模式	正常	正常	正常	正常	手柄指示灯在连接成功时亮起，模式切换时熄灭。
输入蓝牙模式	正常	正常	正常	正常	手柄指示灯在连接成功时亮起，模式切换时熄灭。
切换蓝牙模式	正常	正常	正常	正常	手柄指示灯在连接成功时亮起，模式切换时熄灭。
BT APP模式	正常	正常	正常	正常	手柄指示灯在连接成功时亮起，模式切换时熄灭。

充电说明

电量状态	指示灯提示
电量不足20%	快速闪烁：用户自定义灯光
充电中	用户自定义灯光：亮灭交替
充电完成	当手柄关机时：用户自定义灯光亮起7秒后熄灭

*默认情况下，充电灯在手柄电量低时会持续闪烁。


北通游戏厅 更多智慧设置

访问北通官网 www.beitong-cn.com 下载《北通游戏厅》，自由探索多样玩法。

1. 智慧自定义按键功能，提升游戏体验，提升竞技水平



2. 智慧自定义按键功能，提升游戏体验，提升竞技水平



3. 智慧自定义按键功能，提升游戏体验，提升竞技水平

