

Function:

1. 6 buttons: MODE、SET、PREV/V-、PLAY、NEXT/V+、LIGHT/SN
2. Bluetooth Speaker
3. FM Radio
4. Time (hour/minutes), 24/12Hr switch
5. LED Brightness : 3 adjustable Levels (HI/LOW/OFF)
6. Sliding switch: turn on/off the display (on the back side)
7. Batteries: 1.5V AAx 2pcs (not included), only for the memory
8. Press "MODE" button, the function menu order is TF (skip to the next function if there is no card) →Bluetooth →FM radio → Clock.

Time Setting:

1. In any mode(except FM mode), hold "SET" button to enter 12/24H setting,
2. Press "SET" button to confirm and move to next time. The setting order is Hour→Minutes →12/24H
2. Under setting mode, press + or – button to adjust the flashing values. Hold to adjust quickly.
3. After setting, hold "SET" button or if no button press for 30 seconds, exit the setting mode.

Alarm Setting:

1. In any mode (except FM mode), press "SET" button and select to display AL 1 or AL 2 time, hold "SET" button to enter AL1 or AL2 time setting
Setting menu order: Hour→Minutes→ AL ON/OFF
2. Under setting mode, press + or – button to adjust the time; Press "SET" button to confirm and move to next time; Hold + or – button to adjust quickly.
3. After setting, hold "SET" button or if no button press for 30 seconds, exit the setting mode.
4. When the alarm sounds, press "LIGHT/SNOOZE" button to activate the snooze function (The Snooze icon will flash and silence the alarm for 5 minutes then sound again). Press "LIGHT/SNOOZE" to deactivate function.
5. When the alarm sounds, press any button except "LIGHT/SNOOZE" to stop ringing; if no button press, the alarm will automatically stop ringing after one minute.

FM Setting

1. Under FM radio mode, press  to enter automatic channel selection and store radio stations.
2. Under FM radio mode ,press “+”“-” to switch radio station, hold“+”“-”to adjust volume .

Bluetooth Function

1. Enter Bluetooth mode with a prompt tone and Bluetooth indicator icon will flash
2. Activate the Bluetooth function on your mobile device to pair
3. Once there is connection with a prompt tone, the Bluetooth indicator icon will be solid.
4. Press PREV / V- button, it will automatically go to the previous song,
5. Press the NEXT / V + button to automatically go to the next song .
6. During music play, hold“+”“-”to adjust volume
7. Press “ PLAY” button to pause and repress and continue to play
5. If a phone call is received with “dodo” sound, press “PLAY” to answer the call, press again to hang up; Hold “PLAY” to reject the call . Double press “PLAY” to call back.

MP3 Function:

- 1.Enter TF mode, or in any mode, insert TF card, it will enter TF mode, TF indicator light will be on, Bluetooth is disconnected, Bluetooth sound is turned off.
2. Pull out the TF card and it automatically enter the Bluetooth mode. Without be paired, it will automatically exit Bluetooth mode to entre time mode.

Note: Before disconnect external power, push the sliding switch to OFF (on the back side); After connect the external power again, push the sliding witch to ON (on the back side), the time and alarm time will be memorized and go normally.

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.