
MAKIBES

User manual



MAKIBES M2

Wireless Speaker

Thank you for choosing Makibes M2 Wireless Speaker. M2 is equipped with Bluetooth 5.0 for optimal connection & pairing with your Bluetooth enabled device. Please read the user manual before use and keep it handy for future reference.

FEATURES


- Silicon covered exterior with IPX7 water-resistance rating.
- Passive radiator for deep bass.
- True Wireless Stereo (TWS) for stereo surround sound.
- Output up to 40W.
- Up to 18 hours of playtime
- Bluetooth 5.0.
- Equipped with USB Type-C port supporting DC 5V/2A input charging.

PACKAGE CONTENTS

1 x M2 wireless speaker
1 x Charging cable
1 x 3.5mm AUX cable
1 x Lanyard
1 x Warranty card

BUTTON CONFIGURATIONS

① Volume+/Next track
② Volume-/Previous track
③ Play/Pause/Hands-Free call/Voice Assistant
④ Music playing mode/Bluetooth disconnect
⑤ TWS/Tri-bass effects: Vocal, Extra Bass, Light music.
⑥ Power ON/OFF/Reset
⑦ Charging port
⑧ Micro SD/TF card slot
⑨ AUX-in
⑩ Indicator



1

	Hold and press to choose previous track.
	Press to Volume down.
	Reset: Press and hold for 5 seconds.
	Hold and press to choose next track.
	Press to Volume up.
	Turn on NFC and Bluetooth on the mobile phone, and put it close to the NFC sensing area of the speaker, then you can connect to NFC.

SPEZIFIKATIONEN

Model	M2
Bluetooth	5.0
Transmission range	12m/39ft (open area)
Waterproof	IPX7
Output	20W*2
Playtime	Up to 18 hours
Power supply	DC 5V/2.0A Max
Battery capacity	2600mAh*2
Charging time	About 3x1 hours
Loudspeaker size	52x9.3mm
Distortion	≤1.0%
Frequency	20Hz-16kHz
Dimension	8.11x 2.51 x 3.14in / 206 x 64 x 80mm
Product weight	700g / 24.69 oz

2

FUNCTIONS

	ON: Press the POWER button for 1 second.	
	OFF: Hold and press the POWER button for 3 seconds.	
	Reset: Press and hold for 8 seconds. （In the case of speaker crash）	
EQ	Switch sound effects	Short press EQ button to switch sound effect（Vocal, Extra Bass, Light music）. The vocal is the default sound effects.（No light）, Extra bass (Green light）, Light music (White light)
	TWS	TWS disconnect: Long press EQ button to disconnect two speakers from each other.
		TWS connect: Please turn on the two speakers at the same time. After turning on the two speakers, the two speakers are disconnected to the mobile phone. Press one of the speakers and double-tap the EQ button twice, and there will be a beep sound, and then the yellow light flashes. After the pairing is successful, the yellow lights of the two speakers are on at the same time, the Bluetooth light of the host flashes. When the mobile phone and the speaker are connected, and the Bluetooth light of the auxiliary machine goes out.
M	Switch playing mode	During Bluetooth mode, press to switch to Micro SD/TF card mode.
	Disconnect Bluetooth	Press and hold for 3 seconds.
⏯	Play/Pause: Press play/pause button.	
	Answer/Hang up a phone call: During an incoming call, press to answer or hang up the phone call.	
	Reject a phone call: Hold for 2 seconds to reject the incoming call.	
	Redial: During Bluetooth connected mode, double press quickly to redial the last dialed number.	
	Voice Assistant: With the Bluetooth connected, Press and hold 2 seconds.	

3

BLUETOOTH PAIRING

Turn ON the speaker, the blue LED light flashes, and then activate the Bluetooth in your device. Go to device's Bluetooth settings, scan for new Bluetooth devices and upon discovering the device 'Makibes M2', click to pair with it. Hold Play/Pause button for 3 seconds to disconnect the Bluetooth.

TWS MODE

What is TWS?
TWS is true wireless stereo, which means two M2 Bluetooth speakers are able to be paired and then play music synchronously, providing stereo surround sound.

How to pair two M2 speakers?

1. Turn ON two speakers and confirm they are disconnected to any bluetooth device.
2. Press one of the speakers and double-tap the EQ button twice, and there will be a beep sound, and then the yellow light flashes. After the pairing is successful, the yellow lights of the two speakers are on at the same time, the Bluetooth light of the host flashes. When the mobile phone and the speaker are connected, and the Bluetooth light of the auxiliary machine goes out.
3. Go to device's Bluetooth settings, scan for 'Makibes M2', click to pair with it. The Bluetooth indicator of main speaker being steady ON blue means the connection to Bluetooth device is successful. And when start to play music, this blue indicator will flash slowly.

How to disconnect TWS?

During TWS mode, long press the EQ button of one speaker, then the TWS will be disconnected.
Note: Once two speakers are well paired for the first time, they will be automatically paired next time without the above pairing operations as long as they are ON.

AUX-IN MODE

The speaker also features one AUX audio in port. Simply connect the speaker with your mobile phone/MP3 player/PC/laptop with the 3.5mm audio jack cable. Once the blue light flashes slowly, then you can play music via the wired connection.

MICRO SD/TF CARD MODE

Press the Power ON/OFF button to switch Bluetooth Mode to Micro SD/TF card Mode. The memory capacity of Micro SD/TF card should be no more than 64GB.

LED

Bluetooth: Blue light flashes quickly for waiting for pairing mode. Blue light kept ON for connected successfully.
Micro SD/TF & AUX-IN: Blue light flashes slowly.
TWS: The TWS indicator flashes yellow slowly for pairing. Yellow light kept ON for paired successfully. Light goes off for canceling the pair.
Charging: Red light ON for charging. Red light goes OFF for charging completion.

SLEEP MODE

The M2 speaker will go into Sleep Mode if it does not pair with any device through Bluetooth or after paired over Bluetooth, there is nothing is played within 10 minutes that helps to save battery power. When you need to use it, press the Power ON/OFF button to turn it on.

TIPS

Because of the powerful output of this speaker, please do not be too close to the speaker and keep an appropriate distance away to listen to the music. To avoid any discomfort caused by excessive sound, it is recommended to listen to music at a suitable volume.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO INSTRUCTIONS.
To prevent possible hearing damage, do not listen at high volume levels for long periods.

CARE & MAINTENANCE

Please keep this manual handy for future reference. To clean the Makibes M2 Bluetooth Speaker use a lightly dampened cloth in water to clean the exterior in-case it gets dirty. Do not use any form of detergents or cleaning material to clean the product, any type of chemical may make this device unusable. Do not disassemble this product. It contains no user serviceable parts. Do not drop or jump on it, treat it with care for the best performance. Keep the product in a dry location. Dust, dirt & moisture from humidity can accumulate on the body of the product if kept at an unfriendly place. Do not dispose this product in fire, batteries may explode or leak.

WARRANTY INFORMATION

Your 'Makibes M2 Bluetooth Speaker' is warranted to the original owner for 12 months from the date of purchase against defects in material and workmanship under normal use and service. Should your product prove defective within 12 months from the date of purchase, return the defective part or unit, freight prepaid along with an explanation of the claim. Please pack the product carefully to avoid damages in transit. Under this warranty, Makibes will repair or replace any parts found to be defective due to manufacturer's defect. This warranty extends only to personal use and does not extend to any product that has been used for commercial use, rental use, or use which is not intended. There are no warranties other than that expressly set forth herein. This warranty is not transferable. Makibes is not responsible in any way for damages, losses or inconveniences caused by equipment with the User Manual or any additional safety, use, or warnings included in the product materials. Further, Makibes is not liable for incidental use of this product and any liability shall not exceed the purchase price of the product.
This Warranty gives you specific legal rights. You may also have other rights which vary from state to state.

THIS WARRANTY DOES NOT APPLY TO THE FOLLOWING

- Damage due to accident, misuse, abuse, alterations or vandalism.
- Improper or inadequate maintenance.
- Unauthorized modifications or commercial use.
- Damage in return transit.
- Unsupervised use by children under 18 years of age.

(Makibes and its subsidiaries assume no liability for damage caused by the use of the Makibes M2 Bluetooth Speaker other than for its intended use or as instructed above in the User Manual.)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna. •Increase the separation between the equipment and receiver. •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. •Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

MAKIBES

SHENZHEN VALUE IN ACTION TECHNOLOGY CO.,LTD.
A3 Hekan Industrial Building, 41# Wuhe Str, Banlian, Longgang District, 518129 Shenzhen, China
Email: support@makibes.com
800-270-1082 (USA & Canada)
+86-755-23605740 (Global)


EU REP:
AMZLAB GmbH
Laubenhof 23,45326 Essen

Made in China

4

MAKIBES

User manual



MAKIBES M2

Wireless-Lautsprecher

Vielen Dank, dass Sie sich für Makibes M2 Wireless Speaker entschieden haben. M2 ist mit Bluetooth 5.0 für eine optimale Verbindung und Kopplung mit Ihrem Bluetooth-fähigen Gerät ausgestattet. Bitte lesen Sie vor der Verwendung die Bedienungsanleitung und halten Sie sie zum späteren Nachschlagen bereit.

FEATURES


- Silikonbeschichtetes Äußeres mit IPX7-Wasserdichtigkeit.
- Passiver Strahler für tiefen Bass.
- True Wireless Stereo (TWS) für Stereo-Surround-Sound.
- Leistung bis zu 40W.
- Bis zu 18 Stunden Spielzeit.
- Bluetooth 5.0.
- Ausgestattet mit einem USB-Typ-C-Anschluss, der das Laden des DC 5V / 2A-Eingangs unterstützt.

PACKUNGSINHALT

1 x M2 Funklautsprecher
1 x Ladekabel
1 x 3.5 mm AUX-Kabel
1 x Lanyard
1 x Garantiekarte

TASTENKONFIGURATIONEN

① Volumen + / Nächster Titel
② Volumen- / Vorheriger Titel
③ Pauser Spielen / Freisprechanruf / Sprachassistent
④ Musikwiedergabemodus / Bluetooth-Verbindung trennen
⑤ TWS / Tri-Bass-Effekte: Gesang, Extra-Bass, Unterhaltungsmusik.
⑥ Einschalten / Ausschalten / Sich ausruhen
⑦ Ladeanschluss
⑧ Mikro-SD / TF-Kartensteckplatz
⑨ AUX-in
⑩ Indikator



5

	Halten Sie gedrückt und drücken Sie, um den vorherigen Titel auszuwählen.
	Drücken Sie, um die Lautstärke zu verringern.
	Zurücksetzen: 5 Sekunden lang gedrückt halten.
	Halten Sie gedrückt und drücken Sie, um den nächsten Titel auszuwählen.
	Drücken Sie, um die Lautstärke zu erhöhen.
	Schalten Sie NFC und Bluetooth auf dem Mobiltelefon ein und platzieren Sie es in der Nähe des NFC-Erfassungsbereichs des Lautsprechers.

SPEZIFIKATIONEN

Modell	M2
Bluetooth	5.0
Übertragungsbereich	12m/39ft (offene Fläche)
Wasserdicht	IPX7
Ausgabe	20W*2
Spielzeit	Bis zu 18 Stunden
Netzteil	DC 5V/2.0A Max
Batterie Kapazität	2600mAh*2
Akku Ladezeit	Etwa 3x1 Stunden
Lautsprechergröße	52x9.3mm
Verzerrung	≤1.0%
Frequenz	20Hz-16kh
Abmessungen	8.11x 2.51 x 3.14in / 206 x 64 x 80mm
Produktgewicht	700g / 24.69 oz

6

FUNKTIONEN

	EIN: Drücken Sie die POWER-Taste 1 Sekunde lang.	
	AUS: Halten Sie die POWER-Taste 3 Sekunden lang gedrückt.	
	Zurücksetzen: 8 Sekunden lang gedrückt halten. （Bei Lautsprecherabsturz）	
EQ	Soundeffekte wechseln	Drücken Sie kurz die EQ-Taste, um den Soundeffekt umzuschalten (Gesang, Extra-Bass, Unterhaltungsmusik). Die Stimme ist der Standard-Soundeffekt. (Kein Licht). Extra Bass (Grünes Licht). Leichte Musik (Weißes Licht)
	TWS	TWS-Trennung: Drücken Sie lange die EQ-Taste, um zwei Lautsprecher voneinander zu trennen.
		TWS verbinden: Bitte schalten Sie die zwei Lautsprecher zur gleichen Zeit. Nach dem Einschalten der beiden Lautsprecher werden die beiden Lautsprecher vom Mobiltelefon getrennt. Drücken Sie einen der Lautsprecher und tippen Sie zweimal zweimal auf die EQ-Taste. Es ertönt ein Piepton, und dann blinkt das gelbe Licht. Nachdem das Pairing erfolgreich war, leuchten die gelben Lichter der beiden Lautsprecher gleichzeitig und das Bluetooth-Licht des Hosts blinkt. Wenn das Mobiltelefon und der Lautsprecher verbunden sind und die Bluetooth-Anzeige des Zusatzgeräts erlischt.
M	Spielmodus wechseln	Drücken Sie im Bluetooth-Modus, um in den Micro SD / TF-Kartenmodus zu wechseln.
	Trennen Sie Bluetooth	Halten Sie 3 Sekunden lang gedrückt.
⏯	Wiedergabe / Pause: Drücken Sie die Wiedergabe- / Pause-Taste.	
	Annehmen / Auflegen eines Anrufs: Drücken Sie während eines eingehenden Anrufs, um den Anruf anzunehmen oder aufzulegen.	
	Anruf ablehnen: Halten Sie die Taste 2 Sekunden lang gedrückt, um den eingehenden Anruf abzulehnen.	
	Wahlwiederholung: Drücken Sie im Bluetooth-Verbindungsmodus schnell zweimal, um die zuletzt gewählte Nummer erneut zu wählen.	
	Sprachassistent: Halten Sie bei verbundenem Bluetooth 2 Sekunden lang gedrückt.	

7

BLUETOOTH PAARUNG

Schalten Sie den Lautsprecher ein, die blaue LED blinkt und aktivieren Sie dann Bluetooth in Ihrem Gerät. Gehen Sie zu den Bluetooth-Einstellungen des Geräts, suchen Sie nach neuen Bluetooth-Geräten und klicken Sie, um das Gerät zu koppeln, nachdem Sie das Gerät 'Makibes M2' entdeckt haben. Halten Sie die Play / Pause-Taste 3 Sekunden lang gedrückt, um die Bluetooth-Verbindung zu trennen.

TWS-MODUS

Was ist TWS?
TWS ist echtes kabelloses Stereo, dh zwei M2-Bluetooth-Lautsprecher können gekoppelt werden und dann synchron Musik abspielen, um Stereo-Surround-Sound bereitzustellen.

Wie kopple ich zwei M2-Lautsprecher?

1. Schalten Sie zwei Lautsprecher ein und stellen Sie sicher, dass sie nicht mit einem Bluetooth-Gerät verbunden sind.
2. Drücken Sie auf einen der Lautsprecher und tippen Sie zweimal zweimal auf die EQ-Taste. Es ertönt ein Piepton, und dann blinkt das gelbe Licht. Nachdem das Pairing erfolgreich war, leuchten die gelben Lichter der beiden Lautsprecher gleichzeitig und das Bluetooth-Licht des Hosts blinkt. Wenn das Mobiltelefon und der Lautsprecher verbunden sind und die Bluetooth-Anzeige des Zusatzgeräts erlischt.
3. Gehen Sie zu den Bluetooth-Einstellungen des Geräts, suchen Sie nach "Makibes M2" und klicken Sie, um es zu koppeln. Die Bluetooth-Anzeige des Hauptlautsprechers leuchtet blau. Dies bedeutet, dass die Verbindung zum Bluetooth-Gerät erfolgreich hergestellt wurde. Und wenn Sie mit der Musikwiedergabe beginnen, blinkt diese blaue Anzeige langsam.

Wie trenne ich TWS?

Drücken Sie im TWS-Modus lange die EQ-Taste eines Lautsprechers, um den TWS zu trennen.
Hinweis: Sobald zwei Lautsprecher zum ersten Mal gut gekoppelt sind, werden sie beim nächsten Mal automatisch ohne die oben genannten Kopplungsvorgänge gekoppelt, solange sie eingeschaltet sind.

AUX-IN-MODUS

Der Lautsprecher verfügt außerdem über einen AUX-Audioeingang. Schließen Sie den Lautsprecher einfach mit dem 3,5-mm-Audiokabel an Ihr Mobiltelefon / MP3-Player / PC / Laptop an. Sobald das blaue Licht langsam blinkt, können Sie Musik über die Kabelverbindung abspielen.

MICRO SD / TF-KARTENMODUS

Drücken Sie die Ein- / Aus-Taste, um den Bluetooth-Modus in den Micro SD / TF-Kartenmodus zu schalten. Die Speicherkapazität der Micro SD / TF-Karte sollte nicht mehr als 64 GB betragen.

LED

Bluetooth: Blaues Licht blinkt schnell, um auf den Pairing-Modus zu warten. Blaues Licht leuchtet für eine erfolgreiche Verbindung.
Micro SD / TF & AUX-IN: Blaues Licht blinkt langsam.
TWS: Die TWS-Anzeige blinkt zum Pairing langsam gelb. Gelbes Licht leuchtet für erfolgreiches Pairing. Das Licht geht aus, um das Paar abzubrechen.
Laden: Rotes Licht leuchtet zum Laden. Das rote Licht erlischt, um den Ladevorgang abzuschließen.

SCHLAFMODUS

Der M2-Lautsprecher wechselt in den Ruhemodus, wenn er nicht über Bluetooth mit einem Gerät gekoppelt wird oder nachdem er über Bluetooth gekoppelt wurde, wird innerhalb von 10 Minuten nichts abgespielt, was zur Einsparung von Batteriestrom beiträgt. Wenn Sie es benötigen, drücken Sie die Ein- / Aus-Taste, um es einzuschalten.

TIPPS

Seien Sie wegen des starken Ausgangs dieses Lautsprechers nicht zu nahe am Lautsprecher und halten Sie einen angemessenen Abstand ein, um Musik zu hören. Um Unannehmlichkeiten durch übermäßigen Klang zu vermeiden, wird empfohlen, Musik mit einer geeigneten Lautstärke zu hören.

VORSICHT

EXPLOSIONSRISIKO, WENN DIE BATTERIE DURCH EINEN FALSCHEN TYP ERSETZT WIRD. ENTSORGUNG VON GEBRAUCHTEN BATTERIEN NACH ANWEISUNGEN.
Hören Sie nicht lange mit hoher Lautstärke, um mögliche Hörschäden zu vermeiden.

PFLEGE & WARTUNG

Bitte halten Sie dieses Handbuch zum späteren Nachschlagen bereit. Verwenden Sie zum Reinigen des Makibes M2 Bluetooth-Lautsprechers ein leicht angefeuchtetes Tuch in Wasser, um das Äußere zu reinigen, falls es schmutzig wird. Verwenden Sie zum Reinigen des Produkts keine Reinigungsmittel oder Reinigungsmittel. Jede Art von Chemikalie kann dieses Gerät unbrauchbar machen. Zerlegen Sie dieses Produkt nicht. Es enthält keine vom Benutzer zu wartenden Teile. Lassen Sie sich nicht fallen und springen Sie nicht darauf. Behandeln Sie es sorgfältig, um die beste Leistung zu erzielen. Bewahren Sie das Produkt an einem trockenen Ort auf. Staub, Schmutz und Feuchtigkeit durch Feuchtigkeit können sich auf dem Körper des Produkts ansammeln, wenn sie an einem unfreundlichen Ort aufbewahrt werden. Entsorgen Sie dieses Produkt nicht im Feuer, da die Batterien explodieren oder auslaufen können.

GARANTIEINFORMATIONEN

Ihr Ihrer "Makibes M2 Bluetooth-Lautsprecher" wird dem ursprünglichen Besitzer eine Garantie von 12 Monaten ab Kaufdatum gegen Material- und Verarbeitungsfehler bei normalem Gebrauch und Service gewährt. Sollte sich Ihr Produkt innerhalb von 12 Monaten ab Kaufdatum als defekt herausstellen, senden Sie das defekte Teil oder die defekte Einheit mit vorausbezahlter Fracht und einer Erklärung des Anspruchs zurück. Bitte verpacken Sie das Produkt sorgfältig, um Transportschäden zu vermeiden. Im Rahmen dieser Garantie repariert oder ersetzt Makibes alle Teile, die aufgrund eines Defekts des Herstellers als defekt befunden wurden. Diese Garantie erstreckt sich nur auf den persönlichen Gebrauch und nicht auf Produkte, die für den gewerblichen Gebrauch, zur Vermietung oder für nicht bestimmungsgemäße Zwecke verwendet wurden. Es gibt keine anderen Garantien als die hier ausdrücklich dargelegten. Diese Garantie ist nicht übertragbar. Makibes haftet in keiner Weise für Schäden, Verluste oder Unannehmlichkeiten, die durch Geräte mit dem „Benutzerhandbuch" oder zusätzliche Sicherheits-, Verwendungs- oder Warnhinweise in den Produktmaterialien verursacht werden.

Darüber hinaus haftet Makibes nicht für die zufällige Verwendung dieses Produkts und eine Haftung darf den Kaufpreis des Produkts nicht überschreiten.
Diese Garantie gewährt Ihnen bestimmte gesetzliche Rechte. Möglicherweise haben Sie auch andere Rechte, die von Bundesstaat zu Bundesstaat unterschiedlich sind.

DIESE GARANTIE GILT NICHT FÜR FOLGENDES

- Schäden durch Unfall, Missbrauch, Missbrauch, Veränderungen oder Vandalismus.
- Unsachgemäße oder unzureichende Wartung.
- Nicht autorisierte Änderungen oder kommerzielle Nutzung.
- Schäden beim Rücktransport.
- Unbeaufsichtigte Verwendung durch Kinder unter 18 Jahren.

(Makibes und seine Tochterunternehmen übernehmen keine Haftung für Schäden, die durch die Verwendung des Makibes M2 Bluetooth-Lautsprechers verursacht werden, außer für den beabsichtigten Gebrauch oder wie oben im Benutzerhandbuch beschrieben.)

MAKIBES

SHENZHEN VALUE IN ACTION TECHNOLOGY CO.,LTD.
A3 Hekan Industrial Building, 41# Wuhe Str, Banlian, Longgang District, 518129 Shenzhen, China
Email: support@makibes.com
800-270-1082 (USA & Canada)
+86-755-23605740 (Global)

EU REP:
AMZLAB GmbH
Laubenhof 23,45326 Essen

Made in China

8