



INSTRUCTION MANUAL

EXTREME WILD

1:20 2.4GHz/RC/CAR

8+
AGES

Thank you for choosing our product. Please read this instruction manual carefully before use the product as it contains all the information about how to play this product correctly.


SAFETY CAUTIONS:

1. Do not give this product to children under 8 years.
2. Adult's supervision is required when playing.
3. This product should be used in a safe way to avoid electric shock.
4. Do not play the car on grass, sand, rocks or through water.
5. Do not hit the car into any hard object.

BATTERY WARNING:

1. Batteries should be intal with correct polarity.
2. Do not mix different brand of batteries or new and used batteries.
3. Non-rechargeable battery are not to recharged.
4. Rechargeable batteries are only charged under adult's supervision.
5. Rechargeable batteries need to remove from product before it is charged.
6. The supply terminals are not to short-circuited.
7. Remove the batteries from the product when it is not used or when the batteries are exhausted.
8. Batteries should be installed by an adult.
9. Do not dispose batteries in fire.

PARTS IDENTITY



Vehicle




Controller



Instruction Manual


HOW TO INSTALL THE BATTERY INTO CAR

1




Turn off the car

2




Open the battery
compartment cover

3



Install 4xAA
batteries into the car


4



Fix the battery
compartment cover


HOW TO INSTALL THE BATTERY INTO CONTROLLER

1




Open the battery
compartment cover

2





Install 2xAAA
batteries into the controller

3



Fix the battery
compartment cover

KEY FUNCTION OF THE PRODUCT



HOW TO PLAY

1. Turn on the vehicle, then turn on the controller. The indicator light on the controller will flash quickly, after the car and controller are matched frequency, the lights will keep on.
2. If you have more than one vehicle, please match frequency one by one.
3. Please turn off both vehicle and controller and re-start frequency matching if you want to play it with another 2.4GHz controller.
4. Press "Forwards" button, the car will move forwards.
5. Press "Backwards" button, the car will move backwards.
6. Press "Right" button, the car will turn right
7. Press "Left" button, the car will turn left

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: FOR SAFETY REASONS,
REMOVE ALL TAGS, LABELS AND
PLASTIC FASTENERS BEFORE
GIVING THIS TOY TO YOUR CHILD.

WARNING:
CHOKING HAZARD- small parts,
Not for children under 3 years.

MADE IN CHINA