





Label Area
49.49 x 19.24 mm

Scan QR to register
device in Command

S/N: WWW-WWW-WWW
MAC: E0:A7:00:XX:XX:XX

QR
Should direct to:
vkda.co/s/XXXX-XXXX-XXXX
—
XXXX-XXXX-XXXX should be
replaced with serial number.



Label Area
49.102 x 48.18 mm

Verkada
BE32 8-Zone Alarm Expander

Model: BE32-HW
P/N: 60-B0801-R1
Power In: DC 10V~36V VDC input
S/N: XXXX-XXXX-XXXX

FCC ID: 2AWUJ60801
IC: 26271-60801

ENGINEERING SAMPLE
NOT FOR RESALE

Designed in California | Made in Taiwan

QR
Should direct to:
vkda.co/s/XXXX-XXXX-XXXX
—
XXXX-XXXX-XXXX should be
replaced with serial number.

QYY
Q represents quarter, each
quarter can be represented
by character "A, B, C, D".
(For example, fourth quarter
of 2021 should be "D21".)

NOT FINAL ART
FOR QUOTING, PROTOTYPING,
AND TESTING PURPOSES ONLY.



Kuribo – BE32 8-Zone Alarm Expander Product Label