



REDDY RACER REMOTE CONTROL DRAGSTER

AGES
2+


INTRODUCTION

Congratulations on your purchase of your Reddy Racer Remote Control Dragster! Please read all instructions and warnings on this sheet before you start. Keep this instruction sheet as it contains important information for future reference.

CONTENTS

- 1x R/C Reddy Racer
- 1x Remote

PLAY



- When 2.4Ghz paired successfully, for example, the remote will have a sound and the flashing light of car changes to solid.
 - Press the left white button to go forward.
 - Press the right white button to make a circle.
 - Press any of the center buttons for fun sounds.
- Note:** For best results, operate on a smooth, hard surface.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Model No.: 1014451

FEATURES


- Easy to use controls
- Working night lights
- Realistic sounds

INSTALLING BATTERIES


The cars require 4 AA 1.5V battery (not included) and the remotes require 2 AA 1.5V batteries (included).

Use a Phillips head or Cross screwdriver to loosen the screw securing the battery cover plate. Insert the batterie(s), ensuring the correct polarity. Replace the battery cover and tighten the screw.

CAR



REMOTE CONTROL



NIGHTLIGHT

If batteries are inserted correctly, press the spoiler to activated the nightlight whatever the car is turned on or off. Press one by one to adjust the brightness.

BATTERY WARNINGS

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries using the correct polarity.
- Do not short-circuit the battery supply terminals.
- Remove batteries before storing.
- Recycle or dispose of batteries according to federal, state, and local laws.
- Do not dispose of batteries in fire, batteries may explode or leak.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.
- Do not attempt to charge non-rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Exhausted batteries are to be removed from the toy.
- Alkaline batteries are recommended. Use only the specified voltage.
- Keep these instructions for future reference.

SAFETY WARNINGS

- For indoor use only.
- Do not expose to moisture or extreme temperatures
- Do not use people or animals as obstacles.
- Do not run car into furniture objects or hard surfaces as this will cause damage to both the objects and car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while car is switched to "ON".
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating car.
- Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately.