

S2 使用说明书

Mode Instruction:

This speaker is with Bluetooth Speaker Mode and Alarm Setting Mode.

Bluetooth Speaker Mode: long press  button to turn on, the speaker is in the Bluetooth Speaker Mode at this status, Alarm can't be set.

Alarm Setting Mode: long press  button to turn off the speaker, at this status the alarm and the time can be set, while Bluetooth speaker is not functional.

Overview and Intruction for Use

- : Volume Down/Time Backward

+ : Volume Up/Time Forward

: On/Off/Play/Pause/Hands Free Phone Call/Time and Alarm Setting

M: Mode Switch/Long Press Search Radio when it's under FM mode

: Previous Song/Long Press for Back Ground Light On and Off

: Next Song/Long Press for Light Brightness Adjusting (3 brightness level available,the speaker is in lowest one)

: Long press these two at same time can turn off the whole machine(include alarm clock)

TF: TF Card Slot

USB: USB disk socket

DC: Charging Slot

AUX: Aux Line In/reset

Note: It will be in Time Mode after power ON. And will get into sleep state automatically if with no operation in 10 minutes. (will back to Time mode by pressing any button)

Time/Alarm Setting Instruction:

1. Press  for 3 seconds to turn the power ON(will in time mode), press  again, the number will start flashing, press  to set hours/minutes/Time Format; Alarm 1 hours/minutes, Alarm 1 Loop, Alarm 1 rings; Alarm 2 hours/minutes, Alarm 2 Loop, Alarm 2 rings. Press -/+ to adjust the content; Press  to confirm after setting finished.
2. Alarm On/Off Setting: OFF is Alarm Off, ON is Alarm On, there will be a alarm icon  on the screen.
3. Alarm Loop Setting: ONE indicates it will ring only once. Loop indicates it will ring in loop.(Ten minutes for one loop, it will loop five times)
4. Alarm rings: It has 5 rings for this machine. You can also choose"TF" when setting it(should always have a TF card in the speaker, otherwise it will ring in first sound when time is up)
5. Press any button to stop the alarm ring

Bluetooth Speaker Instruction:

How to connect the mobile phone by Bluetooth?

1. Long press  for 3 seconds to turn the power ON, there will be a turn on prompt sound. In this status, the backside indicator light in blue and flash slowly. Press **M**, the speaker will into Bluetooth connection mode
2. Turn on the Bluetooth of mobile phone and search S2, and then match the speaker to mobile phone. There will be a prompt sound after connection succeeded, and the blue indicator light will stop flashing. Bluetooth pairing time is about 1 minute. It will be different for different mobile phones as the Bluetooth version is different.
3. Note: There is a memory function for the Bluetooth speaker. Turn off the Bluetooth of the previous mobile phone before connecting to another one.
4. Buttons control Instruction: press button  for last song, press button  for next song; press button  for volume down, press button  for volume up; Press button  for pause / play.
5. Short press button  to answer the phone call, long press button  to refuse the phone call. Press button  to finish the phone call, the speaker will be back to work
6. Long press  for 3 seconds to turn off the speaker. (The speaker will turn off automatically if it doesn't work and have got no operate instruction within 10 minutes.)

How to Line in by AUX (external audio input)?

This speaker can connect to all kinds of audio devices (such as mobile phones, pad, MP3 player, cassette player, CD player, radio, etc.). With 3.5mm AUX plug in the earphone jack of the audio device and the other end in the AUX slot of the speaker, there will be a prompt sound. Then it can play under AUX line in mode.

How to use Micro SD/TF Card?

Insert the Micro SD/TF Card into the TF slot of speaker, there will be a prompt sound, and then play the audio files in the card.

It supports following format file: MP3 WAV.

It support maximum 32GB TF card

FM Radio

Long press button **M** in the radio mode, it will search the radio automatically. Once finished it, press button  to play the radio.

How to charge?

1. The Speaker will make a prompt sound and turn off automatically when the battery is low. Insert one end of the cable to the charging slot of speaker, the USB plug to the computer or the mobile charger (5V 1A). The front indicator light on red indicates it's charging, the front indicator light off indicates it's fully charged. (The charging voltage is 5V. The speaker's internal chip will be burned out and couldn't work normally if using higher charger)
2. It takes around 3 hours for fully charged. It could work about 5-6 hours at maximum volume, and 8-10 hours at default volume. The standby time is about 300 hours.

Reset Function:

When the buttons are out of control, the speaker may get into stuck. Please check if the battery ran out. If battery ran out, please charge it. If the stuck happen while the battery is full, please insert a pointy tool into the reset hole and long press for 3 seconds. Then turn on the speaker.

Using for Tablet PC/Notebook:

Connect the speaker and Tablet PC/Notebook by using the 3.5mm AUX cable.

F&Q

1. It cannot be matched with the devices by Bluetooth: (1) turn off the speaker and mobile phone, and then turn on both, rematch. (2) Too many Bluetooth devices surround, turn off the other Bluetooth devices
2. Sound too small or distortion too much: (1) may be battery runs out. Please charge it. (2) Turn up the volume of the mobile phone.
3. Sound off and on: please check if the range between the speaker and the device is more than 10 meters. Or check if there are any barrier between the speaker and the device

Specification			
Model number:	S2	Power output:	3W*2
Bluetooth version:	4.2	Bluetooth range:	≤10 meter
Battery:	3.7V 1800mAh	Power input:	DC 5V 2A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.