


User guide / Guia de usuario / Guia do utilizador
Guide de l'utilisateur / Guida all'uso / Benutzerhandbuch
Gebruiksaanwijzing / Podręcznik użytkownika

PIC 01



Slim LED walkie-talkie watch

ENGLISH

INSTRUCTIONS FOR USE

This set includes 2 walkie-talkie watch; these are communication devices that operate on mobile radio frequencies. They come with 22 channels and a LED display, allowing you to communicate over long distances for free (up to 200M in open areas).

NOTE: Please read these operating instructions carefully before using the equipment and keep them for future reference.

SAFETY INSTRUCTIONS

Read carefully before first use and retain this instruction manual. Children should not use this product without the presence of an adult.

Rechargeable batteries are also suitable for this product. Non-rechargeable batteries should not be recharged. If rechargeable batteries are used and if power is insufficient, recharge them under adult supervision in a dedicated charger. Do not mix different types of batteries or new and used batteries. Properly dispose of empty batteries in designated locations. Contact your local authority or retailer for advice on recycling. To avoid accidents, do not dispose of the product in fire or water. Batteries should not be disposed of with household waste. This product is not suitable for children under 3 years of age.

BATTERY WARNING

- Battery required: 1x402030 rechargeable, non-replaceable lithium battery (included).
- If the battery runs out, it must be charged within 1 month, otherwise, the battery will not work.
- Even if the power is sufficient and the walkie-talkies has not been used, it must be charged within 6 months, otherwise, the battery will not work.
- Do not use the walkie-talkies during charging, otherwise, it will damage the battery.

ITEM DESCRIPTION (PIC 01)

- | | |
|----------------|-------------------------|
| 1. LED Display | 6. Speaker |
| 2. UP button | 7. Power button |
| 3. Down button | 8. Type-C charging port |
| 4. Menu button | 9. Antenna |
| 5. Talk button | 10. Microphone |

The toy should only be connected to equipment bearing one of the following symbols :  or 

HOW TO USE

1. When the walkie-talkie watch is powered off, press the up(2)/down(3) buttons to display time, press again to turn off the time display or the time will automatically power off after no operation for 20 seconds.

2. Press and hold the Power button(7) to turn on/off the walkie-talkies watch.

When the walkie-talkie watch is powered on, all the lights will go out after no operation for 1 minute.

3. When the walkie-talkie watch is powered on, press the up(2)/down(3) buttons to choose the volume; V(volume)01~08 indicate the current volume.

4. When the walkie-talkie watch is powered on, press the Power button(7) to display the current battery level. The battery level is divided into 4 grades, which are 0/00/000/0000 (1).

5. Press and hold the Talk button(5), and speak to Microphone(10). Double press the Talk button(5), both of the two walkie-talkies watch will ring; The voices and the rings come from the speaker(6).

ENGLISH

6. Press and hold the Menu button(4) to enter the menu, press Menu button(4) to switch in the following sequence:
CH(channel)01~22 → CA(call)01~10 → Time → Minute → exit and go back standby mode;

In any menu, press the up(2)/down(3) buttons to adjust.

7. Use the Type-C charger to plug into the charging port(8) for charging.

The walkie-talkie watch will automatically power off when charging. If it is turned on.

When charging, the rightmost "0" will keep flashing continuously; four "0" will appear and stop flashing simultaneously after fully charged. Please disconnect the USB cable from the charging port immediately.

8. When the walkie-talkie watch is powered on, the walkie-talkie watch will automatically power off after no operation for 30 minutes.

Walkie-talkies must be set to the same channel in order to make a call

TECHNICAL SPECIFICATIONS

- Channels: 22
- Sub-code: CTCSS only one (118.8HZ)
- Frequency: TX / RX : 462.5500-462.7250MHz, 467.5625-467.7125MHz
- Range: Up to 200M (Open field)
- Battery: 1x402030 rechargeable, non-replaceable lithium battery
- Transmitting power: 462.5500-462.7250MHz: 3.04dBm, 467.5625-467.7125MHz: 2.69dBm
- Modulation type: FM
- Channel spacing: 12.5KHZ
- Charging time: 2 hours
- Usage time (using all the time): 1 hour
- INPUT: ≤5V≤1A
- Over-discharge protection, 2.8V
- Overload protection, 4.2V
- Current limiting protection, 100mAh
- Short-circuit protection
- Battery Charger: walkies with 402030 LIPO battery 3.7V 150mAh 0.555Wh


Disposal of Old Electrical and Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems) This symbol on the product or on its packaging indicates that this product must not be treated as household waste, but must be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Recycling materials will help conserve natural resources. For more detailed information about recycling of this product, please contact your local city office or your household waste disposal service.

The USB charger used with the electric toy should be examined regularly for damage to the power cord, plug, housing or other parts, and in case of damage, should not be used until it has been repaired.

· The toy should only be used with a toy adapter.

· The adapter is not a toy.

· Improper use of the adapter may cause an electric shock.



1001 AVE. OF THE AMERICAS 6TH FLOOR, NY, New York, United States, 10018



BATTERIES
Requires: 1x 3.7V 402030
rechargeable non-replaceable
lithium battery per unit.
Included.



EN Made in China · ES Hecho en China · PT Feito na China · FR Fabriqué en Chine
IT Prodotto in Cina · NL Gemaakt in China · DE Hergestellt in China · PL Wyprodukowane w Chinach

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.