



ZØCHIN Samba Pad Magnetic 2-in-1 Wireless Charger



User manual

Product Overview



What's in the Box:
Samba Pad Magnetic 2-in-1 Wireless Charger *1
Power Adapter *1
User manual *1


Technical Parameters

Input	9V $\approx$ 2.22A
Output	iPhone 7.5W Samsung 10W AirPods 5W
Adapter Model	PA20-US
Input	100-240V~ 50/60 HZ 0.5A _{Max}
Output	9V $\approx$ 2.22A


1.

Connecting

1. Insert the power adapter plug into the DC jack.




2. Use the AC adapter to power the wireless charger.



2.

compatibility


Magnetic charging pad



Designed for:

All iPhones with MagSafe
(iPhone 12 series and later)

Case compatibility:
MagSafe Case for iPhone only.



Designed for:


· AirPods 3, AirPods Pro, AirPods (with wireless charging case)
· Samsung Galaxy Buds, Buds+, Buds Pro, Buds Live
· Soundcore Liberty Air 2, Air 2 Pro, 2 Pro
· All TWS earphones with wireless charging

Case compatibility:
Non-metallic Case thinner than 4mm for your device.

3.

compatibility


Non-Magnetic charging pad



Designed for:

· All iPhones with wireless charging.
(iPhone 8 series and later)
· Samsung Note10+, 10, 9
· Samsung S20+, S20, S20 Ultra, S10+, S10, S10e
· Pixel 4, Pixel 4XL
· LG V30, V30+, G7, V35, V40
· Almost all mobile phones with wireless charging.

Case compatibility:
Non-metallic Case thinner than 4mm for your phone.



Designed for:


· AirPods 3, AirPods Pro, AirPods (with wireless charging case)
· Samsung Galaxy Buds, Buds+, Buds Pro, Buds Live
· Soundcore Liberty Air 2, Air 2 Pro, 2 Pro
· All TWS earphones with wireless charging

Case compatibility:
Non-metallic Case thinner than 4mm for your device.

4.


LED Indicator

1. Plug in the power adapter, the indicator light will light up faintly and keep on.




Weak light

2. When any charging pad is working, the indicator light will be bright, and it will turn into a weak light after 5 seconds.



Bright light 5 seconds


3. When there is metal on the charging pad, or the phone strays too far, the light will flash until the fault is corrected.



Flashing


5.

Charging Mode Settings




Pad Mode


Lay the device flat on the charging pad.



1. Pry from the groove on the side of the charging Pad to lift it up.



2. Pull the charging pad up, you can use the Hover mode.



Hover Mode.

In this mode, you can adjust the angle of the iPhone at will, and even rotate it at will.

Tips: It is highly recommended to charge your device in this mode. Charging is faster in hover mode as it is more conducive to cooling. And easier to place and remove your device.

Important Safety Instructions

- **Avoid dropping.**
- **Do not disassemble.**
- **Do not expose to liquids.**
- **Only use the original power adapter.**
- **This product is suitable for moderate climates only.**
- **The maximum ambient temperature during use of this product must not exceed 40°C.**
- **Open flame sources, such as candles, must not be placed on this product.**
- **Only use a dry cloth or brush to clean this product.**
- **Do not put anything else between your smartphone and the wireless charger such as credit cards, door keys, coins, metal, NFC cards, etc.**
- **Make sure to place the device in the center of the charging pad. Improper placement may result in heat generation or non-charging.**

Tips

Tips:

The charging speed is related to the ambient temperature. For fast charging, please place the wireless charger in a cool and ventilated place. For example, a cool room, or near a fan or air conditioner. Do not expose it to direct sunlight; or place it near hot objects. Such as electrical appliances, heating, fireplaces, etc.



Ventilated



No direct sunlight



Keep cool



Keep away from heat

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement

FCC warning:
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



FCC ID: 2AXAW323

Product name: Samba Pad Magnetic 2-in-1 Wireless Charger

Model: W323

Brand: Zechin

Manufacturer: Longconn Electronics(Shenzhen)Co.,Ltd.

Made in China