

风琴折：51mm×70mm

TWS XY-11

功能操作说明

产品示意图



产品参数

·型号:XY-11

·蓝牙版本:V5.3+EDR

·耳机电池容量:40mAh

·充电仓电池容量:400mAh

·电源输入:5V

·产品质量:约36g

·工作时间:3.5小时

·工作电压:3.3V~4.2V

·充电时长:70分钟

·喇叭阻抗:F6/32欧

·频率响应:20-20KHZ

·传输距离:10米以上

产品包装明细

·蓝牙耳机本体（2PCS）

·耳机充电仓

·Type-c充电线

·使用说明书

·精美包装盒

·耳帽（3对）



产品使用方法

1.开机

步骤一:打开充电仓上盖。

步骤二:取出两个耳机,此时耳机自动开机匹配,等待连接手机手动开机

手动开机

如果耳机不在充电仓里，长按左右耳2秒开机。

2.关机

耳机自动关机

步骤一:使用后,将耳机从耳朵上拿下来。

步骤二:将左右耳机放入充电仓上盖,会自动关机并充电。

手动关机

步骤一:如果耳机处于开机并且相互连接状态,任意长按左/右耳5秒关机。

步骤二:将左右耳机放入充电仓充电。

3.蓝牙配对

步骤一:打开充电仓。

步骤二:将手机蓝牙打开。

步骤三:找到耳机蓝牙名“【XY-11】”。

步骤四:点击连接。

注意：如果已有配对设备信息，耳机会在2-4S内自动回连设备；若未连接到设备，耳机待机3分钟后自动关机。

4.耳机常用操作

(A) 接听/挂断：
单击任意一只耳机一次接听/挂断电话。
长按任意一只耳机1.5S为拒绝接听电话。

(B) 暂停/播放：
音乐播放过程中短按耳机即可暂停/播放音乐。

(C) 上一曲/下一曲：
音乐播放过程中双击左/右耳机即可完成上一曲操作。
音乐播放过程中双击右/左耳机即可完成下一曲操作。

(D) 音量加减：
点击三下左/右耳机可提高音量。
点击三下右/左耳机可减弱音量。

(E) 唤醒语音助手：
长按耳机3秒可激活手机语音助手。

指示灯工作状态说明

工作状态	指示灯状态
USB-5V充电	红灯闪烁充满后常亮
充电仓给耳机充电	绿灯常亮
充电仓低电状态	绿灯闪烁

FCC警告

该设备符合国际立方规则的第15部分。操作应符合以下两种条件：此设备可能不会造成有害的干扰，并且（2）该设备必须接受接收到的任何干扰，包括可能导致不良操作的干扰。
注1:根据FCC规则第15部分，本设备已经过测试，并符合B类数字设备的限制。这些限制旨在为住宅设施提供合理的保护，防止有害干扰。该设备产生、使用并能辐射射频能量。如果不按照说明书安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定的安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰，可以通过关闭和打开设备来确定。鼓励用户尝试通过以下一种或多种措施来纠正干扰：
-重新定位或更换接收天线。
-加大设备与接收器之间的距离。
-将设备连接到与接收器连接的电路不同的电路插座上。
-向经销商或有经验的广播/电视技术人员寻求帮助。
该设备已经过评估，以满足一般的射频暴露要求。

TWS XY-11

Function Instructions

Diagrammatic Sketch



Specifications

·Model:XY-11

·Bluetooth version: V5.3+EDR

·Earbud battery:30mAh

·Charging case battery:400mAh

·Power input:5V

·Product weight: about 36g

·Working time: 3.5hours

·Working voltage: 3.3V~4.2V

·Charging time: 70 minutes

·Speaker impedance: F6/32Ω

·Frequency response: 20-20KHZ

·Transmission distance:cover 10 meters

Package List

·Bluetooth headset（2PCS）

·Earphone Charging box

·Type-c charging cable

·User's manual

·Gift package

·Earphone caps（3 pairs）



How to use

1. The boot

Step 1: Open the top cover of the charging compartment.

Step 2: Take out the two earphones, at this time the earphones are automatically turned on and matched, waiting for the mobile phone to be connected manually

boot

Manual boot

If the headset is not in the charging compartment, press and hold the left and right ears for 2 seconds to power on.

2. To turn it off

Headphones automatically shut down

Step 1: After use, remove the earphone from the ear.

Step 2: Put the left and right earphones into the charging compartment and cover, it will automatically shut down and charge.

Manual shutdown

Step 1: If the earphones are powered on and connected to each other, press and hold the left/right ears

Shut down in seconds.

Step 2: Put the left and right earphones into the charging compartment to charge.

3. Bluetooth pairing

Step 1: Open the charging compartment.

Step 2: Turn on the Bluetooth of the mobile phone.

Step 3: Find the headset Bluetooth name "XY-11".

Step 4: Click Connect.

Note:If there is pairing device information,the headset will automatically connect to the device within 2-4s. If the headset is not connected to the device,it will automatically shut down after three minutes of standby.

4. Operation of earphone

(A) Answer/Hang up:
Click any headset to answer/end the call.
Hold down either earphone for 1.5 seconds to refuse to answer the call.

(B) Pause/play:
Click either earphone to pause or play the music.

(C) Previous/next:
During the music playing, double click the left earphone to complete the operation of the previous song.
Double-click the headset on the right during the music playing to complete the next song operation.

(D) Volume increase and decrease:
Tap the left earphone three times to increase the volume.
Click the right earphone three times to reduce the volume.

(E) Wake up the voice assistant:
After setting permissions on the IOS phone and screening SIRI functions, hold down the headset for 1.5 seconds to wake up SIRI.

Indicator working status

Working status	Indicator status
Put earbuds into charging case	The green breathes for one second
Charging for charging cas	The orange lights for 10 seconds
Full of charging	The Green lights for 4 seconds

Precautions for use

1. Headphones should be stored in a dry and ventilated environment to avoid contact with oil, water vapor and steam.In order to avoid affecting product performance.

2. Avoid cleaning with irritating, organic solvents or materials containing these ingredients.

3. The headset should be used according to the correct specification requirements,and pay attention to the influence of the using environment on the headset.

To ensure smooth connection, it is recommended that the distance between the mobile phone and the earphone be within 10 meters.

4. If the earphone fails to connect or communicate properly, do not remove the earphone without permission

The machine body and its accessories are not guaranteed otherwise.

5. To charge the earphone, please use the standard car charger or the one specified by our company.Chargers required.

6. To ensure normal use of the earphone, ensure that the power of the earphone is sufficient.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Disconnect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement.