


 *Music Playback*

 *15 White Noises*

Galaxy Projector **Pro**

User Manual



Initiate a romantic music galaxy light show

 WARNING (English)

- When projecting, please do not direct your eyes directly.
- This product should be kept away from heat sources, such as radiators, heat registers, stoves or other electrical appliances that generate heat.

Unboxing Check

- Thank you for purchasing our products, please read the user manual carefully before use. The user manual contains necessary safety advice and user instructions, follow them to operate to avoid damaging the product for misuse.
- Check the product to ensure it is in good condition when received. Do not disassemble the host and component by yourself.

Package List

- Galaxy Projector Pro x 1
- USB Type-C Cable x 1
- User Manual x 1
- Film Discs x 2 Boxes (6pcs/box)
- Wireless Remote Control x 1

Notices

- ⚠ Please use this product in a dark indoor environment.
- ⚠ This product requires the power adapter in DC 5V/2A, and connecting with USB Type-C cable.

Warm Tips


- Film discs are consumable accessories. To extend their lifespan, it is recommended to frequently alternate and replace them.
- For optimal projection results, it is suggested that users operate the projector in a dark environment, particularly when projecting onto a white background wall at a distance of 2 meters (6.56 feet) for best clarity and reality.
- The circular device on the top of the host is an adjustment focus knob, which can be adjusted by rotating it back and forth to achieve clear projection.
- The slow-speed mode of this product simulates the slow orbit of planets. If users prefer a faster rotation effect, it is recommended to switch to the fast-speed mode.
- This product supports wireless remote control to operate the main unit. When using the remote control, please ensure that it remains within range of the main unit.

Product Functions

- This product is an ultra-large focus adjustment projector with high resolution. Comes with 12pcs HD film discs, you can freely choose your favorite film disc for projection.
- With an ultra-large projection area, this galaxy projector brings you into an immersive starry ambiance.
- Designed with a one-arm reinforced rotating stand, it is convenient to project at different angles.
- This product has a built-in bluetooth speaker. When powered on, bluetooth is enabled by default and in pairing mode. You can use bluetooth to connect to "BL-DQY02" to play music.
- This product has 15 built-in white noise tracks, which can be played or switched via the remote control. The built-in white noise tracks are as follows:
① Lullaby 01, ② Lullaby 02, ③ Lullaby 03, ④ White Noise, ⑤ Babbling Brook, ⑥ Drizzling Rain, ⑦ Rolling Waves, ⑧ Summer Night Insects, ⑨ Bird Chirping and Cicada Singing, ⑩ Frog Croaking and Flowing Water, ⑪ Thunderstorm, ⑫ Wind Blowing Through Leaves, ⑬ Wind Chimes and Waves, ⑭ Joyful Burning, ⑮ Jungle Waterfall.

Operating Instructions

1. Figures:



2. Operations:

When using, insert the film disc with the "UP↑" side facing up into the film disc tray, and twist it into card slot to securely lock film disc in place.

Powering on the product automatically activates the projection status when plugged in. When powered on, bluetooth is enabled by default and in pairing mode. When using the remote control, please ensure that it remains within range of the main unit. The default rotation speed is slow, and the product is set to automatically shut down after 4 hours.

-  Power On/Off: Long press to power on or off the device, short press to enable or disable projection light.
-  Timer Setting: Short press to switch timer settings in sequence. The cycle sequence is: one-hour timer shutdown, two-hour timer shutdown, and cancel timer shutdown (automatically enters the default 4-hour auto-shutdown state). The indicator above the timer button shows the current timer setting: "1H" indicates one-hour timer shutdown, and "2H" indicates two-hour auto-shutdown.
-  BT-WN Button: Short press to switch between white noise playback mode and bluetooth playback mode. Long press to disconnect the currently connected bluetooth device, waiting for the projection light to flash three times, indicating that the current bluetooth device has been disconnected.
-  Rotation Speed: Short press to switch speed settings in sequence. The default setting is slow rotation, with the sequence as follows: slow rotation - fast rotation - stop rotation. The current speed setting can be checked via the indicator lights. When set to slow speed, the "S-" indicator light is on; when set to fast speed, the "S+" indicator light is on. When set to "stop," both "S-" and "S+" indicator lights are off.