



3. Film Discs Replacement Instructions:

(1) Standard Configuration: This product comes with 12 pieces of $\phi 18\text{mm}$ large pattern film discs.

(2) When installing the film disc, ensure that the film disc is positioned with the marked "UP↑" facing upwards and insert it into the slot aligned with the groove. Then, firmly grip the film gear and rotate it clockwise until it securely locks into place within the film disc card slot.




(3) When removing the film disc, please firmly grip the film gear with your hand and rotate the film disc in counterclockwise to align it with the groove of the film disc card slot before taking it out.



(4) Note: It is recommended to replace the film disc in the powered-off state.

4. Remote Control Function Description



① Power On/Off: Long press to power on or off the device, short press to enable or disable projection light.

② Play/Pause

③ Volume Up

④ Volume Down

⑤ Previous Song

⑥ Next Song


⑦ Timer Setting: Short press to switch timer settings in sequence. The cycle sequence is: one-hour timer shutdown, two-hour timer shutdown, and cancel timer shutdown (automatically enters the default 4-hour auto-shutdown state). The indicator above the timer button shows the current timer setting: "1H" indicates one-hour timer shutdown, and "2H" indicates two-hour auto-shutdown.

⑧ BT-WN Button: Short press to switch between white noise playback mode and bluetooth playback mode. Long press to disconnect the currently connected bluetooth device, waiting for the projection light to flash three times, indicating that the current bluetooth device has been disconnected.

⑨ Rotation Speed: Short press to switch speed settings in sequence. The default setting is slow rotation, with the sequence as follows: slow rotation - fast rotation - stop rotation. The current speed setting can be checked via the indicator lights. When set to slow speed, the "S-" indicator light is on; when set to fast speed, the "S+" indicator light is on. When set to "stop," both "S-" and "S+" indicator lights are off.

5. How to Adjust the Projection Focus:

- This product supports projection focus adjustment from 0.5 meters to 3 meters (1.64-9.84 ft).
- When adjusting the projection focus, rotate the focus adjustment knob in the positive or negative direction based on the current projection clarity to achieve a sharper image on the projection surface.



Common Troubleshooting:

- (1) No Power On: Check if the power adapter meets the product's specified input voltage standard (DC 5V/2A). Excessive input voltage can damage the product, while too low voltage may result in failure to power on.
- (2) Unclear Projection: Verify if the focus is adjusted to the optimal state. Ensure the projection distance and projected surface are appropriate.
- (3) Rotation Halt: Check if the rotation speed is set to either S+ or S-. Confirm if the corresponding speed indicator blue light is continuously on, indicating a successful speed setting.

Specifications

Product Model	BL-DQY02
Material	ABS
Power Input	DC 5V 2A
Maximum Power	10W
Projection Way	Film disc projection
Projection Source	LED Bulbs
Projection Distance	0.5m-3m/1.64-9.84ft
Projection Area	The projection area is 12.5m ² ~23.75m ² /134.55 sq.ft~255.64sq.ft at a 2m~3m/6.56ft~9.84ft projecting distance, and so on
Recommended Projection Environment	For optimal projection results, it is recommended to use the product in a dark environment, especially achieving the best clarity and reality when projecting onto a white background wall at a distance of 2 meters (6.56 feet).
Operating Temperature	-20°C~50°C/-4°F~122°F
Storage Temperature	-20°C~60°C/-4°F~140°F
Operating Environment	Use in a dark indoor environment
Bluetooth Version	Bluetooth 5.1
FCC ID	2AXGMBL-DQY02

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.


Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



★ Initiate a romantic music galaxy light show